

SLV-825/B/NC/NP/UB/VC

RMT-V127

SERVICE MANUAL




Photo:SLV-825

- Refer to the SERVICE MANUAL of VHS MECHANICAL ADJUSTMENT II for MECHANICAL ADJUSTMENTS. (9-972-816-11)

AEP Model
SLV-825
French Model
SLV-825B
E Model
North European Model
SLV-825NC
Spanish Model
SLV-825NP
UK Model
SLV-825UB
Germany Model
Swiss Model
SLV-825VC



SPECIFICATIONS

<p>Channel coverage</p> <p>VHF channels E2-E12 (A to H only for Italy) CATV channels S01-S03 CATV channels S1-S20 HYPER S21-S41 UHF channels E21-E69 SLV-825/825VC/825NC/825NP UHF channels B21-B68 SLV-825UB System B/G VHF channels E2-E12 CATV S3-S20 UHF channels E21-E69 System L VHF channels F2-F10 CATV S01-S23 HYPER S24-S44 UHF F21-F69</p> <p>SLV-825B</p> <p>Usable video cassettes</p> <p>VHS video format cassettes NTSC cassette recorded in SP mode can be played back on a PAL system television set</p> <p>Inputs and Outputs</p> <p>Video inputs</p> <p>LINE IN 2: phono jack EURO-AV (LINE 1): 21-pin (pin 20) SLV-825/825UB/825NC/825NP EURO-AV (LINE 3): 21-pin (pin 20) SLV-825 VC EURO-AV (LINE 3) PAY-TV DECODER : CANAL PLUS 21-pin (pin 20) SLV-825B</p>	<p>Audio inputs</p> <p>LINE IN 2: phono jack EURO-AV (LINE 1): 21-pin (pins 2 and 6) SLV-825/825UB/825NC/825NP EURO-AV (LINE 3): 21-pin (pins 2 and 6) SLV-825VC EURO-AV (LINE 3) PAY-TV DECODER : CANAL PLUS 21-pin (pins 2 and 6) SLV-825B</p> <p>Video output</p> <p>LINE OUT : phono jack EURO-AV (LINE 1): 21-pin (pin 19)</p> <p>Audio output</p> <p>LINE OUT: phono jack EURO-AV (LINE 1): 21-pin (pins 1 and 3) Stereo mini-minijack (1)</p> <p>CONTROL L CONTROL S IN/OUT</p> <p>Minijack (2) Minijack Stereo minijack</p> <p>Microphone input Headphone output</p> <p>Stereo minijack</p> <p>General</p> <p>Power requirements</p> <p>240 V AC, 50 Hz (SLV-825UB) 220-230V AC, 50 Hz (SLV-825/825VC/825NC/825NP /825B)</p> <p>Power consumption 33 W</p>	<p>Operating temperature</p> <p>5°C to 40°C (41°F to 104°F)</p> <p>Storage temperature</p> <p>-20°C to 60°C (-4°F to 140°F)</p> <p>Dimensions</p> <p>Approx. 466 X 115 X 395 mm (w/h/d) (18 3/8 X 4 5/8 X 15 5/8 inches) including projecting parts and controls.</p> <p>Weight</p> <p>SLV-825/825VC 7.9 kg (17 lb 7oz) SLV-825UB/825NC/825NP/825B 8.1 kg (17 lb 14 oz)</p> <p>Accessories Supplied</p> <p>See page 5.</p> <p>Note</p> <p>This appliance conforms with EEC directive 67/308/EEC regarding interference suppression.</p> <p>Design and specifications are subject to change without notice.</p>
---	--	--

Remote commander RMT-V127 is supplied as a unit for service. Don't supply individual parts except for the timer cover and the battery cover.



VHS VIDEO CASSETTE RECORDER
PAL
SONY

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety check before releasing the set to the customer:

Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampers). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

SAFETY-RELATED COMPONENT WARNING!!




COMPONENTS IDENTIFIED BY MARK  OR DOTTED LINE WITH MARK  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
1. GENERAL		4
2. DISASSEMBLY		
2-1.	Removal of Front Panel and Cabinet Assemblies	35
2-2.	Removal of Control Switch Block	35
2-3.	Opening of YC-124 Board and VI-116 Board	36
2-4.	Remove of DG-11, DI-43, and CN-62 Board	36
2-5.	Remove of HF-26, VP-33, CG-15 Board	37
2-6.	Remove of FL Cassette Compartment Assembly	37
2-7.	Remove of Power Block Assembly	37
2-8.	Remove of MF-167, 168, 169, 170 Board	38
2-9.	Remove of Mechanism Chassis and RP-147 Board	38
3. DIAGRAMS		
3-1.	Circuit Boards Location	39
3-2.	Over All Block Diagram	40
3-3.	Video (1) Block Diagram	43
3-4.	Video (2) Block Diagram	47
3-5.	Digital Picture Block Diagram	51
3-6.	Servo System Control Block Diagram	53
3-7.	Sytem Control Microcomputer Port Functions Description	55
3-8.	System Control - Servo Peripheral Circuit Interface -	57
3-9.	System Control - Mechanism Block Interface -	58
3-10.	System Control - Servo Peripheral Circuit Interface -	58
3-11.	System Control - Video Block Interface -	60
3-12.	System Control - Audio Block Interface -	61
3-13.	System Control - Tuner Block Interface -	62
3-14.	System Control - RF Modulator/Input Selector Block Interface -	62
3-15.	System Control - Digital Control Block Interface -	62
3-16.	Audio Block Diagram	63
3-17.	Timer Tuner, Mode Control 3Block Diagram	67
3-18.	Tuner Nicam Block Diagram	69
3-19.	Transcoder Block Diagram	71
3-20.	Power Supply Block Diagram	73

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE  SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.


SONY SLV835

Service Manual

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
4 PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS			7-5-5.	White Clip Dark Clip Adjustments (YC-124 Board)	197
4-1.	Frame Schematic Diagrams	75	7-5-6.	Recording Y Signal Level Adjustment (YC-124 Board)	197
4-2.	Printed Wiring Boards And Schematic Diagrams	78	7-5-7.	Recording Chroma Level Adjustment (YC-124 Board)	198
•	RP-147 Board	78	7-5-8.	PAL JOG AFC Adjustment (YC-124 Board)	198
•	YC-124 Board	84	7-5-9.	0.5H CCD Level Adjustment (YC-124 Board)	198
•	VI-116, CN-62, DI-43 Boards	91	7-5-10.	Secam Discrimination Adjustment (YC-124 Board) (SLV-825B Only)	198
•	CG-15 Board	97	7-5-11.	Secam Sync Gate Timing Adjustment (YC-124 Board)	199
•	DG-11 Board	102	7-5-12.	Secam Bell Filter Adjustment (YC-124 Board)	199
•	MA-140 Board	108	7-5-13.	Secam Recording Chroma Level Adjustment (YC-124 Board)	199
•	VP-33 Board	117	7-6.	Digital Picture and Character Generator System Adjustments	200
•	MD-58 Board	122	7-6-1.	Read Clock Adjustment (DG-11 Board)	200
•	HF-26 Board	127	7-6-2.	Write Clock Adjustment (DG-11 Board)	200
•	MF-168, 169, 170, TK-17, 18 Boards	132	7-6-3.	Tint Adjustment (DG-11 Board)	201
•	MF-167 Board	137	7-6-4.	Clamp Level Adjustment (DG-11 Board)	201
•	TC-27 Board	142	7-6-5.	Hue and Color Level Adjustment (DG-11 Board)	201
•	SW Block	146	7-6-6.	Character Generator Clock Check (CG-15 Board)	201
4-3.	Semiconductors	148	7-6-7.	AFC Adjustment (CG-15 Board)	201
4-4.	Indicator Tube, Fluorescent description ..	150	7-6-8.	Character Position Adjustment (CG-15 Board)	202
5. EXPLODED VIEWS			7-7.	Audio System Adjustments	202
5-1.	Front Panel And Cabinet Assemblies	151	7-7-1.	Hi-Fi Audio System Adjustment	202
5-2.	Power Supply Block Assembly	152	7-7-2.	Normal Audio System Adjustment	205
5-3.	Main Boards Assembly	153	7-8.	Tuner System Adjustment	205
5-4.	Fl, Cassette Compartment Assembly	154	7-8-1.	RF AGC Adjustment (IF501)	205
5-5.	Mechanism Chassis Assembly (1)	155	7-8-2.	Receive Separation Adjustment (MA-140 Board) (except UB model) ..	205
5-6.	Mechanism Chassis Assembly (2)	156	7-9.	Transcoder (TC-27 Board) Adjustment	206
5-7.	Mechanism Chassis Assembly (3)	157	7-9-1.	VCO-1 Adjustment	206
6. ELECTRICAL PARTS LIST		158	7-9-2.	VCO-2 Adjustment	206
7. ELECTRICAL ADJUSTMENTS			7-9-3.	I-REF-1 Adjustment	207
7-1.	Pre-Adjustment Preparations	193	7-9-4.	I-REF-2 Adjustment	207
7-1-1.	Instruments to be Used	193	7-9-5.	BELL-1 Filter Adjustment	208
7-1-2.	Connection	193	7-9-6.	BELL-2 Filter Adjustment	208
7-1-3.	Setup for Adjustment	193	7-9-7.	B-Y f ₀ Adjustment	208
7-1-4.	Alignment Tape (MH-2)	193	7-9-8.	R-Y f ₀ Adjustment	208
7-1-5.	Specified I/O Level and impedance	194	7-9-9.	Colour Output Level Adjustment	209
7-1-6.	Operating Method When the Front Panel Removed	194	7-10.	Adjustment Parts Arrangement Diagram	210
7-1-7.	Adjusting Sequence	194			
7-2.	Power Supply Check (Power Block)	194			
7-3.	System Control Adjustment	195			
7-3-1.	Clock Adjustment (MF-167 Board)	195			
7-4.	Servo System Adjustment	195			
7-4-1.	Switching Position Adjustment (MF-140 Board)	195			
7-5.	Video System Adjustment	196			
7-5-1.	Playback Y Signal Level Adjustment (YC-124 Board)	196			
7-5-2.	Y Signal NR Level Adjustment (YC-124 Board)	196			
7-5-3.	Sync AGC Adjustment (YC-124 Board)	196			
7-5-4.	Sync Tip Carrier Set and Deviation Adjustment (YC-124 Board)	197			

Identifying the Parts and Controls




Front Panel

See the indicated pages.


- 1 ON/STANDBY switch and indicator 7, 14
The indicator lights up in green when the VCR is turned on, and in red when the VCR is in standby mode.
- 2 Cassette compartment 15
- 3 Remote Sensor
- 4 Indicators
AUTO TRACKING 19
EDIT MONITOR 59
AUDIO INSERT 62
VIDEO INSERT 62
- 5 VCR Display panel 67
- 6 REC LEVEL controls 48
- 7 Upper drop-down panel
- 8 EJECT button 15
- 9 VPS (ON/OFF) button 28
(This button is provided on the SLV-825VC models only)
- 10 COUNTER RESET button 17, 61
- 11 Tape transport buttons
REW (rewind) button
PLAY button
FF (fast forward) button
HI-SPEED REWIND
STOP button
PAUSE button
- 12 EDIT STANDBY button and indicator 59
- 13 JOG dial 9, 13, 20, 21, 29, 33, 34, 51, 60, 61
- 14 LANC REMOTE button and indicator 60
- 15 TV/VTR button 7, 14
- 16 INPUT SELECT button 7, 14, 24, 34, 54, 59
- 17 REC MODE (SP/LP) button 4, 24, 48, 54, 59
- 18 EDIT ON/OFF button 55, 61
- 19 TIMER REC ON/OFF button 23, 24, 25, 27
- 20 QUICK TIMER button 24
- 21 TRACKING AUTO/MANUAL button 19, 33
- 22 PROGRAM +/- buttons 10, 13, 21, 29, 30, 34, 51
- 23 TRACKING NORMAL/SLOW (STILL ADJUST) buttons 19, 33
- 24 SHUTTLE ring 33, 60, 61
- 25 SYNCHRO EDIT button and indicator 60
- 26 REC (record) button 20, 21, 51
- 27 EDIT MONITOR (ON/OFF) button 61, 62

Front Panel




- 28 Remote Sensor
- 29 (cassette) lamp
- 30 PLAY lamp
- 31 PAUSE lamp
- 32 REC lamp
- 33 TIMER REC lamp
- 34 VPS lamp
(This indicator is provided on the SLV-825VC models only)
- 35 CL (clear) button 69
- 36 NTSC PB ON PAL TV (ON/OFF) switch 16, 17
- 37 COMMAND MODE VTR1/2/3 selector 8
- 38 SHARPNESS SOFT/SHARP control 16
- 39 PHONE LEVEL MIN/MAX control
- 40 CONTROL L jack 56
- 41 LINE IN 2 VIDEO/AUDIO jacks 48, 49, 53, 56
- 42 MIC (microphone) jack 62
- 43 PHONES (headphones) jack


Rear panel




- 1 RF CHANNEL screw (30-39) 14
- 2 AERIAL OUT socket 6, 28
- 3 EURO-AV (LINE 3) (21-pin) socket (SLV-825/825UB/825NC) 53, 57
EURO-AV (LINE 3) PAY-TV DECODER (21-pin) socket (SLV-825VC models only) 28, 53, 57
- 4 LINE OUT AUDIO/VIDEO jacks 6, 55
- 5 CONTROL S IN/OUT jacks 57
- 6 AC IN inlet
- 7 EURO-AV (LINE 1) (21-pin) socket 6, 28, 53
- 8 AERIAL IN socket 6
- 9 LOCAL/DX switch 14



Remote Control (with flap closed)









The buttons on the Remote Control with the same name or mark as those on the unit have the same function. The buttons with an orange dot can be used to remotely control Sony TVs having the  mark when the TV/VTR selector is set to TV. The TV/VTR button and/or the -- (10's digit) button cannot operate certain Sony TVs.

- 1 **TIMER ON SCREEN** button 25
- 2 **EDIT MONITOR** button 61, 62
- 3 **DATA SCREEN** button 17, 19, 43, 44
- 4 **AUDIO MONITOR** button 18, 45, 47
- 5 **SHUTTLE EDIT** buttons 51, 61
- 6 **|| PAUSE** button 16, 21, 32, 50, 51
- 7 **● REC** (recording) buttons 20, 21, 51
- 8 **INDEX** button 43, 44
- 9 **PROG** (programme) +/- buttons 10, 13, 21, 29, 30, 34, 51
- 10 **VOL** (TV volume) +/- buttons
Press to control the volume of the TV.
Effective only for Sony TVs with the  mark.
- 11 **COUNTER RESET** button 17, 61
- 12 **AUDIO/VIDEO INSERT** buttons 62
- 13 **REPLAY** button 32


Remote Control (with flap opened)



- 14 **TIMER REC (ON/OFF)** button 23, 24, 25, 27
- 15 **TV/VTR** remote control selector 8, 20
- 16 **Remote display** 67
- 17 **Programme position number** buttons 13
- 18 **--** (10's digit) button 13
- 19 **Various speed playback** buttons 32, 33
- 20 **TIMER CHECK/TIMER CLEAR** buttons 26
- 21 **Tape transport** buttons 16, 20, 30, 32, 39, 43, 44, 51, 62
 -  **SEARCH** (reverse/forward)
 -  **REW** (rewind)
 -  **PLAY**
 -  **FF** (fast forward)
 -  **STOP**
 -  **HI-SPEED REWIND**
- 22 **JOG/SHUTTLE function button and indicator** 33, 51, 61
- 23 **TV/VTR** button 12, 20, 29, 30, 31, 35
- 24 **(on/standby)** button 16, 27
- 25 **Timer recording/clock set** buttons 11, 22, 23, 26, 27
- 26 **COMMAND MODE** button 8
- 27 **Menu operation** buttons 9, 10, 12, 13, 18, 29, 31, 37-40, 46, 49, 58
- 28 **TV SCAN** button 34
- 29 **FUNCTION MEMORY** button 38
- 30 **P in P** (picture in picture) buttons 34, 35
P in P. SHIFT, DIGITAL OFF
- 31 **INPUT SELECT** button 23, 29, 35, 49, 51
- 32 **REC MODE** select button 20, 21
- 33 **INDEX MARK and ERASE** buttons 42, 44
- 34 **PROG** (programme) function button and indicator 9, 13, 20, 21, 29, 34, 35, 51, 54, 61
- 35 **SHUTTLE ring** 13, 29
- 36 **JOG dial** 9, 13

Note on the TV/VTR remote control selector
When you set the TV/VTR remote control selector on the Remote control to TV, the TV/VTR button cannot operate some Sony TV's.

Step 2 Connecting the VCR



- 1 Turn the VCR round so you can see the rear panel.
- 2 Disconnect the aerial input lead from your TV and connect it to the socket marked "AERIAL IN" on the rear of the VCR.
- 3 Connect the coaxial cable (supplied with the VCR) to the socket marked "AERIAL OUT" on the VCR and then plug it into the aerial input socket on your TV.
- 4 Check all connections and ensure they are firm.
- 5 Take the mains lead and plug it into the socket on the back of the VCR marked "AC IN". Then plug the other end into the mains supply.

Additional Connections

The hookup using the supplied coaxial cable shows the basic hookup to watch and record TV programmes. If your TV has a SCART connector, or the phono type audio/video input jacks, make additional connections. Additional connections can improve playback picture quality.


If your TV has a SCART connector: connect the EURO-AV connector of this VCR and 21-pin SCART connector on your TV, using the VMC-2121CE cable (SCART connector, not supplied).

If your TV has the phono type audio/video input jacks: connect the LINE OUT AUDIO/VIDEO jacks of this VCR and the AUDIO/VIDEO IN jacks of your TV, using the AV cable (supplied).

If you have made the VCR-TV connection using the LINE OUT AUDIO/VIDEO jacks, you can't use the on-screen information display.

Important
If you have made the VCR-TV connection using the EURO-AV connector, open the main MENU, move the arrow to "RF MODULATOR" and select "OFF". See "Customizing Your VCR" on page 40 for details.

Step 3 Tuning the VCR to Your TV




- 1 Having completed Step 2, press ON/STANDBY on the front of the VCR so that the green light above the button lights up. If you have made additional connections, skip step 3.
- 2 Press TV/VTR several times until "VTR" appears in the VCR display panel on the inside surface of the upper drop-down panel.
- 3 Press INPUT SELECT (on the inside surface of the upper drop-down panel of the VCR). Each time you press this, part of the display on the VCR will change. Keep pressing until "LINE L2" shows.
- 4 Turn on your TV and select a programme position that is not used to receive a TV station (in the UK, 0 or 9 perhaps).
- 5 Tune the TV so that a blue screen with tape counter (0:00:00) is clearly displayed on the TV screen. (If you have difficulty, please refer to the instructions for tuning your TV.)


- 6 Press INPUT SELECT again, and keep pressing it until "TUNER" shows in the VCR display panel.

You have now tuned your TV to the VCR. Whenever you wish to receive the VCR's playback picture on the TV, turn to the TV programme position you have set for the VCR, switch on the VCR and press TV/VTR.


Step 4 Preparing the Remote Control



- 1 Take the remote control and turn it over so that the remote display cannot be seen.
- 2 Slide and remove the cover.
- 3 Insert two R6 batteries.
- 4 Close the cover. Now you have "D VTR 3 :- :-" in the remote display. If you don't, check the battery polarities and position the batteries correctly. Also check that "VTR 3" is shown in the remote display. If not, lift the flap of the remote control and press COMMAND MODE several times until the command mode display "VTR 3" is shown in the remote display.



- 5 Check that the COMMAND MODE 1/2/3 selector (inside the lower drop-down panel of the VCR) is positioned at "VTR 3." If not, slide the selector so that it is positioned at "VTR 3."



- 6 Set the TV/VTR remote control selector to "VTR."

Notes on batteries

- Under normal operation, batteries last for about three months. If the remote control however, is not to be used for a long period, remove the batteries from the compartment to avoid possible damage from battery leakage.
- Do not use a new battery together with an old one.
- Do not use different types of batteries.



Note

When you insert the batteries into the remote control, the indication "VTR3" appears in the remote display. That tells you that the command mode setting of the remote control is set to "VTR3."




Getting Started

Step 5 Tuning the VCR to the Required Stations




Now that you have the blue screen on your TV, you can tune the individual channels on your VCR to receive the required stations.

- 1 Lift the flap on the remote control, point the remote control at the VCR and press MENU. The following menu comes up.



If you want to use the different language that is now displayed on the screen, see page 12.


- 2 Using ▲ or ▼ of the cursor keys on the remote control, move the cursor (▶) on the TV screen down to "TUNER PRESET", and then press EXE on the remote control. The menu shown at the right will appear on the TV screen:*



*The screen display differs depending on the model.

- To SLV-825UB users: "NORMAL/CATV" does not appear on the TV screen of your model. Therefore, skip steps 3 and 4 below.
- "PAY-TV" appears on SLV-825VC models only.

- 3 All except SLV-825UB models: using ▲ or ▼ of the cursor keys on the remote control, move the cursor (▶) on the TV screen up to "NORMAL/CATV." Then, move the dot to NORM using the left cursor key.



- 4 All except SLV-825UB models: using ▲ or ▼ of the cursor keys on the remote control, move the cursor (▶) on the TV screen down to "CHANNEL SET."


- 5 Close the flap and press PROG +/- on the flap of the remote control or PROGRAM +/- on the inside surface of the upper drop-down panel of the VCR to select the programme position.** The programme number will change in the VCR display panel and on the TV screen.

**Another way to select the programme position is:

Press the PROG function button on the remote control to light the indicator beside the button and turn the jog dial clockwise for higher numbered programme position or counterclockwise for lower numbered programme positions.

(Continued)

Step 6 Setting the Clock



6 Once you have selected the programme position, open the flap and tune to the channel required using ◀ and ▶ of the cursor keys on the remote control. The channel number automatically increases with ▶ and decreases with ◀. (In Italy, channel numbers 13 to 20 correspond to channels A to H.) The number stops changing when the first broadcast programme received is displayed; the programme will be displayed briefly before the screen turns blue again.


7 If this is the broadcast programme required*, press EXE to store it. If it is not, keep searching, i.e. go back to step 6.

8 Now that you have stored a channel against your chosen programme number, go back to step 1 and repeat storing all the channels required against the different programme numbers.


*A faster way to store broadcast channels (say, if your area has a lot of broadcast channels) is to do the following alternative steps 7 and 8:

7 If this is the broadcast programme required, press PROG+ once (on the remote control) to automatically store it. To store the next broadcast channel, return to step 5.


8 Having stored all the broadcast channels against your chosen programme numbers, press EXE.



If the received picture is unclear
Press ◀ or ▶ of the cursor keys on the remote control until you get a clearer picture.



For setting the day, month and year




For setting the time

The last thing you need to do in Getting Started is set the clock on the remote control.


1 To do this, lift the remote control flap.

2 The items in the remote display flash to tell you that the remote control is ready to receive your clock setting data.



3 Press CLOCK SET.

4 Press the button marked "D" (top to go forward and bottom to go backwards) until today's day, date, month and year are indicated. Keep pressing the "D" button going through the dates, months and years until the correct data is set. **If you keep the "D" button pressed, the display will change more rapidly.**



5 Press the H and M rocker buttons under the flashing "0:00" on the remote display. Use these buttons to set the correct time. Once done the correct date, month, year and time are all shown on the remote display.

6 When you are satisfied that all the information is correct, point the remote at the VCR and press TRAN at the exact time corresponding with a time signal from the accurate clock, radio, telephone and so on. The clock will start at 00 second. The correct time should appear in the display on the front of the VCR when the VCR is off.



7 Close the remote control flap.

The following section "Additional Presetting Functions" describes various functions concerning setting up your VCR. Read through the section briefly to get to know the functions.

Now that you have finished all the things you should do in "Getting Started", you should proceed to "Basic Operations" to enjoy real home video life.

When --- lights up in the VCR display panel


Any time power is interrupted for more than one hour, you will see --- lighted when power is restored. You will have to re-set the date and clock again.

When a short beep sounds repeatedly

The VCR is in timer recording or quick timer recording or standby mode for timer recording, and the setting cannot be transmitted.

To correct the preset date and time
Open the remote control flap, repeat steps 2 to 7.

Additional Presetting Functions



Controlling Other Sony VCRs with This Remote Control

If the equipment has a command selector
Set the command mode selector to other position than "VTR 3", and press COMMAND MODE several times until the same command mode display as you have selected for the equipment is shown in the remote display.





If the equipment doesn't have a command selector
The command mode of this remote control should correspond to the settings listed below.

- If other equipment is a Sony Betamax infrared remote control VCR, select VTR 1.
- If other equipment is a Sony 8 mm format VCR, select VTR 2.
- If other equipment is a VHS format VCR, select a command mode position other than "VTR 3," which is selected for this VCR.

Selecting the Language on the MENU

Most of the operations are done using the on-screen display (MENU). You can also select the language you want to display on the TV screen. Once you have selected the language, you can use the on-screen display in your language.

- 1 Turn on the TV and VCR.
- 2 Press TV/VTR on the remote control several times until "VTR" appears in the VCR display panel. (If you have made only an aerial connection, turn to the video channel you set the VCR to in Step 3.)
- 3 Lift the remote control flap.
- 4 Press MENU.
The main MENU appears on the TV screen.
- 5 Move the cursor (▶) to "LANGUAGE".
- 6 Press EXE.
The LANGUAGE menu appears.
- 7 Select the language which you want to use for the on-screen display, using ▲ or ▼ of the cursor keys on the remote control.
- 8 Press EXE when you have finished selecting your option.



On FINE TUNING indicator
This indicator shows the operable fine-tuning range and stops at the optimal point of reception. When the VCR's tuner is receiving an optimal broadcast signal, the indicator stops at the centre position or one space right or left of the centre position. However, even when a broadcast is received in an optimal condition, the indicator may not be at the position described.

Allocating the Channels Directly

Enter the desired programme numbers using the programme position number buttons. To enter one's digits, press the desired number. To enter two digits numbers, press the /- (10's digit) button, then press the ten's digit number and the one's digit number.

Disabling Unwanted Channels


If you want to let only desired programme positions appear when you select the programme position for normal recording, quick timer recording or timer-activated recording, you can do this by following the procedure below.





- 1 Press MENU, move the cursor (▶) down to "TUNER PRESET" and press EXE.
- 2 Press PROG +/- on the flap of the remote control or PROGRAM +/- on the inside surface of the upper drop-down panel of the VCR until the programme position you want to disable appears in the PROG field of the TUNER PRESET menu.
You can also use the jog dial to select the programme position. To use this, press PROG function button to light the indicator beside the button.
- 3 Press programme position number button 0 twice or keep pressing the left and right cursor keys until "0" is displayed in the CHANNEL SET field.
- 4 Repeat steps 2 and 3 to disable other programme positions.
- 5 Press EXE.

If You Can't Get a Clearer Picture -Fine -Tuning

Normally, the Auto Fine Tuning (AFT) setting on the TUNER PRESET menu is set to ON, and the AFT function fine-tunes the picture. If the picture of a programme is not acceptable, fine-tune it manually.

- 1 Select the programme position in which the picture is distorted using PROG +/- on the flap of the remote control or PROGRAM +/- on the inside surface of the upper drop-down panel of the VCR.
You can also select the programme position by pressing the PROG function button on the remote control to light the indicator beside the button and turn the jog dial clockwise or counterclockwise.
- 2 Press MENU, move the the cursor (▶) down to "TUNER PRESET" and press EXE.
- 3 Press ▲ or ▼ of the cursor keys to move the cursor (▶) down to FINE TUNING.
The FINE TUNING indicator is displayed in the TUNER PRESET menu.
- 4 Press ▲ or ▼ of the cursor keys to get a clearer picture.
The AFT function switches off automatically.
- 5 If you can't get a better picture, press ▲ to move the cursor (▶) up to "AFT," select "ON" and press EXE.
The TV screen returns to the original screen.









If You Have Failed in Tuning the VCR to Your TV

- 1 Find a UHF channel between 30 and 39 where there is no picture and you can hear a steady rustling sound or no sound at all.
- 2 Press INPUT SELECT several times until "LINE L2" appears in the VCR display panel.
- 3 Press TV/VTR several times until "VTR" appears in the VCR display panel.
- 4 With the supplied plastic adjuster, turn the RF CHANNEL screw (at the rear of the VCR) to a channel where your TV clearly displays a blue screen with the tape counter.
- 5 Press INPUT SELECT several times until "TUNER" appears in the VCR display panel.
- 6 Press PROGRAM +/- to see if the TV screen changes to a different channel.

If the TV Signal is too Strong

You can strengthen or attenuate the reception signals using the LOCAL /DX switch at the rear of the VCR. Normally set this switch to the DX position. If the reception signals are very strong, set it to the LOCAL position.

Playback



This section shows you how to play back a video cassette.

Inserting a Video Cassette

- 1 Open the upper-drop down panel.
- 2 Insert a video cassette.
- 3 Gently press the centre of the front side of a cassette with the arrow indication facing upwards until the mechanism draws it into the compartment. When the cassette has been loaded, the cassette indicator lights in the VCR display panel and the VCR turns on automatically. If you insert a cassette with its safety tab removed, playback starts automatically.

Ejecting the Cassette

Press EJECT on the VCR.


You can eject the cassette even if the power is off. When you press EJECT, the power is turned on. After ejecting the cassette, the power automatically shuts off.

Note
You cannot eject a cassette during recording or recording pause mode.

Protecting your cassette against accidental erasure

The cassette is provided with a safety tab to protect against accidentally erasing a previous recording. Break off the safety tab with a screw driver or a similar tool as shown on the illustration at left. If the safety tab is removed, the VCR ejects the cassette when you try to record on the cassette.

To record on a cassette with the safety tab broken off, simply cover the tab hole with adhesive tape.



Playing Back a Cassette

The VCR automatically detects the tape speed (SP or LP) with which a cassette was recorded. If you insert a cassette with its safety tab removed, playback starts automatically.

- 1 Insert a cassette.
The VCR turns on automatically.
- 2 Press TV/VTR several times to light up the VTR indication in the display window of the VCR.
- 3 Turn on the TV.
If you have made only an aerial connection, turn to the programme position you set the VCR to in "Step 3 Tuning the VCR to your TV" on page 7.
- 4 Set the NTSC PB ON PAL TV ON/OFF switch to "ON" if you play back an NTSC-recorded tape.
- 5 Press ► PLAY.
When the tape reaches the end, it automatically rewinds.

To stop playback
Press ■ STOP.

To stop play back for a moment
Press || PAUSE.
Press || PAUSE again or press ► PLAY to resume playback.

To advance the tape rapidly
Press ■ STOP, then ►► FF.

To rewind the tape.
Press ■ STOP, then ◀◀ REW.


To rewind the tape at a higher speed
Press ◀◀◀ HI-SPEED REWIND.

To start playback automatically after rewinding a cassette (AUTO PLAY)
This feature works only from the VCR.
Press ► PLAY while holding ◀◀.
The "►" indication flashes while the tape is being rewound.

To view the picture during fast forward mode or rewind mode
Keep pressing ►► during fast forward, and keep pressing ◀◀ during rewind. Release the button to return to fast forward or rewind.


To turn the VCR on or off
Press ON/STANDBY on the VCR or I on the remote control.

Adjusting the sharpness of the picture
Turn the SHARPNESS control inside the lower down-panel of the VCR.
Turn to SHARP to get a sharper picture, and to SOFT to get a softer picture.



— 11 —

Never unplug the power cord while the tape is in motion. This may cause the tape to be jammed in the VCR. When you need to unplug the mains lead, be sure to remove the cassette or turn off the power of the VCR.



NTSC PB ON PAL TV ON/OFF switch

When the data screen does not appear on the TV screen

Check to see that the LINE OUT jacks are connected to the line input jacks of the TV. If this is the case, the data screen doesn't appear.

Notes on counter reading


- The counter does not work on the portions on which no recording has been made.
- After a cassette is ejected, the counter reading is retained.

When a cassette is inserted in the VCR, the counter reading automatically returns to "0H00M00S."

Using the Data Screen

The data screen may appear on your TV screen when you first turn on the VCR. If the data screen does not appear, press DATA SCREEN on the remote control. The data screen does not appear when the NTSC PB ON PAL TV switch is set to ON.

The Data Screen with Tape Counter Display



To turn off the data screen
Press DATA SCREEN.

Indexing Tape Contents

You can use the tape counter as a reference to locate a desired scene by rewinding the tape.
Press COUNTER RESET on the remote control or on the VCR to set the counter to "0H00M00S" (counter zero position) before you play back or record.
To view a desired scene after playback or recording, rewind the tape to the counter zero position.




NTSC-recorded Tapes

You can play back a cassette recorded in NTSC video system using the SP mode (NTSC-recorded tape) on a PAL system television set. If the tape is recorded in the Hi-Fi system, the Hi-Fi sound can be reproduced.

Slide the NTSC PB ON PAL TV ON/OFF switch to "ON" every time you watch an NTSC recorded tape.
When you watch a PAL recorded tape, return the NTSC PB ON PAL TV switch to OFF. And if you are using a TV equipped with the COLOUR SYSTEM selector switch, set the COLOUR SYSTEM selector switch to "PAL."

The following will occur during playback of an NTSC-recorded tape

- The time/tape-counter display will not appear even if you press DATA SCREEN.
- Depending on the TV you are using, the following phenomena may occur separately or in combination:
 - the picture becomes black and white
 - the picture shakes
 - no picture appears on the screen
 - black streaks appear horizontally on the screen
 - the colour density increases or decreases
 - the audio becomes normal audio and noise appears in LP and EP mode
- If a tape has portions recorded in PAL and NTSC video systems, the tape counter reading is not correct. This discrepancy is due to the difference between the counting cycles of the two video systems.
- You may not use the digital functions for an NTSC-recorded tape. For details see page 34.
- You cannot edit the NTSC-recorded tape onto another VCR.



Selecting the Monitor Sound

You can select the sound you want to hear when you play back a stereo or bilingual tape, or when you want to play back a tape on which sounds were mixedly recorded on the Hi-Fi audio track and the normal audio track.

Listening to a Stereo or Bilingual Tape



Press AUDIO MONITOR to select the sound to hear. With each press, you change from stereo (left and right channel sounds), to left-channel sound, to right-channel sound or to the sound on the normal audio track. The selected sound type appears in the display window of the VCR.

Display	Sound heard	
	Stereo tape	Bilingual tape
STEREO	Stereo	Left and right channels
MAIN/L	Left channel	Left channel
SUB/R	Right channel	Right channel
No indication	Monaural (on normal audio track)	Sound on normal audio track

Listening to Mixed Sounds



You can hear the sounds recorded on the Hi-Fi audio track and the normal audio track at the same time. This function is useful when you listen to an audio-inserted tape. (For details on the audio insert function, see page 61.)

- Press MENU. The main MENU appears.
- Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "MODE SET."
- Press EXE. The MODE SET menu appears. If the MODE SET [PAGE 1] menu is displayed on your TV screen, press ▲ or ▼ of the cursor keys to move the cursor (▶) to "NEXT PAGE," then press EXE. The MODE SET [PAGE 2] menu appears.
- Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "AUDIO MIX."
- Select ON or OFF using ◀ or ▶ of the cursor keys.
ON: to make the AUDIO MONITOR button inoperative so that the sounds of the Hi-Fi video and normal audio tracks are always output.
OFF: to make the AUDIO MONITOR button operative so that you can select the sound to hear.
- Press EXE to store the setting. The TV screen returns to the original screen.



You cannot select the monitor sound in the following cases

- When a monaural tape (a tape which has no recording on its Hi-Fi track) is played back.
- When AUDIO MIX ON is selected in the MODE SET menu.



When the sound on the Hi-Fi audio track is not clear, adjust it with TRACKING NORMAL/SLOW (STILL ADJUST) ▼/▲. When the recording condition is poor, you can't adjust.

Removing Picture Distortion


Usually, the tracking control function removes picture distortion automatically. However, occasionally, streaks or "snow" may appear on the screen when you play a video tape. When this happens, you can adjust the tracking manually.

Automatic Tracking Adjustment

"AUTO TRACKING" flashes while the VCR is searching for the best tracking condition and lights steadily when it finds the best possible tracking. If the VCR cannot find the best tracking condition, adjust the tracking manually.

Manual Tracking Adjustment


- Press DATA SCREEN to display the tape counter on screen.
- Press ▼/▲ on the TRACKING NORMAL/SLOW (STILL/ADJUST) buttons to get the best picture. The tracking meter appears on the screen. The distortion should disappear as you press one of the two buttons. The tracking meter does not appear when the NTSC ON PAL TV switch is set to ON.



When you cannot get a better picture even if you have made manual tracking, press AUTO/MANUAL to return automatic tracking adjustment mode.

To return to the tracking meter to its normal position Simultaneously press ▼/▲ on the TRACKING NORMAL/SLOW (STILL/ADJUST) buttons.

Recording TV Programmes



You can record TV programmes in one of three ways:
 -While you are watching the programme (this page)
 -While you are watching another programme (See page 21)
 -While you are not watching the TV at all (See page 21.)

Before you begin


- Make sure that the connections have been made correctly (see "Step 2 Connecting the VCR" on page 6.)
- Check that "TUNER" lights up in the VCR display panel.

Recording While Watching the TV Programme

- 1 Insert a cassette. (Its safety tab must be in place.)
The VCR turns on automatically (Auto power on).
- 2 Turn on the TV.
- 3 Press TV/VTR on the remote control several times until "VTR" appears in the VCR display panel. (If you have made only an aerial connection, turn to the video channel you set the VCR to in "Step 3 Tuning the VCR to Your TV" on page 7.)
- 4 Select SP or LP with REC MODE (SP/LP).
In the LP mode, you can record twice as long as in the SP mode.
- 5 Press PROG+/- on the flap of the remote control or PROGRAM +/- on the inside surface of the upper drop-down panel of the VCR to select the programme position.
You can also use the jog dial to select the programme position. To use this, press the PROG function button to light indicator beside the button. Turn the jog dial clockwise for higher numbered programme positions or counterclockwise for lower numbered programme positions.
The programme number will change in the VCR display panel and on the TV screen.
- 6 Press the two ●REC buttons on the remote control at the same time, or the REC button on the VCR.
The REC (recording) indication lights up in the VCR display panel.

To stop recording
Press ■STOP.

When the cassette reaches the end
The cassette rewinds to the beginning automatically and the power remains on.



Pausing

You can stop recording an unwanted scene and resume recording smoothly.

- 1 Press ■ PAUSE when an unwanted scene appears.
Recording will stop and the VCR enters recording pause mode.
- 2 Press ■ PAUSE again at the desired point to release pause mode.
Recording resumes from the point set in step 1.

When the recording pause mode lasts for approximately 5 minutes, the VCR enters stop mode.

Recording with the TV Off

Turn off the power of the TV or monitor.
There will be no interference with the recording.

Recording While Watching Another Programme

The recording procedure differs depending on the type of TV-VCR connection you have made.

- 1 Record the programme following the steps 1 to 6 on page 20.
- 2 Do one of the following depending on the type of connection your VCR has:

If you have made a EURO-AV connection:


- 1 Press TV/VTR until "VTR" disappears from the VCR display panel.
- 2 Select the programme you want to watch on the TV.

If you have made an aerial connection only:

Select the programme you want to watch on the TV.

If you have made a LINE OUT VIDEO/AUDIO connection:


- 1 Select the tuner input on the TV.
- 2 Select the programme you want to watch on the TV.



If the tape is ejected when the REC buttons are pressed
The tab on the cassette is out.
Use another cassette with its safety tab intact.

If you are using a Sony TV
You can use the remote control of this VCR to operate the TV.
When doing this, slide the [TV/VTR] remote control selector at the top of the remote control to "TV." To operate the VCR, return the [TV/VTR] remote control selector to "VTR."

Timer-Activated Recording



The timer recording function lets you preset your VCR to record up to eight programmes within a one-month period. Perform this procedure on the remote control and transmit the preset data to the VCR.

Before you begin

- Make sure that the time and date clock is set correctly (see "Step 6 Setting the Clock" on page 11.)
- Check to see that the cassette is long enough to record all the programmes.
- Make sure that the safety tab of the cassette has not been removed. If you insert a cassette without a safety tab and try to set the timer, a short beep sound will be heard repeatedly and the cassette automatically ejects from the VCR.

Setting the Timer


Example

Here is how to record a broadcast on programme position 8 from 20:00 to 20:50 on Friday, 27th November 1992, in SP mode.


- 1 Open the flap of the remote control. The remote control enters timer preset mode.

Note:
Never close the flap until you finish transmitting the programme data to the VCR.


- 2 Press D (DAY) until 27 appears. The day of the week (Friday) is automatically set.



- 3 Press H under the TURN ON section until 20 appears.





- 4 Press M under the TURN ON section until 00 appears.




- 5 Press H and M under the TURN OFF section until 20:50 appears.


- 6 Press PROG+/- until 8 appears.



- 7 Set the recording speed, SP or LP, with REC MODE (SP/LP). The TRANSMIT indicator flashes to tell you that all of the items have been entered.



- 8 Point the remote control to the VCR and press TRANS. Press TRANS within five minutes after you have entered all the items. A beep sound will tell you that the preset data have been transmitted to the VCR, and the VCR enters recording standby mode. The TIMER REC indicator lights up in the VCR display panel and the contents of the timer setting you've just transmitted to the VCR also appears in the VCR display panel. The PROGRAM LIST appears on the TV screen for a few seconds if the VCR is turned on.



To set another programme, repeat steps 2 to 8.

- 9 Close the flap of the remote control so that the present time appears on the remote display. The VCR turns on automatically and starts recording at the preset time, then turns off after recording ends.

To stop timer-recording

To stop timer-recording while a programme is being recorded, press TIMER REC (ON/OFF).

To rewind the tape after timer recording is over

Use the TIMER REC-REW function (for details, see page 41).


To record video source from the EURO-AV (LINE1) connector, EURO-AV (LINE3) connector or LINE IN 2 AUDIO/VIDEO jacks
Press INPUT SELECT any time in steps 1 to 6 to change the indication from PROG-- to LINE L1 (for the EURO-AV (LINE 1) connector), LINE L2 (for the LINE IN 2 AUDIO/VIDEO jacks), or LINE L3 (for the EURO-AV (LINE3) connector).

To record a TV programme and audio signals from equipment connected to the EURO-AV (LINE 1) connector or LINE IN 2 AUDIO simultaneously.

For selecting the audio input terminal, see item "SIMUL AUDIO IN" on page 40. Set the desired programme position and press INPUT SELECT to indicate SIMUL in step 6.

If power interruption occurs during timer recording
Recording will stop and your VCR will turn off. If power is restored within one hour, and it's before the recording end time, recording will start again from that point. If the interruption lasts for more than one hour, any presettings will be erased and you'll need to reset the time and date for your programmes. Note that the tape counter will return to "0H00M00S."

To record a satellite programme from a satellite tuner connected to EURO-AV (LINE 3) connector
Press INPUT SELECT to display "LINE L3" in the remote display. You need a commercially available timer to turn on/off the satellite tuner at the preset time. The programme position to be recorded must be preset on the satellite tuner.





Daily/Weekly Recording

You can preset your VCR for daily or weekly recording.

Daily recording records the same programme every day of the week, while weekly recording records the same programme on the same day, every week.

In step 2 of the "Setting the Timer" section (page 22), press the -(minus)-side of the D button to change the indication in the remote display to one of the choices. (See the diagram at left.) When you set and transmit your preset data to the VCR, the corresponding indicator lights up in the VCR display panel.



If your cassette ends during quick-timer recording Recording stops and the VCR turns off. The cassette will not rewind automatically.

If a power interruption occurs during quick-timer recording Recording will stop and the VCR will turn off. If the interruption lasts less than one hour and the power is restored before the recording end time, recording will start again from the time the power is restored.

For the buttons you can use during quick-timer recording See page 22.

Quick-Timer Recording


This function is convenient for recording programmes without going through the entire timer setting procedure. Note, however, that it provides only an approximate setting for the programme you wish to record. If you're currently recording, skip to step 7.

- 1 Insert a cassette into your VCR.
- 2 Press INPUT SELECT to select TUNER.
- 3 Select the desired recording speed (SP or LP) by pressing REC MODE on the inside surface of the upper drop-down panel.
- 4 Press QUICK TIMER on the VCR. If you insert a cassette with the safety tab removed, your VCR will eject the cassette.
- 5 Select the programme position you wish to record using PROGRAM +/- on the inside surface of the upper drop-down panel of the VCR. The programme position can be changed while the programme position indicator is flashing (for about 30 seconds).
- 6 Press QUICK TIMER again to start recording. Unless you press QUICK TIMER within 30 seconds, the power will be turned off.
- 7 Select the recording duration by pressing QUICK TIMER to change the duration indicator in the display window. Each time you press QUICK TIMER, the recording duration increases by 30 minutes (up to 8 hours). Once recording has finished, your VCR will turn off automatically. During quick-timer recording, the recording time can be changed by pressing the QUICK TIMER button. During recording, the time displayed will count down in units of one minute.


To stop quick-timer recording

To stop quick-timer recording while a programme is being recorded, press TIMER REC (ON/OFF).


Case 1



Case 2



Case 3



Overlapping Timer Recordings

If you have made a "mistake" when presetting multiple programmes, the VCR will interpret your settings as described in the following cases.

Case 1: If you preset two programmes to record at the same time...

The programme listed first on the PROGRAM LIST display has priority over the other programmes. The timer settings for lower priority programmes will be deleted from the PROGRAM LIST display when recording begins for the first programme.

Case 2: If you set programme 2 to record at the same time you set programme 1 to finish recording...

The last 20 seconds of programme 1 will not be recorded.


Case 3: If you set programme 2 to record before programme 1 has finished recording...

Programme 2 will begin recording before programme 1 has finished.

Checking the Timer Settings


Here's how to display your timer settings to confirm the programmes you wish to record.


- 1 Press TIMER REC (ON/OFF) to release timer recording standby mode. The TIMER REC (recording) indicator turns off in the VCR display panel.
- 2 Press \odot to turn on the VCR.
- 3 Press TV/VTR so that the VTR indicator lights up in the VCR display panel.
- 4 Turn on the TV. If you have made only an aerial connection, turn to the video channel you set the VCR to in "Step 3 Tuning the VCR to Your TV" on page 7.
- 5 Press TIMER ON SCREEN. The PROGRAM LIST appears on the TV screen for you to check.
- 6 After you have checked the settings, press TIMER ON SCREEN again. The original TV screen appears.
- 7 Press TIMER REC (ON/OFF) to return to timer recording standby mode. The TIMER REC (recording) indicator turns on in the VCR display panel.



Notes

- If you set a programme to record only one time, that setting is erased from the PROGRAM LIST display when the recording has finished.
- To check the timer settings during timer recording, press TIMER ON SCREEN.





Changing or Cancelling the Timer Settings

Here's how to change or cancel any timer settings on the PROGRAM LIST display.

- 1 Display the PROGRAM LIST display on the TV screen. Follow steps 1 through 5 of the "Checking the Timer Settings" (page 25) section.
- 2 Press TIMER CHECK to display the cursor (▶).
- 3 Press TIMER CHECK to move the cursor (▶) to the setting you want to change or cancel.
- 4 **To change the setting**
Re-enter all the items and transmit it to the VCR. (See "Setting the Timer" on page 22.)
The VCR returns to timer recording standby.



To cancel the setting
Press TIMER CLEAR.

To change or cancel timer settings without using the PROGRAM LIST display

Using this method, you can change or cancel the timer settings without releasing the timer recording standby mode.

- 1 Press TIMER CHECK repeatedly until the programme you want to change or cancel appears in the VCR display panel.
- 2 **To change the timer setting**, change the settings and press TRANS to transmit it to the VCR.

To cancel the setting, press TIMER CLEAR.
The timer setting of the selected programme is cancelled.



Using the VCR Before Timer Recording Starts

- 1 Press TIMER REC (ON/OFF).
The TIMER REC (recording) indicator in the VCR display panel turns off and the VCR leaves the timer recording standby mode.
- 2 Press ⏻.
The VCR is ready to use.
A short beep sound will be heard and the message will appear on the TV screen five minutes prior to a preset timer start time.
- 3 After using the VCR, press TIMER REC (ON/OFF).
The VCR returns to the timer recording standby mode.


Storing the Timer Settings

Once a one-time programme has been recorded, the setting is cancelled, and if you wish to record at that time again, you need to reenter the settings. Daily/Weekly recordings are of course kept in memory and repeated until you change them. However, if you store the timer settings into the remote control's memory, you can recall the timer settings whenever you want. You can store up to four settings into the remote control's memory. Each setting is stored into one of four positions (A, B, C and D). Moreover, the recording date shifts automatically to the next week after the recording is completed. Thus, you can have easy access to the most frequently used settings, especially your favourite weekly programme.

- 1 Press MEMORY so that MEMORY A appears in the remote display.
- 2 Set all items for timer-activated recording. (See "Setting the Timer" on pages 22 and 23.)
The setting is stored in MEMORY A.
- 3 If you want to store other settings, press MEMORY several times until the positions you want to store settings (B, C, or D) appears, then repeat step 2.
The settings are kept in memory even if you close the flap of the remote control.

Recalling and re-entering the settings

- 1 Press MEMORY several times until the indication (A, B, C or D) you want to recall/change appears.
- 2 Make whatever changes you want.
- 3 Press TRANS.
The VCR enters timer-activated recording standby mode.




VPS Recording (SLV-825VC models only)

The German broadcasting system transmits VPS (Video Programme System) signals with its TV programmes. These signals assure you that your timer recordings are made regardless of broadcast delays, early starts, or broadcast interruptions. For example, if an urgent news bulletin interrupts a regular programme, recording will stop. As soon as the interrupted programme resumes, recording starts again.

1 Make sure the "TIMER REC" indicator is not lit in the VCR display panel.

2 Before setting the timer to record, press VPS (ON/OFF) on the inside surface of the upper drop-down panel so that the "VPS" indicator lights in the VCR display panel.





3 Set the timer following the steps of "Timer-Activated Recording" (page 22). The VCR will enter standby mode for VPS recording well before the turn-on time so as to be ready if there is a change in the start time. The VPS lamp on the front panel lights up when the signal with VPS label is received by the VCR. The VPS indicator in the VCR display panel lights up when you press the VPS (ON/OFF) button on the inside surface of the upper drop-down panel.

Notes on VPS Recording

- If recording times overlap due to a VPS time shift, the programme that was broadcast first has priority. The second programme will begin to record only when the first programme has finished.
- The VPS button is effective only when TIMER REC does not light up in the VCR display panel.
- If the VPS cannot receive a VPS signal because the signal is too weak or because the station failed to transmit VPS signals, the VCR will record the programme without the VPS function regardless of the VPS indication in the VCR display panel.

PAY-TV Programme Recording (SLV-825VC models only)


You can watch or record a PAY-TV programme if you connect the decoder (not supplied) to the VCR. (See the connection below.)



Presetting PAY-TV programme Broadcasts


Before watching or recording a PAY-TV programme, you should preset PAY-TV programme broadcasts to store them into the VCR.

- 1 Turn on the VCR and TV.
- 2 Press INPUT SELECT so that "TUNER" appears in the front panel display.
- 3 Turn on the TV.
- 4 Press TV/VTR on the remote control several times until "VTR" appears in the VCR display panel.
- 5 Call up the TUNER PRESET menu. (See "Step 5 Tuning the VCR to the Required Stations" on page 9.)



- 6 Press PROG +/- on the flap of the remote control or PROGRAM +/- on the inside surface of the upper drop-down panel of the VCR to select the programme position. You can also use the jog dial to select the programme position. To use this, press the PROG function button to light the indicator beside the button. Turn the jog dial clockwise for higher numbered programme positions or counterclockwise for lower numbered programme positions. The programme number will change in the VCR display panel and on the TV screen.


- 7 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "CHANNEL SET" and tune in PAY-TV channels.



- 8 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "PAY-TV" and select "ON." Then press EXE.

Important


Once you have preset a single TV programme with the PAY-TV setting ON, the upper EURO-AV connector on the rear of the VCR can't be used as an external connector (LINE 3), but can only be used as the connector which is connected with the PAY-TV decoder. Because of this, "LINE 3" will not appear even if you press the INPUT SELECT button. The input mode indication will then change as:



If all the TV programmes are preset again with the PAY-TV setting OFF, the upper EURO-AV connector can be used as a LINE 3 input terminal and LINE 3 becomes effective when you connect any other equipment except the PAY-TV decoder to this connector.

Notes

- So long as the decoder is connected to the VCR, make sure to keep the mains lead of the decoder connected to an AC outlet.
- If you want to store normal television programmes, make sure that the PAY-TV in the TUNER PRESET menu is set to "OFF."



Recording a PAY-TV programme

Turn on the power of the decoder first.
For the steps other than described below, refer to "Recording TV Programmes" on page 20.

To record a PAY-TV programme while watching it
Select a PAY-TV programme using PROG +/- on the flap of the remote control.

To watch a normal TV programme while recording a PAY-TV programme
Press TV/VTR so that "VTR" goes off, then select a normal television programme you want to watch on the TV.

To watch a PAY-TV programme while recording a normal television programme
Press TV/VTR to turn off "VTR", then select a PAY-TV programme you want to watch on the TV.

The following table will show you which indicators are lit during the watching and recording of a PAY-TV programme.

VTR indicator	To watch	To record
Lit	PAY-TV programme	PAY-TV programme
Unlit	Normal television	PAY-TV programme
Unlit	PAY-TV programme	Normal television

Recording a PAY-TV programme using the timer-activated recording function

Select a PAY-TV programme in step 6 of "Setting the Timer" on page 22. The other steps are the same as the normal timer-activated recording. The PAY-TV decoder must be kept turned on.

Watching a PAY-TV programme with the VCR turned off


Select a PAY-TV programme you want to watch on the TV.

Subtitle superimposing

Put the subtitle ON/OFF switch of the decoder to ON. Note that you cannot record the subtitle on the VCR.

Notes


- If the VCR records a PAY-TV programme which has been preset in the VCR's memory, this PAY-TV programme is not decoded on your TV even if you tune in this programme on your TV.
- You cannot use the subtitle superimposing function unless the 21-pin EURO-AV cables which are compatible with the RGB signals, are used for both the decoder-VCR and VCR-TV connections.



Temporarily using the EURO-AV (LINE 3) PAY-TV DECODER Connector as LINE 3 Input Terminal

Once you have done PAY-TV presetting, the upper EURO-AV connector on the rear of the VCR becomes the connector exclusively for a PAY-TV decoder. If you want to temporarily use this connector as a LINE 3 input connector for dubbing the tape, do the following.

- Turn on the VCR and TV.
- Press TV/VTR on the remote control several times until "VTR" appears in the VCR display panel.
- Press MENU.
The main MENU appears.
- Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "MODE SET."
- Press EXE.
The MODE SET menu appears.
If the MODE SET [PAGE 1] menu is displayed on your TV screen, press ▲ or ▼ of the cursor keys to move the cursor (▶) to "NEXT PAGE", then press EXE.
The MODE SET [PAGE 2] menu appears.
- Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "EURO AV."
- Select "L3" using ◀ or ▶ of the cursor keys.
- Press EXE.



Now you can use the upper EURO-AV connector as LINE 3 input terminal (if you connect a PAY-TV decoder to this connector, a PAY-TV programme is not decoded.)

To use the upper EURO-AV connector exclusively for the PAY-TV decoder again, perform steps 1 to 6, select "PAY-TV," then press EXE. You don't need to preset PAY-TV programmes again to watch and record. The programmes you have preset in the VCR's memory as PAY-TV programmes will still be effective.

Line-through

With the line-through function, you can watch a picture coming from a source connected to your VCR through the EURO-AV (LINE 3) connector even though your VCR is turned off.

For this function to work, you need the following conditions:




- The source equipment should be connected to the VCR's upper 21-pin EURO-AV (LINE 3) connector with a 21-pin EURO-AV cable.
- The source equipment needs to have a TV/VTR, TV/DISC, TV/SAT or equivalent selector switch, which you set to the non-TV position. (The VTR indicator should not be lit in the VCR display panel.)
- The VCR's lower EURO-AV (LINE 1) connector and your TV are connected with a 21-pin EURO-AV cable.

To watch a TV programme rather than the picture from the source connected to the VCR, simply set the TV/VTR switch of the connected equipment (which may be called TV/DISC, TV/SAT, or an equivalent) to the "TV" position.

Notes

- Depending on the equipment you connect to the EURO-AV (LINE 3) connector, the selector equivalent to the TV/VTR switching selector is not always set to the "TV" position. In this case you always have the output of this equipment on the TV. When you don't need to watch, turn off the power of this equipment.
- The line-through function does not support the RGB signals. Accordingly, if the connected equipment outputs superimpose signals, you can't watch them.

Variable Speed Playback



Note
During variable speed playback, "streaks" or "snow" may appear on the picture, the picture may flicker and the colour may not be reproduced properly depending on the speed or the direction.

The following section explains the advanced playback functions available on your VCR. No sound is heard during these operations.

Replay

During playback and playback pause, press **REPLAY**. The VCR replays in slow-motion the last two seconds of the scene just played back. After replay is over, the VCR resumes normal playback (or playback pause).
If you continue to press **REPLAY**, the tape will rewind as long as the button is held down. However, slow playback continues for about more than one minute, the VCR resumes normal playback automatically.

Still Picture

During playback, press **II PAUSE** to hold the picture in one place.

To resume normal playback, press either **▶ PLAY** or **II PAUSE**.

If you leave your VCR in pause mode, normal playback resumes after approximately 5 minutes.

To reduce the bands on the top or bottom of the screen in still mode Change to the slow motion play mode and adjust the picture with **TRACKING NORMAL/SLOW (STILL ADJUST) ▼/▲**.
To reduce the picture shaking during still mode Adjust the picture with **TRACKING NORMAL/SLOW (STILL ADJUST) ▼/▲**.

Picture Search (During Playback)

Press **▶▶ FF** or **◀◀ REW** during playback.

When you release the button, normal playback will resume.

Locked Picture Search

This feature works only from the remote control.

Press **SEARCH** on the remote control in the playback mode. For the reverse direction, press the left **SEARCH** button. For the forward direction, press the right **SEARCH** button.

To resume normal playback, press **▶ PLAY**.

Frame-by-Frame Picture

This feature works only from the remote control.



During playback pause, press **III** on the remote control to advance the picture one frame or **III** to go back one frame.

To resume normal playback, press **▶ PLAY**.

Reversing the Normal Playback

This feature works only from the remote control.

Press **◀◀** during normal playback.



Note
It takes about two or three seconds to reverse the direction in slow motion playback or frame-by-frame picture.

Slow Motion Playback

This feature works only from the remote control.

Press **▶ SLOW +/-** to start slow motion playback during playback.

You can change the playback speed of slow motion playback from 1/5 to 1/30 times the normal speed.
Press **▶ SLOW +** to increase the playback speed.
Press **▶ SLOW -** to decrease the playback speed.

To resume normal playback, press **▶ PLAY**.

To play back in the reverse direction Press **◀◀** (<).

To resume normal playback, press **▶ PLAY**.

To reduce streaks or "snow" during slow motion playback Adjust the picture with **TRACKING NORMAL/SLOW (STILL ADJUST) ▼/▲** on the inside surface of the upper drop-down panel of the VCR.

X2 Double Speed Playback

This feature works only from the remote control.

Press **X2** on the remote control.

To playback in the reverse direction Press **◀◀** (<).

To resume normal playback, press **▶ PLAY**.

JOG/SHUTTLE Operation

Using the **JOG** dial and **SHUTTLE** ring on the VCR or the remote control during playback or playback pause, you can play back cassettes at a variety of speeds, in either forward or reverse direction.


Using the SHUTTLE ring

- 1* Press the **JOG/SHUTTLE** function button. The indicator beside the button lights up.
- 2 Turn the ring and hold it. Playback speed is selected according to the turning angle as illustrated. The same speeds are available in the reverse direction.

Using the JOG dial

- 1* Press **JOG/SHUTTLE** function button. The indicator beside the button lights up.
- 2 Turn the dial. Playback speed varies according to the speed at which you turn the dial (frame-by-frame, slow, x1). The same speeds are available in the reverse direction.


SHUTTLE



- 1/5 (Slow motion playback)
- 1 (Normal playback)
- 2 (Double speed playback)
- SEARCH (Picture search)

remote control only

JOG



Releasing **JOG/SHUTTLE** produces a still picture. To resume normal playback, press **▶ PLAY**.

Watching Multiple Picture


Using the digital memory built in this VCR, you can enjoy a couple of digital operations.

Using P in P (Picture in Picture)


If you want to insert a small picture, press P in P. The subsidiary picture selected using INPUT SELECT will appear on the TV screen.



To change the position of the subsidiary picture
Press SHIFT repeatedly until the desired position is reached.



To swap pictures
Press P in P again. The sound is also switched.




To turn off the subsidiary picture
Press DIGITAL OFF.


Using TV Scan

You can watch all preset TV programmes in succession while you are watching a TV programme or during playback.

During watching a TV programme
Press TV SCAN. After all preset programmes are scanned, the first programme will appear again.




During playback
Press TV SCAN. Each preset programme will be displayed on the subsidiary screen for a few seconds in order of programme position numbers. After all the preset programmes are scanned, the first programme will appear.



To stop scanning at the programme position you want to watch
Select the programme position you want to watch using the programme position number buttons on the remote control. Or you can use PROG +/- on the remote control or PROGRAM +/- on the VCR or you can press the PROG function button so that the indicator beside the button lights up and turn the JOG dial on the remote control.

To turn off the subsidiary picture
Press DIGITAL OFF.



Notes on the PAY-TV programmes (SLV-825VC models only)

- If the PAY-TV programme is not preset on the VCR, the PAY-TV programme will not appear either on the main screen or the subsidiary screen.
 - If you have made VCR-TV connection using the EURO-AV connection, the decoded picture of the PAY-TV programme will appear either on the main screen or on the subsidiary screen, and not appear on both screens at the same time. When you select TUNER or SIMUL using INPUT SELECT, the picture of the PAY-TV programme will appear as follows:
 - When the PAY-TV programme is preset to ON, it will appear only on the main screen.
 - When the PAY-TV programme is not preset (PAY-TV setting is OFF), it will appear only on the subsidiary screen.
- When you select LINE L1, L2 or L3, however, the PAY-TV programme will not appear on the main screen.


Using TV in TV

If you want to watch two TV programmes at the same time, you can tune one with the TV and the other with the VCR. Using the P in P function one will appear in the subsidiary screen, and one will appear on the main screen. The TV and the VCR must be connected with the EURO-AV cable.

- Press INPUT SELECT to display "TUNER" in the VCR display panel.
- Press TV/VTR to turn on the VTR indicator. The programme selected on the VCR appears on the screen.
- Press P in P. The programme selected on the TV appears on the subsidiary screen.

To change the position of the subsidiary picture
Press SHIFT repeatedly until the desired position is reached.

To turn off the subsidiary picture
Press DIGITAL OFF.




How to select the main picture and the subsidiary picture

If you press INPUT SELECT, the picture on the main screen and the subsidiary screen changes as follows. The audible sound is determined according to the input mode selected with INPUT SELECT.

INPUT SELECT position	Main picture	Subsidiary picture
TUNER	The programme selected on the VCR	TV programme selected on the TV
SIMUL	TV programme selected on the VCR	TV programme selected on the TV
LINE L1	TV programme selected on the TV	TV programme selected on the VCR
LINE L2	Picture of the equipment connected to LINE IN 2 VIDEO	TV programme selected on the VCR
LINE L3	Picture of the equipment connected to LINE 3 (EURO-AV)	TV programme selected on the VCR

- Notes**
- You cannot change the programme position of the VCR if it appears on the subsidiary screen.
 - If you have preset "PAY-TV" to "ON" in the TUNER PRESET menu, you can't select "LINE 3."
- The input mode indicator changes cyclically as follows.



Using the On-Screen Menus

When you make a specific setting or select a series of tape operations while using your VCR, you sometimes need to open the MENU screen. The following table shows you when and why you need to select the menu options.


AUTO MENU	Select this item to perform certain operations in sequence. See page 37 for details.
AUTO REPEAT	Select this item to repeat certain portions of a tape. See page 39.
MODE SET	Select this item to customize your VCR. See page 40.
TUNER PRESET	See page 9.
LANGUAGE	Select this item to display the menu in your language (ENGLISH, DEUTSCH, FRANÇAIS, ITALIANO, ESPAÑOL, NEDERLANDS) . See page 12.
FUNCTION MEMORY	Select this item to keep a certain operation in memory. See page 38.
DEMONSTRATION	Select this item to get an overview of the on-screen menus. While the VCR is showing a sequence of the DEMONSTRATION menu, you can stop at the desired screen by pressing EXE. Press EXE again to start again. To quit the demonstration, press any button except for EXE.

Before you begin

- Use ▲ or ▼ to move the cursor (▶).
- Use ◀ or ▶ to select items.
- To quit setting in the middle of the procedure, press MENU.

Assigning a Desired Operation-AUTO MENU/ FUNCTION MEMORY

You can get the VCR to perform certain functions in sequence automatically. The AUTO MENU guides you to your desired sequence of operations. You can choose from the eight AUTO MENU choices. Moreover, one of the AUTO MENU choices you selected can be assigned to the FUNCTION MEMORY button on the remote control.



Note on AUTO MENU operation

AUTO MENU cannot be operated if there is no cassette installed or if the tape is being transported. A short beep alerts you if the AUTO MENU is not operable.



Note on "GO TO REC START-PLAY"

The recording start point data will be erased from the memory after the following operations, and "GO TO REC START-PLAY" will not be operable.

- When COUNTER RESET is pressed.
- When cassette is ejected and re-inserted.
- When HI-SPEED REWIND is pressed.


AUTO MENU Setting

- 1 Press MENU.
The main MENU appears.
- 2 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to AUTO MENU.
- 3 Press EXE.
The display changes to the "AUTO MENU" display.
- 4 Press ▲ or ▼ of the cursor keys to select the menu choice you want. For menu choices, see below.
- 5 Press EXE to return to the original screen.
The selected operation will begin. The menu choice you selected will be superimposed on the TV screen for a few seconds.
The AUTO indicator will light up in the VCR display panel during AUTO MENU operation.




Menu choices

- **PLAY-REW-POWER OFF**
Plays back the tape, rewinds the tape when it reaches the end, and turns off the power.
- **GO TO ZERO-STOP**
Searches for the counter zero point and stops.
- **GO TO ZERO-PLAY**
Searches for the counter zero point and starts playback.
- **GO TO REC START -PLAY**
Searches for the recording start point and starts playback.
- **REW-POWER OFF**
Rewinds the tape to the beginning and turns off the power.
- **REW-EJECT-POWER OFF**
Rewinds the tape to the beginning, ejects the cassette, and turns off the power.
- **REW-PLAY**
Rewinds the tape to the beginning and starts playback.
- **REW-TIMER REC**
Rewinds the tape to the beginning and puts the VCR in timer recording standby mode when the timer is preset.




FUNCTION MEMORY

- 1 Press MENU.
The main MENU appears.
- 2 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to FUNCTION MEMORY.
- 3 Press EXE.
The FUNCTION MEMORY menu appears.
- 4 Move the cursor (▶) to the menu choice you want and press EXE.



If you have selected [AUTO MENU], you can directly go to the AUTO MENU simply by pressing FUNCTION MEMORY, without displaying the main MENU. This is a short cut to the AUTO MENU.

For the menu choices, see the previous page.
The menu choice you selected will be activated every time you press FUNCTION MEMORY when the VCR is in stop mode.



Repeating Playback Automatically —AUTO REPEAT

You can make the VCR repeat playback of a certain portion of the tape automatically.

- 1 Press MENU while the VCR is in the stop mode.
The main MENU appears.
- 2 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to AUTO REPEAT and press EXE.
The AUTO REPEAT menu appears.
- 3 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to the menu choice you want and press EXE.
The VCR will rewind or advance the tape rapidly to the start point of the selected repeat portion and start playback. Playback of that portion will be repeated five times and then the VCR will rewind the tape to the start point. The AUTO indicator will light in the VCR display panel during AUTO REPEAT operation.



To stop playback

Press ■ STOP on the VCR or on the remote control.

Menu choices

- TAPE START-TAPE END
Repeats playback from the beginning to the end of the tape.
- TAPE START-VIDEO END
Repeats playback from the beginning of the tape to the end of the recorded portion.
- TAPE START-COUNTER 0*
Repeats playback from the beginning of the tape to the counter zero point.
- COUNTER 0*-TAPE END
Repeats playback from the counter zero point to the end of the tape.
- COUNTER 0*-VIDEO END
Repeats playback from the counter zero point to the end of the record portion of the tape.

- Before activating AUTO REPEAT, you must press COUNTER RESET on the VCR or on the remote control to set the tape counter to 0H00M00S at the desired point.

Notes on AUTO REPEAT operation

- If you press any tape operation button during repeat playback, AUTO REPEAT will be released.
- AUTO REPEAT cannot be operated if there is no cassette installed or if the VCR is in modes other than stop mode. A short beep alerts you if the AUTO REPEAT is not operable.


Note on "VIDEO END"

The VCR normally detects a blank of about 10 seconds on the tape as "VIDEO END."

However, for about 30 seconds from the beginning of the tape, the VCR does not do this.

AUTO REPEAT will not work correctly in the following cases


- When there is a blank of more than 10 seconds in the assigned repeat portion (more than 40 seconds at the beginning).
- When there is a blank of less than 10 seconds after the recorded portion to be played back repeatedly.
- When the tape is recorded to its end. (Select the menu choice including "TAPE END.")




Customizing Your VCR—MODE SET

You can customize your VCR using the MODE SET menu.

- 1 Press MENU.
The main MENU appears.
- 2 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to MODE SET.
- 3 Press EXE.
The MODE SET menu appears.
If the MODE SET [PAGE 1] menu is displayed on your TV screen, press ▲ or ▼ of the cursor keys to move the cursor (▶) to "NEXT PAGE", then press EXE.
The MODE SET [PAGE 2] menu appears.



[PAGE 1] menu



[PAGE 2] menu

- 4 Press ▲ or ▼ of the cursor keys to move the cursor to the menu choice you want, then press ◀ or ▶ of the cursor keys to move the dot (•) to select the item.
For the menu choices, see below.
- 5 Press EXE to store the setting.

Menu choices


- **CLOCK DISPLAY**
Select "ON" to display the current date and time in the data screen, and select "OFF" to turn off the current date and time in the data screen.
- **DIMMER**
Select "ON" to make the display window dimmer and select "OFF" to make the display window brighter.
- **SIMUL AUDIO IN**
Select "L1" to select the audio source from the LINE IN 1 connector during simul recording and select "L2" to select the audio source from the LINE IN 2 jacks during simul recording.
- **RF MODULATOR**
Select "ON" if you have made the VCR-TV connection via the aerial socket only.
Select "OFF" if you have made the VCR-TV connection via the EURO-AV connector.
If interference occurs when you use the aerial socket, make the EURO-AV connection and set the RF MODULATOR to "OFF."

Important
Do not set RF MODULATOR to "OFF" when you have made the VCR-TV connection via the AERIAL IN socket only.
If the RF MODULATOR is set to "OFF", no picture will appear on the TV screen. In this case, press the CL button inside the lower drop-down panel with a pointed object. Since this will clear all stored information (e.g., the clock and any preset information), you must set them once again.

Note
The position of the cursor remains the same as long as the mains lead is connected.

- **BACK COLOUR**
Select the background colour you want : BL (blue), GR (green) or PK (pink).
- **TIMER REC-REW**
Select "ON" to automatically rewind the tape after timer recording is over and select "OFF" to cancel this setting.
- **AUDIO MIX**
Select "ON" to make the AUDIO MONITOR button inoperative so that the sounds of the hi-fi video and normal audio tracks are always output and select "OFF" to make the AUDIO MONITOR button operative so that you can select the sound to hear (for details, see page 47).
- **LANC MODE**
Select "M" to control the other VCR using the synchronized editing function of this VCR and select "S" in any other cases (for details, see page 58).
- **SHUTTLE MODE**
Normally set to "AUTO." The VCR detects automatically whether the other VCR has a reverse slow-motion playback function or not. If the other VCR doesn't perform tape movement as you operated, select "A."
When you select "A", the tape will come to move only in the forward direction, and the JOG dial doesn't work (for details, see page 58).
- **HI-FI AUDIO (SLV-825UB and SLV-825NC models only)**
Select "NICAM" to record a NICAM broadcast on a Hi-Fi audio track and select "STD" to record only standard sound on a Hi-Fi audio track (for details see page 46).
- **EURO AV (SLV-825VC models only)**
Select "PAY-TV" to use the EURO-AV (LINE 3) PAY-TV DECODER connector to connect a PAY-TV decoder only after the PAY-TV presetting has been done. Select "L3" to use this connector as a LINE 3 connector temporarily (for details, see page 31).

Index Function



You can find specific scenes easily using the markings (index points) recorded on a cassette. This function is called the Index Function. You can mark an index anywhere on a tape, so that you can easily find the specific point later on. Index works as a divider between scenes, and is not numbered. So, when you specify the index mark later, you have to specify the relative position from the current position. (The first index, the second index....from the current position.) You can mark and erase index signals during playback, but while recording, you cannot erase them.

Marking Index Signals

Where you mark an index, the INDEX indicator flashes in the VCR display panel and the INDEX MARK indicator appears on your TV screen.

Automatic Index Mark

An index signal is automatically recorded at the beginning of a scene when you start recording.


Manual Index Mark

When recording or playing a cassette, you can manually mark an index signal by pressing INDEX MARK.

When you mark an index signal during playback, the recorded sound may be interrupted but the audio signal will not be erased.

Notes on marking indexes



- Leave an interval of at least 2 minutes between indexes so that the VCR can detect the signals correctly.
- You cannot mark an index signal in the following cases:
 - On a cassette whose safety tab has been removed
 - On an unrecorded portion of a tape
 - Immediately before a point on the cassette where the tape speed (SP or LP) changes.



Playing Back from the Index Point—Index Scan

Here's how to find and play a programme you've marked with an index signal.


- 1 Insert an indexed cassette into your VCR
- 2 Press DATA SCREEN to display the data screen.
- 3 Press INDEX once. The INDEX and SCAN indicators flash alternately in the VCR display panel and the INDEX SCAN indicator appears on the TV screen.
- 4 Press ◀◀ to find the previous programme or ▶▶ to find the next programme. The index scan locates the next index signal and plays about 10 seconds of tape prior to the signal (10-second preview). The VCR then rewinds or advances to the next index signal. Every time the VCR finds an index signal, 10-second preview begins.



- 5 When you find the programme you want, press ▶ PLAY during the 10-second preview. Playback starts from that point.

To stop index scan underway



Press ▶ PLAY or ■ STOP.



Locating an index— Index Search

Locate an index by indicating how many index signals ahead or behind the scene is from the tape's current position. You can specify up to the 19th index point either ahead or behind the current position.

- 1 Press DATA SCREEN to display the data screen.
- 2 Press INDEX until the index number you want appears.



- 3 Press ►► FF to find an upcoming index signal or ◀◀ REW to find a prior index signal.
The cassette advances or rewinds to find the signal.
Each time an index signal is detected, the index number decreases.
When the index number reaches 0, it means you've located the specified scene and your VCR will begin to play.

Erasing Index Signals

To remove any unwanted index signals, follow these steps:

- 1 Press INDEX once during playback or stop mode.
- 2 Press ►► FF to find the next scene or ◀◀ REW to find the previous scene. Each time an index is detected, the VCR plays back the indexed scene for approximately 10 seconds. It then rewinds or advances to the next index signal. This 10 second preview lets you decide whether you've located the index mark you want to erase.
- 3 Press INDEX ERASE during 10 seconds preview.
"INDEX ERASE" is displayed on the TV screen. The VCR automatically rewinds the tape to a position before that index, and erase the index. After one index is erased, the next index is located.

Note
You cannot erase an index signal at the beginning of the tape.


Recording Stereo/Bilingual Programmes



SLV-825/825VC/825NC Models

The SLV-825/825VC/825NC can receive and record stereo/bilingual programmes based on the "Zweiton" system adopted in Germany. Recording of the Zweiton system programmes is automatically done. A stereo or bilingual programme is recorded on the Hi-Fi audio track and normal audio track as shown below.

Hi-Fi recording pattern on a tape



Where the sound is recorded

Stereo programme

When a stereo programme is received, "STEREO" appears in the VCR display panel and the sound is recorded as follows:

- Left channel: on the left channel of the Hi-Fi audio track
- Right channel: on the right channel of the Hi-Fi audio track
- Mixed of the left and right channels (monaural): on the normal audio track

Bilingual programme

When a bilingual programme is received, "MAIN/L" appears in the VCR display panel and the sound is recorded as follows.

- Main: on the left channel of the Hi-Fi audio track and on the normal audio track
- Sub: on the right channel of the Hi-Fi audio track

How to select the sound you hear

Stereo programme


The AUDIO MONITOR button does not function for the stereo programmes of the Zweiton system.

Bilingual programme

When the VCR receives a bilingual programme, "MAIN/L" appears in the VCR display panel and you can select the sound to hear.

Press AUDIO MONITOR several times until you can hear the sound you want. With each press, the sound is cyclically changed in the following order.

Display	Sound heard
MAIN/L	Main sound
SUB/R	Sub sound
MAIN/L SUB/R	Main sound on the left channel Sub sound on the right channel




SLV-825UB/825NC Models

The SLV-825UB/825NC can receive and record stereo/bilingual programmes based on the "NICAM" system adopted in the United Kingdom and Nordic countries. NICAM broadcasting has two-channel digital sound called NICAM L and R channels in addition to the standard sound. The NICAM L and R are assigned to the stereo left and right channels or the main and sub sounds of a bilingual programme. The standard sound of most NICAM broadcasts is the mixed sound of the left and right channels for a stereo programme, and the main sound for a bilingual programme.

Recording NICAM broadcasts

You need to select "NICAM" of "HI-FI AUDIO" in the MODE SET [PAGE 2] menu.

- 1 Before recording a NICAM broadcast, press MENU. The main MENU appears.
- 2 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to MODE SET.
- 3 Press EXE. The MODE SET menu appears. If the MODE SET [PAGE 1] menu is displayed on your TV screen, press ▲ or ▼ of the cursor keys to move the cursor (▶) to "NEXT PAGE", then press EXE.
- 4 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to HI-FI AUDIO.
- 5 Select NICAM using ◀ or ▶ of the cursor keys.
- 6 Press EXE to store the setting.





With NICAM setting, NICAM broadcasts will be recorded as shown in the following table.

Track	Sound heard	
	Stereo	Bilingual
Hi-Fi audio left channel	Left channel	Main
Hi-Fi audio right channel	Right channel	Sub
Normal audio	Standard	Standard

Note
When there is no NICAM broadcast, the standard sound will be recorded on both the Hi-Fi video track and the normal audio track.

To record the standard sound only

Follow the operation above and set HI-FI AUDIO to STD in step 5. The standard sound will be recorded on the left and right channels of the Hi-Fi video track and the normal audio track.



How to select the sound you hear

Stereo programme

When a stereo programme is received, "STEREO" and "NICAM" appears in the VCR display panel and you can select the sound to hear.

Press AUDIO MONITOR.

With each press, the STEREO (NICAM L and R channels) or the standard sound is selected alternately.

Display panel	Sound heard
STEREO	Left channel sound on the left channel and right channel sound on the right channel.
No indication	Standard sound


Bilingual programme

When a bilingual programme is received, "NICAM" and "MAIN/L" appears in the VCR display panel and you can select the sound to hear.

Press AUDIO MONITOR several times until you can hear the sound you want. With each press, the sound is cyclically changed in the following order.

Display panel	Sound heard
MAIN/L	Main sound
SUB/R	Sub sound
MAIN/L, SUB/R	Main sound on the left channel and sub sound on the right channel
No indication	Standard sound

Audio Recording



The Hi-Fi recording system of this VCR allows recording of high quality stereo sound from an FM tuner, audio system, or other audio equipment.

Before you begin

- Connect your audio system to the LINE IN 2 AUDIO jacks using the RK-C510KS audio connecting cable (not supplied).
- Set INPUT SELECT to LINE L2.
- Select REC MODE, SP or LP.

Adjusting the Audio Recording Level

Play the recording source. While observing the PEAK PROGRAM METER on the VCR, adjust the REC LEVEL controls as follows.

When recording from records: Adjust the level so that the right-most element (+10) lights up sometimes.

When recording from CDs or using a PCM processor: Adjust the level so that the right most element (+10) lights up only when the signal is input at its maximum level.


Recording

The recording procedure is the same as "Recording While Watching the TV Programme" on page 20.

PCM Recording and Playback

You can perform PCM recording and playback on the video track by connecting a PCM digital audio processor to the LINE IN and OUT VIDEO jacks on this VCR. For details, refer to the instruction manual of the PCM digital audio processor.

Caution
To avoid damaging the speakers due to a wide dynamic range of a Hi-Fi recorded tape/disc, turn down the volume of the TV before playing back a Hi-Fi recorded tape/disc.



Simulcast Recording

You can record a TV programme and the sound from other equipment such as an FM tuner, simultaneously. The audio signals from the TV receiver are recorded on the normal audio track and those from the connected equipment on the Hi-Fi track.

Before you begin


- Connect your audio equipment to the EURO-AV (LINE 1) connector or the LINE IN 2 AUDIO jacks. The EURO-AV (LINE 3) (EURO-AV (LINE 3) PAY-TV DECODER for the SLV-825VC Model) connector cannot be used for a simulcast.
- Press INPUT SELECT on this VCR to indicate "SIMUL" in the VCR display panel.
- Other settings are the same as "Audio Recording" on the previous page.

Selecting the audio input


- 1 Press MENU.
The main MENU appears.
- 2 Press ▲ or ▼ of the cursor keys to move the cursor (▸) to MODE SET.
- 3 Press EXE.
The MODE SET menu appears.
If the MODE SET (PAGE 2) menu is displayed on your TV screen, press ▲ or ▼ of the cursor keys to move the cursor (▸) to "PREVIOUS PAGE", then press EXE.
The MODE SET (PAGE 1) menu appears.
- 4 Press ▲ or ▼ of the cursor keys to move the cursor (▸) to SIMUL AUDIO IN.
- 5 Move the dot using ◀ or ▶ of the cursor keys to L1 or L2 whichever your audio equipment is connected to.
Select L1 when your audio equipment is connected to the EURO-AV (LINE 1) connector, and select L2 when your audio equipment is connected to the LINE IN 2 AUDIO jacks.
- 6 Press EXE to store the setting and return to the original screen.

Recording

The recording procedure is the same as "Recording While Watching the TV Programme" on page 20.




Cutting out the Unwanted Scenes— SHUTTLE EDIT



During Recording




If you wish to cut out scenes such as TV commercials, you can pause recording and play back the tape in the reverse direction until the beginning of an unwanted scene is reached. Then, record over it. This feature only works from the VCR.
During timer-activated recording, you cannot use this function.
The VCR enters the P in P mode so that you can check the pictures to be edited on the screen.

- 1 Press **II PAUSE** during recording. The VCR enters recording pause mode.
- 2 Turn the JOG dial and the SHUTTLE ring on the VCR counterclockwise to rewind the tape until the unwanted scene appears. The VCR will enter P in P mode and the playback picture will appear on the subsidiary screen.



If you turn the JOG dial, you can select the playback speed by how fast you turn it, and if you turn the SHUTTLE ring, you can select the playback speed by how far you turn it.
When you release the dial or ring, the VCR enters recording pause mode and the subsidiary screen disappears from the TV screen.

- 3 Press **II PAUSE** when a wanted scene appears on the screen. Recording starts.



During Playback

You can re-record onto an unwanted portion of a pre-recorded cassette. Use the JOG dial and the SHUTTLE ring on the VCR or on the remote control.

- 1 Press **II PAUSE** at the end of the unwanted scene during playback. The VCR enters playback pause mode.
- 2 Turn the dial or ring until the beginning of the unwanted scene appears on the screen. If you turn the JOG dial, you can select the playback speed by how fast you turn it, and if you turn the SHUTTLE ring, you can select the playback speed by how far you turn it. When you release the ring, the VCR enters playback pause mode. You can also use the SHUTTLE EDIT buttons on the remote control to find the scene.
- 3 Press **● REC** on the VCR or **● RECS** on the remote control. The VCR enters recording pause mode.
- 4 Select a new programme for re-recording. Press **PROG +/-** on the flap of the remote control or **PROGRAM +/-** on the inside surface of the upper drop-down panel of the VCR to select the programme position. You can also use the jog dial to select the programme position. To use this, press the **PROG** function button to light the indicator beside the button. Turn the jog dial clockwise for higher numbered programme positions or counterclockwise for lower numbered programme positions. The programme number will change in the VCR display panel and on the TV screen.
- 5 Press **II PAUSE** when the scene to be recorded begins to appear on the screen. Recording begins.


To stop recording, press **■ STOP**.

Note
The picture may be distorted a moment at the cut-out point (recording end point).


Overview of the Editing Functions

Using a second VCR, you can record programmes from one VCR to the other. The following are the tape editing functions available on the VCR. You can perform these editings using the synchronized editing function or manually (not using the synchronized editing). In this section, the editing using the synchronized editing function will be mainly explained.


- To make a copy of a tape.
— See "Tape Dubbing" on page 53.



- To edit out unwanted scenes using the synchronized editing function (Synchronized Assemble Editing)
You can use the synchronized editing function to perform assemble editing and insert editing if your other VCR has a control L connector. Using this function controls both the playback VCR and the recording VCR simultaneously.
— See "Synchronized Editing" on page 56.



- To insert a new picture and/or sound onto a previously recorded tape
— See "Insert Editing" on page 61.




Tape Dubbing

Editing from the Other VCR


Here's how to edit from the other VCR (such as an 8mm video camera recorder or a VHS-format VCR for playback) when using this VCR for recording. You can use the video/audio jacks on the front panel, or the 21-pin EURO-AV connector on the rear panel to perform this operation.

Connections


When using the 21-pin EURO-AV connector



When using the front panel video/audio jacks



- Notes
- If the other VCR is a monaural type, connect the white plug to LINE IN 2 AUDIO L and leave the red plug unconnected. This enables the sound to be separated into the right and left channels. If the other VCR is a stereo type, make connections with both the red and white plugs.
 - Press INPUT SELECT on this VCR to indicate LINE L1, LINE L2 or LINE L3 in the VCR display panel to match the jack to which you have connected the other VCR.




Before you begin

- Select the tape speed (SP or LP) with REC MODE.
- Press the INPUT SELECT button to select LINE IN 1 or LINE IN 2. (When connected to the rear panel, select LINE IN 1. When connected to the front panel, select LINE IN 2).
- L1 or L2 appears in the VCR display panel.
- If your playback VCR has an editing function, select it to reduce static and improve reception.
- Adjust the REC LEVEL control (see "Audio Recording" on page 48).

Operation

- 1 Insert a blank cassette into this VCR (recorder).
- 2 Turn on the other VCR (player) and insert a source cassette.
- 3 Locate the playback starting point and select the playback pause mode on the other VCR (player).
- 4 Locate the recording starting point and select the recording pause mode on this VCR (recorder).
- 5 Press **II** PAUSE on both VCRs.
For best result, press **II** PAUSE on the other VCR (player) just before pressing **II** PAUSE on this VCR (recorder).
When you've finished editing, press **■** STOP on both VCRs.




Notes

- If your recording VCR is a monaural type, make connections using the VCM-910MS/920MS cable (not supplied).
- When connecting the VCRs, do not connect both LINE IN and LINE OUT jacks on your VCR simultaneously. Doing so may cause a humming noise.

Editing onto the Other VCR

Here's how to use this VCR as the playback VCR and the other VCR as the recording VCR.

Connections



Before you begin

- Press the EDIT button so that the EDIT indicator lights up in the VCR display panel. If your recording VCR has an editing function, it should also be selected to improve reception.
- Press AUDIO MONITOR on the remote control to select the sound to be recorded.

Operation


- 1 Turn on the other VCR (recorder) and insert a blank cassette.
- 2 Insert a source cassette into this VCR (player).
- 3 Locate the playback start point and select the playback pause mode on this VCR (player).
- 4 Locate the recording start point and select the recording pause mode on the other VCR (recorder).
- 5 Press **II** PAUSE on both VCRs.
For best results, press **II** PAUSE on this VCR (player) just before pressing **II** PAUSE on the other VCR (recorder).
When you've finished editing, press **■** STOP on both VCRs.

Synchronized Editing

If your other VCR has a control L connector, and/or CONTROL S IN connector, you can take advantage of a feature called "Synchronized Editing" that controls both VCRs (recording VCR and playback VCR), and releases the pause when the SYNCHRO EDIT button is pressed. To use this function, you must connect the control cable in addition to the connections of the audio and video cables. There are two types of control cables: control L (LANC or REMOTE) cable or control S cable. Which cable you need to use depends on the connectors that your other VCR has.

Connecting Video Equipment with the LANC connector

When using the front panel jacks



Notes

- When connecting the VCRs, do not connect both LINE IN and LINE OUT jacks on your VCRs simultaneously. Doing so may cause a humming noise.
- When the REMOTE connector of the other VCR is a stereo mini-mini plug, use the VK-820 control L cable (not supplied). If it is a 5-pin DIN connector, use the VK-810 control L cable (not supplied).
- If your playback VCR is a monaural type, connect the white plug to LINE IN 2 AUDIO L on this VCR. This lets you record the sound of the playback VCR on both channels of this VCR.
- If another VCR has both the LANC connector and the CONTROL S connector, use the LANC connector. Do not make the LANC and CONTROL S connections simultaneously.


Important

After you have made the connections, make sure you set the LANC mode (see page 58).

About the Ⓛ (LANC)

LANC stands for Local Application Control System. The LANC connector is used for controlling the tape transport of video equipment and peripherals connected to it. This connector has the same function as the connectors indicated as CONTROL L or REMOTE.

Connecting Video Equipment with the CONTROL S connector



When using the CONTROL S cable


Set the commander mode of this VCR and the other video equipment to the same position.

If the other video equipment has the synchronized function, use the SYNCHRO EDIT button on other equipment.

Comparing to the synchronized editing using the LANC connector, the synchronized editing using the CONTROL S connector only enables you to pause both VCRs and release the pause mode of both VCRs.

Note


When connecting the other VCR to LINE IN 2 on the front, use the supplied video/audio connecting cable. If the other VCR is a monaural type, connect to LINE IN 2 AUDIO L using the white plugs. This enables the sound to be separated into the right and left channels. Leave the red plugs unconnected.



Setting the LANC MODE and SHUTTLE MODE

After you have made the control L cable connection on page 56, you must choose the LANC MODE and SHUTTLE MODE setting. The LANC MODE setting decides which VCR controls which. Use the MODE SET [PAGE 2] for this setting. Here's how to do this setting.

- 1 Press MENU to display the main MENU.
- 2 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "MODE SET".
- 3 Press EXE.
The MODE SET menu appears.
If the MODE SET [PAGE 1] menu is displayed on your TV screen, press ▲ or ▼ of the cursor keys to move the cursor (▶) to "NEXT PAGE", then press EXE.
- 4 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "LANC MODE."
- 5 Select "M" or "S" using ◀ or ▶ of the cursor keys.
When you want to control the other VCR from this VCR, select "M."
When you want to control this VCR from the other VCR, select "S."
- 6 Press ▲ or ▼ of the cursor keys to move the cursor (▶) to "SHUTTLE MODE."
- 7 Select "AUTO" or "A" using ◀ or ▶ of the cursor keys.
Normally set to "AUTO." The VCR detects automatically whether the other VCR has a reverse slow-motion playback function or not. If the other VCR doesn't perform tape movement as you operated, select "A."
When you select "A", the tape will come to move only in the forward direction, and the JOG dial doesn't work (for details, see page 41).
- 8 Press EXE to store the setting.
The TV screen returns to the original screen.



Synchronized Assemble Editing


You can display both the picture of the playback VCR and recording VCR simultaneously on the TV screen. This allows you to perform editing while previewing editing scenes.

Before you begin



- Press the REC MODE button on the VCR or on the remote control to select the tape speed (SP or LP).
- Check the SHUTTLE MODE setting (see page 58).

- 1 Insert a recorded cassette into the other VCR and insert a cassette for recording into this VCR.



- 2 Press EDIT MONITOR.
The EDIT MONITOR screen appears on the TV screen.



- 3 Press EDIT STANDBY.
This VCR (recorder) will enter recording pause mode, the other VCR (player) enters playback pause mode. The EDIT STANDBY indicator on the front panel of this VCR lights up. The LINE IN 2 input is automatically selected. If other VCR (player) is connected to the rear panel, press the INPUT SELECT button to select LINE IN 1 or LINE 3. The LANC MODE setting is automatically set to "M."



- 4 Locate the starting point where you want to begin recording, using the JOG dial and the SHUTTLE ring.





(Continued)

Now you should determine the starting point where the player begins playback.



5 Press LANC REMOTE.

The LANC REMOTE indicator lights up and locate the playback starting point, using the JOG dial and the SHUTTLE ring.





6 Press SYNCHRO EDIT.

The SYNCHRO EDIT indicator lights up. The pause mode of the playback VCR and the recording VCR are released, and the recording starts.



7 Press SYNCHRO EDIT at the scene where you want to stop recording.

The playback VCR and recording VCR enter pause mode.



To edit another scene
Repeat steps 4 through 7.

To stop editing

Press EDIT STANDBY. Both the playback VCR and the recording VCR stop.

"Advanced Synchro Edit"


When you connect this VCR with a video camera recorder (camcorder) or another VCR which responds to the advanced synchro edit function (such as CCD-V800E, CCD-F550E, and CCD-TR805E, etc), you can take advantage of this precise editing function.

Convenient use of the LANC REMOTE button

If you connect your video camera recorder (camcorder) to your TV using an audio/video cable and to this VCR using the LANC cable, you can control the tape operation of your video camera recorder (camcorder) from this VCR.


If your video camera recorder (camcorder) has a reverse playback function such as -slow playback, -X2 speed playback and -X1 playback, you can control the reverse operation using the JOG dial and the SHUTTLE ring (for details, see page 41).

Insert Editing



Inserting a New Picture and/or Sound

You can easily insert a new picture and/or sound onto a pre-recorded tape. This editing is useful to replace an unnecessary scene (or sound) with another scene (or sound).





Before You Begin



- For connection, see page 56 or 57. (The CONTROL L or CONTROL S connection is not necessary).
- Select the insert source from the equipment connected to EURO-AV (LINE 1), LINE 2 and EURO-AV (LINE 3).

Operation

- 1 Insert a source tape into the playback VCR. Insert a tape for recording into this VCR.
- 2 Press EDIT ON/OFF. If the playback VCR is equipped with the EDIT switch, set it to ON.
- 3 Press EDIT MONITOR on the VCR or on the remote control.
- 4 On this VCR, locate the ending point and press COUNTER RESET. The counter will show "0H00M00S" and the ending point will be memorized.
- 5 On this VCR, locate the starting point and set the VCR to the playback pause mode. JOG/SHUTTLE or SHUTTLE EDIT are useful for this operation. When you use the JOG/SHUTTLE on the remote control, press the JOG/SHUTTLE button to light the indicator beside the button first.



(Continued)



Note
The MIC jack of this VCR is adaptable to the use of a monaural mini plug. If you connect a stereo microphone, the audio will be recorded in monaural.

6 Press AUDIO/VIDEO INSERT.

When the VIDEO INSERT button is pressed
The picture and the sound on the Hi-Fi audio track will be inserted. (The sound on the normal audio track will be retained.)

When the AUDIO INSERT button is pressed
The sound on the normal audio track will be inserted. (The picture and the sound on the Hi-Fi audio track will be retained.)

When the VIDEO and AUDIO INSERT buttons are pressed (AV INSERT)
The picture, sound on the Hi-Fi audio track, and the sound on the normal audio track will be inserted.

The indicator corresponding to the button pressed will light up.
At the ending point (0H00M00S), the insertion will stop automatically.

7 On the playback VCR, locate the starting point where you want to start the insertion and set the VCR to the playback pause mode.

8 Press PAUSE on both VCRs to start the insertion.
At the ending point (0H00M00S), the insertion will stop automatically.

To stop the Insertion temporarily
Press PAUSE.


To stop on-going insertion
Press STOP.

To turn off the EDIT MONITOR display
Press EDIT MONITOR.


When the sound from the microphone is inserted

When the microphone is connected to the MIC jack, the sound from the microphone is automatically selected and it is recorded on the normal track.

To record the sound from the microphone, select AUDIO or AV INSERT.




VCR Display Panel




REC	Recording	◀	Slow playback, (reverse)	▶▶	Picture search, locked picture search (forward)
REC+II	Recording pause	▶	Play pause (forward)	◀◀	Picture search, locked picture search (reverse)
▶	Playback, double speed playback (forward)	◀	Play pause (reverse)	◀◀	Auto play (REW-PLAY)
◀	Playback, double speed playback (reverse)	▶▶	Fast forward	AUTO	
▶▶	Slow playback, (forward)	◀◀	Rewind	◀◀	High speed rewind

Remote Display




SECTION 2 DISASSEMBLY


2-1. REMOVAL OF FRONT PANEL AND CABINET ASSEMBLIES




2-2. REMOVAL OF CONTROL SWITCH BLOCK




2-3. OPENING OF YC-124 BOARD AND VI-116 BOARD




2-4. REMOVE OF DG-11, DI-43, AND CN-62 BOARD



2-5. REMOVE OF HF-26, VP-33, CG-15 BOARD




2-6. REMOVE OF FL CASSETTE COMPARTMENT ASSEMBLY




③ Remove the FL cassette compartment assembly in the direction of arrow A.


2-7. REMOVE OF POWER BLOCK ASSEMBLY



2-8. REMOVE OF MF-167, 168, 169, 170 BOARD




2-9. REMOVE OF MECHANISM CHASSIS AND RP-147 BOARD





SECTION 3 DIAGRAMS

3-1. CIRCUIT BOARDS LOCATION





3-2. OVER ALL BLOCK DIAGRAM







3-3. VIDEO (1) BLOCK DIAGRAM






3- 1. VIDEO (2) BLOCK DIAGRAM








(See page 91.)
D1-43 BOARD

3-6. SERVO SYSTEM CONTROL BLOCK DIAGRAM



3-7. SYSTEM CONTROL MICROCOMPUTER PORT FUNCTIONS DESCRIPTION

• IC401 CXP80724-040Q

Signal	I/O	Pin No.	Description
RF_SWP	0	1	RF switching pulse
QVD	0	2	Quasi VD
QHD_ENBLE	0	3	Quasi HD voltage level control
AF_REC_P	0	4	Hi-fi record control
RECP	0	5	Record signal
FE_ON	0	6	Flying erase
REC_CTL	I/O	7	REC_CTL
SYNC_PLS	0	8	Pulse for V sync communication
AF_MIX_	0	9	Hi-fi/normal mix
NA_REC_P	0	10	Normal audio recording signal
NAP_B	0	11	Normal audio playback mode
CAM	0	12	Cam motor selection
CW	0	13	Motor rotation direction control
LOAD	0	14	Loading motor selection
C_IN/REC_PRF	I	15	Cassette-IN. Claw broken detect switch input
C_DOWN_	I	16	Cassette compartment down switch input
T_SENS	I	17	Tape-top sensor input
S_SENS	I	18	Tape-end sensor input
COLOR_CONT	0	19	PAL jog control
PINP_PC	*I/O	20	Digital child/parent select (*INITIAL mode input port)
PINP_ON	0	21	Digital ON/OFF_ control
PINP_SHIFT	0	22	Digital child picture move control
PINP_STILL	0	23	Digital control signal
PINP_EDIT	0	24	Digital control signal
PINP_L_MUTE	0	25	Digital control signal
PINP_R_MUTE	0	26	Digital control signal
STEP_PLS_	0	27	Step pulse
CTL_REC	0	28	CTL amp record inhibit
CTL_STEP	0	29	CTL amp step control
CTL_INDEX	0	30	CTL amp index control
AV_CTRL	0	31	(C+) TV/video select
END_LED	0	32	Top end sensor detect lamp
CAP_TRQ2	0	33	Capstan current limiter-2
CAP_TRQ1	0	34	Capstan current limiter-1
NA_MUTE	0	35	Normal audio mute
FULL_ERS_	0	36	Full erase control
A_MUTE	0	37	Audio mute
CAPSTOP_	0	38	Capstan motor stop
METER_L	I	48	Level meter L-ch input
METER_R	I	49	Level meter R-ch input
LP_HEAD	0	50	LP head selection
AFSW_POS	I	51	Hi-fi switching position adj.
MODE4	I	55	Cam encoder data-4
MODE3	I	56	Cam encoder data-3
MODE2	I	57	Cam encoder data-2
MODE1	I	58	Cam encoder data-1
NC	I	59	

Signal	I/O	Pin No.	Description
RF_ENV	I	60	Video playback signal envelope
AF_ENV	I	61	Hi-fi audio playback signal envelope
SW_POS	I	62	Head switching position adj.
SREEL_FG	I	63	S-side reel FG input
TREEL_FG	I	64	T-side reel FG input
NC	I	65	
V_SYNC	I	66	Composite sync input
PB_CTL	I	67	Servo CTL input
DRM_PG	I	68	Drum PG input
DRM_FG	I	69	Drum FG input
CAP_FG	I	70	Capstan FG input
TA_MUTE	0	71	Tuner audio mute
CAPRVS	0	72	Capstan reverse control
CAP_DA	0	73	Capstan D/A output
DRUM_DA	0	74	Drum D/A output
SKEW_ON	0	75	PAL jog control
SC_ON	0	76	Simultaneous Cast mode
VD_CTL	I	77	CTL counter input
MIC_SW_	I	78	Mic SW input (LOW active)
NORM_CONT1	0	79	Normal audio select function-1
NORM_CONT2	0	80	Normal audio select function-2
LINE1	0	81	Audio input selection-1
LINE2	0	82	Audio input selection-2
MONI_R	0	83	Audio monitor-R
MONI_L	0	84	Audio monitor-L
HEAD_CONT	I/O	85	Head amp control
SP_	0	91	SP mode (LOW active)
LP	0	92	LP mode
V_LINE1	0	93	Video input control-1
EDIT	0	94	Edit mode
VPB_	0	95	Video system playback mode
AFPB_	0	96	Hi-fi audio playback mode
V_LINE2	0	97	Video input control-2
REC	0	98	Head amp record current
JOG	0	99	Jog mode
AF_SWP	0	100	Hi-fi switching pulse

3- 1 SYSTEM CONTROL —SERVO PERIPHERAL CIRCUIT INTERFACE—

• IC401 on MA-140 board.

SGNAL	PIN NO.	I/O	STOP	FF	REW	TAPE/THREAD-ING	TAPE UNTHREAD-ING	PB	PB • PAUSE	SLOW	×2	CUE	REVIEW	REC	REC-PAUSE	PB INDEX WRT/ERS
RIC CTL	7	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	
CAP STOP	38	O (O.D)	L	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	L	*3	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	
STEP PLS	27	O	L	L	L	L	L	L	L	*2	L	L	L	L	L	
CTC REC	28	O	L	L	L	L	L	L	L	L	L	L	L	H	H	H
NDEX	30	O	L	L	L	L	L	L	L	L	L	L	L	L	L	H
PB CTL	67	I	H	*6	*6			*1	H/L	*2	*6	*6	*6	*1	H	
VD CTL	77	I	H	*6	*6			*1	H/L	*2	*6	*6	*6	*1	H	
DFUM PG	68	I	*4	*7	*7	*5	*5	*7	*7	*7	*7	*7	*7	*7	*7	
DFUM FG	69	I	*4	*8	*8	*5	*5	*8	*8	*8	*8	*8	*8	*8	*8	
CAP FG	70	I	H/L	*6	*6	*5	*5	*6	H/L	*9	*6	*6	*6	*6	H/L	
CAP RVS	72	O	H/L	L	H	L	H	L	L	*2	L	L	H	L	L	
CAP DA	73	O	*10	*10	*10	*10	*10	*11	*10	*10	*11	*11	*11	*11	*10	
DFUM DA	74	O	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	*12	
CTL STEP	29	O	L	L	L	L	L	L	L	*13	L	L	L	L	L	

- | | |
|---|--|
| *1. 30Hz pulse. | *8. 360Hz pulse. |
| *2. Tape running pulse. | *9. Tape running pluse. |
| *3. Inverted logic pulse of STEP PLS | *10. Approx. 2 msec cycle "H" or "L" pulse. |
| *4. During drum stop "L" | *11. Approx. 1.5 msec cycle "H" or "L" pulse. |
| *5. Non periodical pulse. | *12. Approx. 3 msec cycle "H" or "L" pulse. |
| *6. Cycle pulse proportional to tape speed. | *13. "H" in FWD direction, during STEP drive mode. |
| *7. 30Hz pulse. | |

3-9. SYSTEM CONTROL —MECHANISM BLOCK INTERFACE—

• IC401 on MA-140 board.

SIGNAL	PIN NO.	I/O	HI-SPEED REW	EJECTED	CASSETTE LOADING	CASSETTE UNLOAD-ING	TAPE/THREAD-ING	TAPE UNTHREAD-ING	STOP	FF	REW
CAM *1	12	O	L	L	L	L	H	H	L	L	L
LOAD	14	O	L	L	H	H	L	L	L	L	L
CW/CCW	13	O			H	L	H	L			
MODE 1	58	I	H	L	L	L	H	H	L	H	H
MODE 2	57	I	L	H	H	H	H	H	L	L	L
MODE 3	56	I	H	H	H	H	L	L	L	L	L
MODE 4	55	I	H	H	H	H	H	H	L	H	H
REC PRF	15	I	*2	L	*2	*2	*2	*2	*2	*2	*2
C-UP/DOWN	16	I	L	H	H→L	L→H	L	L	L	L	L
T REEL	64	I	*3	H/L	H/L	H/L	H/L	H/L	H/L	*3	*3
S REEL	63	O	*3	H/L	H/L	H/L	*3	*3	H/L	*3	*3
END LED	32	O (O.D)	*4	*4	*4	*4	*4	*4	*4	*4	*4
CAP TRQ 1	33	O (O.D)	*1							*1	*1
CAP TRQ 2	34	O (O.D)								*1	*1
CAP STOP	38	O (O.D)	H	L	L	L	H	H	L	H	H
CAP RVS	72	O	H	H			L	H	H/L	L	H
CAP DA *8	73	O									
T SENS	17	I	*7	*4	*4	*4	*7	*7	*7	*7	*7
S SENS	18	I	*7	*4	*4	*4	*7	*7	*7	*7	*7

- | | |
|---|--|
| *1. "H" : when mechanical mode shifted. | *6. During tape run, "L" only when CAP 1 |
| *2. "L" : when erasure protection tab is removed, "H" : When not removed. | *7. "L" : normally. 2 msec cycle "H" pulse top or end is detected. |
| *3. Cycle pulse proportional to reel rotation speed. | *8. Tape running pulse. |
| *4. Approx. 2 msec cycle "H" pulse. | |

3- 10. SYSTEM CONTROL —SERVO PERIPHERAL CIRCUIT INTERFACE—

• IC401 on MA-140 board.

Signal	I/O	Pin No.	Input/output level
COSMO • RESET	I	40	"H" : normally. "L" : when power failure detected or power failure restored
COSMO • CS	I	44	Chip select signal from timer micro computer. V cycle "L" pulse.
SI • BUS	I	45	Serial communication data from timer micro computer. V cycle "L" pulse.
SO • BUS	O	46	Serial communication data to timer micro computer. V cycle "L" pulse.
S CLK	I	47	Serial communication clock with timer micro computer. V cycle "L" pulse.

3-9. SYSTEM CONTROL —MECHANISM BLOCK INTERFACE—

• IC401 on MA-140 board.

VIEW	REC	REC-PAUSE	PB INDEX WRT/ERS
*1	*1	*1	
HI-Z (O.D)	HI-Z (O.D)	HI-Z (O.D)	
L	L	L	
L	H	H	H
L	L	L	H
*6	*1	H	
*6	*1	H	
*7	*7	*7	
*8	*8	*8	
*6	*6	H/L	
H	L	L	
*11	*11	*10	
*12	*12	*12	
L	L	L	

SIGNAL	PIN NO.	I/O	HI-SPEED REW	EJECTED	CASSETTE LOADING	CASSETTE UNLOADING	TAPE/THREADING	TAPE UNTHREADING	STOP	FF	REW	PB	PB • PAUSE	SLOW	×2	CUE	REVIEW	REC	REC • PAUSE
CAM *1	12	O	L	L	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L
LOAD	14	O	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L	L	L
CW/CCW	13	O			H	L	H	L											
MODE 1	58	I	H	L	L	L	H	H	L	H	H	H	L	L	H	H	H	H	L
MODE 2	57	I	L	H	H	H	H	H	L	L	L	L	H	H	L	L	L	L	H
MODE 3	56	I	H	H	H	H	L	L	L	L	L	H	H	H	H	H	L	H	H
MODE 4	55	I	H	H	H	H	H	H	L	H	H	L	L	L	L	L	L	L	L
REC PRF	15	I	*2	L	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
C-UP/DOWN	16	I	L	H	H→L	L→H	L	L	L	L	L	L	L	L	L	L	L	L	L
T REEL	64	I	*3	H/L	H/L	H/L	H/L	H/L	H/L	*3	*3	*3	H/L	*3	*3	*3	*3	*3	H/L
S REEL	63	O	*3	H/L	H/L	H/L	*3	*3	H/L	*3	*3	*3	H/L	*3	*3	*3	*3	*3	H/L
END LED	32	O (O.D)	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4
CAP TRQ 1	33	O (O.D)	*1							*1	*1			*6		*1	*1		
CAP TRQ 2	34	O (O.D)								*1	*1								
CAP STOP	38	O (O.D)	H	L	L	L	H	H	L	H	H	H	L	*8	H	H	H	H	L
CAP RVS	72	O	H	H			L	H	H/L	L	H	L	L	L/*8	L	L	H	L	L
CAP DA *8	73	O																	
T SENS	17	I	*7	*4	*4	*4	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7
S SENS	18	I	*7	*4	*4	*4	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7

- *1. "H" : when mechanical mode shifted.
- *2. "L" : when erasure protection tab is removed, "H" : When not removed.
- *3. Cycle pulse proportional to reel rotation speed.
- *4. Approx. 2 msec cycle "H" pulse.
- *5. During tape run, "L" only when CAP RVS is "H".
- *6. During tape run, "L" only when CAP RVS is "H".
- *7. "L" : normally. 2 msec cycle "H" pulse : when tape top or end is detected.
- *8. Tape running pulse.

3-10. SYSTEM CONTROL —SERVO PERIPHERAL CIRCUIT INTERFACE—

• IC401 on MA-140 board.

Signal	I/O	Pin No.	Input/output level
COSMO • RESET	I	40	"H" : normally. "L" : when power failure detected or power failure restored.
COSMO • CS	I	44	Chip select signal from timer micro computer. V cycle "L" pulse.
SI • BUS	I	45	Serial communication data from timer micro computer. V cycle "L" pulse.
SO • BUS	O	46	Serial communication data to timer micro computer. V cycle "L" pulse.
S CLK	I	47	Serial communication clock with timer micro computer. V cycle "L" pulse.

3-11. SYSTEM CONTROL —VIDEO BLOCK INTERFACE—

• IC401 on MA-140 board.

SIGNAL	PIN NO.	I/O	STOP/FF/REW	TAPE/THREAD-ING	TAPE UNTHREAD-ING	PB	PB • PAUSE	SLOW	×2	CUE	REVIEW	REC	REC-PAUSE
V • PB	95	O	H	H	H	L	L	L	L	L	L	H	H
HEAD CONT	85	O	L	L	L	L	HI-Z (2.5V)	*1	*9	*5	*5	L	L
RF SW P (SW30)	1	O	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
Q VD/V MUTE	2	O	L	L	L	*3	*4	*4	*4	*4	*4	L	L
SP	91	O	*6	*6	*6	*7	*7	*7	*7	*7	*7	*6	*6
SP • 2	92	O	*6	*6	*6	*7	*7	*7	*7	*7	*7	*6	*6
LP	93	O	L	L	L	*7	*7	*7	*7	*7	*7	L	L
REC • P	5	O	L	L	L	L	L	L	L	L	L	L	H
REC	98	O	L	L	L	L	L	L	L	L	L	H	H
V SYNC	66	I	*8	*8	*8	*8	*8	*8	*8	*8	*8	*8	*8
V LINE 1	93	O	*11										
V LINE 2	97	O											

*1. In forward direction slow mode :

during tape stop "HI-Z (2.5V)" during tape run (for about 40ms) "L".

In reverse direction slow mode :

during tape stop "HI-Z (2.5V)" during tape run (for about 40ms).

SP mode "H"

EP mode "L"

*2. Sync with drum revolution. 30 Hz 50% DUTY pulse.

*3. "L" normaly. "H" : when CTL signal is not played back.

*4. V cycle "H" pulse.

*5. According to SP/EP selector. "H" : SP mode, "L" : EP mode.

*6. According to SP/EP selector. "L" : SP mode, "H" : EP mode.

*7. According to tape REC mode.

Signal	Mode		
	LINE1	LINE2	EP
SP (Pin pin)	L	H	H
EP (Pin pin)	L	L	H

*8. Composite sync signal (positive polarity).

*9. According to SP/EP selector. "H" : SP mode, "HI-Z (2.5V)" : EP mode.

*11. According to Input selector mode.

Signal	Mode		
	LINE1	LINE2	TUNER LINE3/CT SC
V LINE 1 (Pin pin)	H	L	H
V LINE 2 (Pin pin)	L	L	H

3-12. SYSTEM CONTROL —AUDIO BLOCK INTERFACE—

• IC401 on MA-140 board.

SIGNAL	PIN NO.	I/O	STOP/FF/REW	TAPE LOADING	TAPE UNLOAD-ING	PB	PB • PAUSE	SLOW	×2	CUE	REVIEW	REC	REC • PAUSE
AF PB	96	O	H	H	H	H	L	L	L	L	L	L	H
MONI (L)	84	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1
MONI (R)	83	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1
AF ENVELOP	61	I	AF RF envelope signal input pin for auto tracking										
NA PB	11	O	L	L	L	H	H	H	H	H	H	L	L
A MUTE	37	O (O.D)	L	L	L	*4	H	H	H	H	H	L	L
SP	91	O	*2	*2	*2	*3	*3	*3	*3	*3	*2	*2	*2
NA REC • P	10	O	L	L	L	L	L	L	L	L	L	H	L
AF REC P	4	O	L	L	L	L	L	L	L	L	L	H	L
AF SWP	100	O	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5
AF SW POSITION	51	I	input pin for AF switching position adj.										
SC - ON	76	O	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6
MICSW	78	I	mic. input switch (low when input)										
AF MIX	9	O (O.D)	L	L	L	*9	*9	*9	*9	*9	*9	L	L
METER (L)	48	I	input pin for audio level meter (left) display										
METER (R)	49	I	input pin for audio level meter (right) display										
FULL ERS	36	O (O.D)	H	H	H	H	H	H	H	H	H	L	H
NOR A MUTE	35	O	L	L	L	*4	H	H	H	H	H	L	L
NOR CONT 1	79	O	*10. normal audio control signal										
NOR CONT 2	80	O											

*1. Depending upon audio monitor

signal	audio monitor			
	stereo or main/sub left/right	main left	sub right	(normal)
MONI (L)	H	H	L	L
MONI (R)	H	L	H	L

*2. Depending upon SP/EP selector. SP mode "L", EP mode "H".

*3. Depending upon recording mode on tape. SP mode "L", EP mode "H".

*4. "H" when CTL signal is not played back.

*5. 30Hz, 50% duty pulse after about 5 msec delayed from RF SW P.

*6. "H" during simul-cast ON.

*9. "H" when HIFI/NORMAL MIX ON.

*10.

signal	input	
	bilingual send/receive	others
NOR CONT 1	L	H
NOR CONT 2	H	H

3-13. S

• IC401

STEREC
BILING
TAMUT
F MONC

3-14. S

• IC401

TV/VTF
LINE 1
LINE 2

*1.

Sig
LI
LI

3-15. S

• IC401

Pin P C
Pin P F
Pin P S
Pin P E
Pin P M
Pin L M
Pin Still

3-12. SYSTEM CONTROL —AUDIO BLOCK INTERFACE—

• IC401 on MA-140 board.

SIGNAL	PIN NO.	I/O	STOP/FF/REW	TAPE LOADING	TAPE UNLOADING	PB	PB • PAUSE	SLOW	× 2	CUE	REVIEW	REC	REC • PAUSE	
AF PB	96	O	H	H	H	H	L	L	L	L	L	L	H	
MONI (L)	84	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	
MONI (R)	83	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	
AF ENVELOP	61	I	AF RF envelope signal input pin for auto tracking											
NA PB	11	O	L	L	L	H	H	H	H	H	H	L	L	
A MUTE	37	O (O.D)	L	L	L	*4	H	H	H	H	H	L	L	
SP	91	O	*2	*2	*2	*3	*3	*3	*3	*3	*2	*2	*2	
NA REC • P	10	O	L	L	L	L	L	L	L	L	L	H	L	
AF REC P	4	O	L	L	L	L	L	L	L	L	L	H	L	
AF SWP	100	O	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	*5	
AF SW POSITION	51	I	input pin for AF switching position adj.											
SC - ON	76	O	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	
MICSW	78	I	mic. input switch (low when input)											
AF MIX	9	O (O.D)	L	L	L	*9	*9	*9	*9	*9	*9	*9	L	L
METER (L)	48	I	input pin for audio level meter (left) display											
METER (R)	49	I	input pin for audio level meter (right) display											
FULL ERS	36	O (O.D)	H	H	H	H	H	H	H	H	H	L	H	
NOR A MUTE	35	O	L	L	L	*4	H	H	H	H	H	L	L	
NOR CONT 1	79	O	} * 10. normal audio control signal											
NOR CONT 2	80	O												

* 1. Depending upon audio monitor

audio monitor signal	stereo or main/sub left/right	main left	sub right	(normal)
MONI (L)	H	H	L	L
MONI (R)	H	L	H	L

* 2. Depending upon SP/EP selector. SP mode "L", EP mode "H".

* 3. Depending upon recording mode on tape. SP mode "L", EP mode "H".

* 4. "H" when CTL signal is not played back.

* 5. 30Hz, 50% duty pulse after about 5 msec delayed from RF SW P.

* 6. "H" during simul-cast ON.

* 9. "H" when HIFI/NORMAL MIX ON.

* 10.

input signal	bilingual send/receive	others
NOR CONT 1 ⑦	L	H
NOR CONT 2 ⑧	H	H

3-13. SYSTEM CONTROL —TUNER BLOCK INTERFACE—

• IC401 on MA-140 board.

Signal	I/O	Pin No.	Input/output level
STEREO	I	21	Tuner audio input pin. "L" in stereo
BILING	I	22	Tuner audio input pin. "L" in bilingual
TAMUTE	O	71	Tuner audio mute output. "H" during tuning operation or during tuned to blank channel.
F MONO	O (O.D)	31	Tuner audio mute output. "L" during auto stereo OFF.

3-14. SYSTEM CONTROL —RF MODULATION/INPUT SELECTOR BLOCK INTERFACE—

• IC401 on MA-140 board.

Signal	I/O	Pin No.	Input/output level
TV/VTR	I	31	"L" when RF modulator is through mode.
LINE 1	I	81	} * 1 input select control signal
LINE 2	I	82	

* 1.


Input Signal	Tuner	LINE 1	LINE 2
LINE 1	L	H	L
LINE 2	L	L	H


3-15. SYSTEM CONTROL —DIGITAL CONTROL BLOCK INTERFACE—


• IC401 on MA-140 board.

Signal	Pin No.	Input/output level
Pin P ON	21	"H" during digital ON
Pin P PC	20	"H" when when parent picture : EE , child picture : PB with PINP.
Pin P SHIFT	22	H pulse during child picture shifting
Pin P Edit	24	"H" during edit monitor
Pin P Mute	26	"H" when right side picture mute during edit monitor mode
Pin L Mute	25	"H" when left side picture mute during edit monitor mode
Pin Still	23	"H" when right side picture is still picture during edit monitor mode.


3-16. AUDIO BLOCK DIAGRAM









3-18. TUNER NICAM BLOCK DIAGRAM



3-19. TRANSCODER BLOCK DIAGRAM (B Model)




3-20. POWER SUPPLY BLOCK DIAGRAM







SECTION 4 PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1. FRAME SCHEMATIC DIAGRAM








D
E
F
G
H
I
J
K
L
M
N





(See page 115.)



MA-140
(See page 111, 115, 119.)

MD-58
(See page 122.)

CAPSTAN MOTOR








































1	CAP FG	1
2	SW SV	2
3	BRK	3
4	CAP RVS	4
5	MTR 12V	5
6	CAP VS	6
7	LIMITER	7
8	GND MTR	8
9	GND SWF	9


CAM MOTOR

1	CAM (C)	1
2	N.C.	2
3	CAM (H)	3

CAM ENCODER

1	MODE 4	1
2	MODE 3	2
3	MODE 2	3
4	MODE 1	4
5	GND UNSW	5








THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.
 (In addition to this, the necessary note is printed in each block.)

- For printed wiring boards:**
- — : indicated a lead wire mounted on the component side.
 - — : indicated a lead wire mounted on the conductor side.
 - ● : Through hole.
 - ■ : Parts mounted on the conductor side.
 - ▨ : Pattern from the side which enables seeing.
 - ▩ : Pattern of the rear side.
 - ○ : Circled numbers refer to waveforms.

Caution :
 Pattern face side: Parts on the pattern face side seen from the (Conductor Side) pattern face are indicated.
 Parts face side: Parts on the parts face side seen from the (Component side) parts face are indicated.


- For schematic diagram:**
- Caution when replacing chip parts.
 New parts must be attached after removal of chip.
 Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
 - All resistors are in ohms, 1/4 W unless otherwise noted.
 Chip resistors: 1/10 W unless otherwise noted.
 k Ω : 1000 Ω , M Ω : 1000k Ω .
 - All capacitors are in μF unless otherwise noted. pF: μ μF.
 50V or less are not indicated except for electrolytics and tantalums.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - : nonflammable resistor.
 - : fusible resistor.


E
F
G
H
I
J
K
L
M
N



16

HEAD AMP





THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.
(In addition to this, the necessary note is printed in each block.)

- For printed wiring boards:**
- — : indicated a lead wire mounted on the component side.
 - — : indicated a lead wire mounted on the conductor side.
 - : Through hole.
 - : Parts mounted on the conductor side.
 - ▨ : Pattern from the side which enables seeing.
 - ▩ : Pattern of the rear side.
 - : Circled numbers refer to waveforms.

Caution :
Pattern face side: Parts on the pattern face side seen from the (Conductor Side) pattern face are indicated.
Parts face side: Parts on the parts face side seen from the (Component side) parts face are indicated.

- For schematic diagram:**
- Caution when replacing chip parts.
New parts must be attached after removal of chip.
Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
 - All resistors are in ohms, 1/4 W unless otherwise noted.
Chip resistors: 1/10 W unless otherwise noted.
kΩ : 1000 Ω , MΩ : 1000k Ω .
 - All capacitors are in μF unless otherwise noted. pF: μ μF.
50V or less are not indicated except for electrolytics and tantalums.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - : nonflammable resistor.
 - : fusible resistor.
 - : panel designation.
 - Δ : internal component.
 - — : B + Line.
 - - - - : B - Line.
 - : IN/OUT direction of B line (+, -).
 - Circled numbers refer to waveforms.
 - Voltage are dc between ground and measurement points.
 - Readings are taken with a color-bar signal input.
 - Readings are taken with a digital multimeter (DC10 MΩ).
 - Voltage are taken with a VOM (input impedance 10 MΩ).
 - Voltage variations may be noted due to normal production tolerances.

Note : The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

Note: The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

Note: Les composants identifiés par une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

• Signal path

	VIDEO Signal			AUDIO Signal
	CHROMA	Y	Y/CHROMA	
REC	→	⇒	⇒⇒	⇒
PB	⇐	⇐⇐	⇐⇐⇐	⇐

RP-147 (HEAD AMP) PRINTED WIRING BOARD


- Ref. No. RP-147 BOARD : 1,000 Series -

RP-147 BOARD

- 0790 A-3
- 0791 B-2
- 0801 D-9
- 0802 B-7
- 0803 B-7
- 0805 D-10
- 0806 C-10
- 0807 C-10

- IC26 B-11
- IC80 B-9

- 0201 D-1
- 0701 B-3
- 0703 A-2
- 0705 B-2
- 0706 A-3
- 0707 B-2
- 0801 C-10
- 0802 C-10
- 0803 C-3
- 0804 C-8
- 0805 B-8
- 0806 B-6
- 0807 B-5
- 0808 B-4
- 0809 C-5
- 0810 A-8
- 0811 A-7
- 0813 C-1
- 0814 B-7
- 0890 A-10
- 0891 A-9
- 0892 A-9



DIODE

D806 8-719-400-18 MA152WK

TRANSISTOR


Q260 8-729-103-72 2SD1005-BV
 Q701 8-729-422-28 2SD601A-R
 Q703 8-729-422-28 2SD601A-R
 Q705 8-729-422-37 2SB709A-R
 Q706 8-729-421-19 UN2213

Q707 8-729-422-28 2SD601A-R
 Q801 8-729-422-28 2SD601A-R
 Q802 8-729-422-28 2SD601A-R
 Q803 8-729-424-18 UN2113
 Q804 8-729-422-28 2SD601A-R

Q805 8-729-422-37 2SB709A-R
 Q806 8-729-422-37 2SB709A-R
 Q807 8-729-422-28 2SD601A-R
 Q808 8-729-901-01 DTC144EK
 Q809 8-729-422-28 2SD601A-R


Q810 8-729-901-47 DTA143EK
 Q811 8-729-301-98 2SB1000A-L
 Q813 8-729-424-18 UN2113
 Q814 8-729-421-19 UN2213
 Q890 8-729-216-22 2SA1162

Q891 8-729-216-22 2SA1162
 Q892 8-729-421-19 UN2213




28	2SD601A-R	Q805	8-729-422-37	2SB709A-R	Q810	8-729-901-47	DTA143EK	Q891	8-729-216-22	2SA1162
28	2SD601A-R	Q806	8-729-422-37	2SB709A-R	Q811	8-729-301-98	2SB1000A-L	Q892	8-729-421-19	UN2213
28	2SD601A-R	Q807	8-729-422-28	2SD601A-R	Q813	8-729-424-18	UN2113			
18	UN2113	Q808	8-729-901-01	DTC144EK	Q814	8-729-421-19	UN2213			
28	2SD601A-R	Q809	8-729-422-28	2SD601A-R	Q890	8-729-216-22	2SA1162			

YC-124 BOARD (1/2)



YC-124 BOARD (2/2)




DIODE

D101	8-719-400-18	MA152WK
D105	8-719-400-18	MA152WK
D301	8-719-400-18	MA152WK
D302	8-719-400-18	MA152WK (B)
D401	8-719-400-18	MA152WK (B)

IC

IC460	8-759-927-46	SN74HC00ANS (B)
IC501	8-759-925-90	SN74HC74ANS
IC502	8-759-300-71	TC4053BF

YC-124 BOARD




TRANSISTOR

Q102	8-729-216-22	2SA1162
Q104	8-729-901-01	DTC144EK
Q105	8-729-920-74	2SC2412K-QR
Q106	8-729-216-22	2SA1162
Q111	8-729-216-22	2SA1162
Q114	8-729-901-01	DTC144EK (EXCEPT B)
Q121	8-729-920-74	2SC2412K-QR
Q122	8-729-901-01	DTC144EK
Q123	8-729-901-01	DTC144EK
Q124	8-729-901-01	DTC144EK
Q125	8-729-901-01	DTC144EK
Q301	8-729-920-74	2SC2412K-QR
Q302	8-729-920-74	2SC2412K-QR
Q303	8-729-920-74	2SC2412K-QR
Q304	8-729-900-53	DTC114EK
Q305	8-729-216-22	2SA1162
Q306	8-729-901-01	DTC144EK
Q307	8-729-920-74	2SC2412K-QR (VC)
Q308	8-729-920-74	2SC2412K-QR
Q309	8-729-920-74	2SC2412K-QR
Q310	8-729-901-04	DTA114EK
Q352	8-729-901-01	DTC144EK (VC)
Q360	8-729-809-77	2SC3142-J4
Q362	8-729-901-01	DTC144EK
Q380	8-729-920-74	2SC2412K-QR
Q381	8-729-920-74	2SC2412K-QR
Q382	8-729-216-22	2SA1162
Q383	8-729-920-74	2SC2412K-QR (EXCEPT B)
Q390	8-729-901-01	DTC144EK (B)
Q401	8-729-920-74	2SC2412K-QR (B)
Q402	8-729-920-74	2SC2412K-QR (B)
Q403	8-729-901-47	DTA143EK (B)
Q405	8-729-920-74	2SC2412K-QR (B)
Q406	8-729-901-47	DTA143EK (B)
Q407	8-729-901-01	DTC144EK (B)
Q408	8-729-901-01	DTC144EK (B)
Q450	8-729-920-74	2SC2412K-QR
Q451	8-729-901-01	DTC144EK (B)
Q452	8-729-901-01	DTC144EK (B)
Q453	8-729-901-01	DTC144EK (B)

Y-124 (VIDEO) PRINTED WIRING BOARD

- Ref. No. YC-124 BOARD : 2,000 Series -

YC-124 BOARD



D101	G-7
D105	E-8
D301	E-6
D302	G-2
D401	B-1
IC101	E-9
IC102	C-10
IC301	F-6
IC302	B-5
IC360	C-5
IC361	C-9
IC362	B-8
IC401	E-2
IC450	C-2
IC460	B-1
IC461	B-2
IC501	B-4
IC502	B-4

Q102	B-9
Q104	E-7
Q105	D-10
Q106	D-10
Q111	B-10
Q121	G-10
Q122	E-8
Q123	E-8
Q124	G-9
Q125	G-10
Q301	G-6
Q302	F-6
Q303	E-5
Q304	E-6
Q305	G-6
Q306	E-7
Q307	G-7
Q308	G-8
Q309	F-5
Q310	B-6
Q352	F-6
Q360	E-5
Q362	C-5
Q380	C-9
Q381	B-8
Q382	B-8
Q383	B-5
Q390	E-6
Q401	G-1
Q402	F-1
Q403	F-1
Q405	F-2
Q406	G-2
Q407	G-2
Q408	F-1
Q450	C-1
Q451	C-7
Q452	B-7
Q453	B-6
Q460	A-2
Q501	G-8
Q502	F-6
Q511	C-3
Q512	D-3
Q513	D-4
Q513	C-3
Q514	B-4
Q515	B-5
Q516	B-7
Q517	B-7
Q518	A-4


TRANSISTOR

Q102	8-729-216-22 2SA1162	Q125	8-729-901-01 DTC144EK	Q310	8-729-901-04 DTA114EK	Q402	8-729-920-74 2SC2412K-QR (B)	Q460	8-729-901-01 DTC144EK (B)	Q517	8-729-901-47 DTA143EK (B)
Q104	8-729-901-01 DTC144EK	Q301	8-729-920-74 2SC2412K-QR	Q352	8-729-901-01 DTC144EK (VC)	Q403	8-729-901-47 DTA143EK (B)	Q501	8-729-920-74 2SC2412K-QR	Q518	8-729-901-01 DTC144EK (B)
(B) Q105	8-729-920-74 2SC2412K-QR	Q302	8-729-920-74 2SC2412K-QR	Q360	8-729-809-77 2SC3142-J4	Q405	8-729-920-74 2SC2412K-QR (B)	Q502	8-729-901-01 DTC144EK		
(B) Q106	8-729-216-22 2SA1162	Q303	8-729-920-74 2SC2412K-QR	Q362	8-729-901-01 DTC144EK	Q406	8-729-901-47 DTA143EK (B)	Q511	8-729-920-74 2SC2412K-QR (EXCEPT B)		
Q111	8-729-216-22 2SA1162	Q304	8-729-900-53 DTC114EK	Q380	8-729-920-74 2SC2412K-QR	Q407	8-729-901-01 DTC144EK (B)	Q512	8-729-920-74 2SC2412K-QR		
Q114	8-729-901-01 DTC144EK (EXCEPT B)	Q305	8-729-216-22 2SA1162	Q381	8-729-920-74 2SC2412K-QR	Q408	8-729-901-01 DTC144EK (B)	Q513	8-729-901-01 DTC144EK (EXCEPT B)		
Q121	8-729-920-74 2SC2412K-QR	Q306	8-729-901-01 DTC144EK	Q382	8-729-216-22 2SA1162	Q450	8-729-920-74 2SC2412K-QR	Q513	8-729-920-74 2SC2412K-QR (B)		
Q122	8-729-901-01 DTC144EK	Q307	8-729-920-74 2SC2412K-QR (VC)	Q383	8-729-920-74 2SC2412K-QR (EXCEPT B)	Q451	8-729-901-01 DTC144EK (B)	Q514	8-729-901-01 DTC144EK		
Q123	8-729-901-01 DTC144EK	Q308	8-729-920-74 2SC2412K-QR	Q390	8-729-901-01 DTC144EK (B)	Q452	8-729-901-01 DTC144EK (B)	Q515	8-729-901-01 DTC144EK (B)		
Q124	8-729-901-01 DTC144EK	Q309	8-729-920-74 2SC2412K-QR	Q401	8-729-920-74 2SC2412K-QR (B)	Q453	8-729-901-01 DTC144EK (B)	Q516	8-729-901-04 DTA114EK (B)		

EO VIDEO

VIDEO VIDEO

E
F
G
H
I
J
K
L
M
N







VI-116 BOARD

INPUT SELECT

TUNER SELECT

LINE3 AMP

AV OUT SELECT




CHILD TUNER SELECT (CANAL PLUS MODELS ONLY)

CHILD SELECT

CHILD AGC

H DET



PARENT (OSD) SEL

CHILD IN SEL (NON DUAL MODELS ONLY)

LINE OUT SEL

$\langle \text{ABC. OUT} \rangle$

$\langle \text{Y. OUT} \rangle$

$\langle \text{OSD. IN} \rangle$

$\langle \text{TC. OUT} \rangle$

$\langle \text{LINE. OUT} \rangle$

$\langle \text{OSD. OUT} \rangle$

$\langle \text{RBB. CONT} \rangle$

$\langle \text{I} \rangle$


$\langle \text{I} \rangle$

E
F
G
H
I
J
K
L
M
N
O

EURO - AV (LINE 3)
CANAL PLUS: NP
PAY-TV-DECODER: VC

CN101 21P EURO CON

A OUT RD	1
A IN RD	2
A OUT LJ	3
GND (AUDI O)	4
GND (D)	5
A IN LJ	6
BLUE	7
CONTROL	8
GND (G)	9
GREEN	10
GND (R)	11
GND (I)	12
RED	13
I	14
GND (V)	15
GND (V)	16
GND (V)	17
GND (V)	18
V OUT	19
V IN	20
GND (V)	21



MA-140 BOARD
CN915
(See page 113.)

THRU	3
C+ CONT	4
VFB	5
H. DET	6

B, NP, VC MODEL

TO MA-140 BOARD
CN917
825VC/NP
ONLY
(See page 114.)

TUNER A RD IN	1
TUNER A LJ IN	2
GND (A)	3
LINE1 A RD IN	4
GND (A)	5
LINE1 A LJ IN	6
TUNER SEL	7
LINE3 OUT MUTE	8
GND (V)	9
GND (V)	10
UNSW 12V	11
I	12
ROB CONT	13

TO VI-116 BOARD
CN501
(See page 91.)

1	LINE3 OUT
2	GND (V)
3	LINE3 IN
4	GND (V)
5	I
6	GND (A)
7	LINE1 A RD IN
8	UNSW 12V
9	LINE1 A LJ IN
10	LINE3 OUT MUTE
11	TUNER A RD IN
12	TUNER SEL
13	TUNER A LJ IN

TO MA-140 BOARD
CN913
(See page 114.)

1	LINE3 A RD IN
2	LINE3 A LJ IN
3	GND (A)
4	C+ DET
5	GND (V)
6	R
7	G
8	B

TO MA-140 BOARD
CN916
(See page 113.)

1	SAT. C+ SEL
2	P IN P
3	CHILD SEL
4	LINE OUT SEL
5	P.C ALT
6	DIGITAL DN
7	LINE OUT
8	GND (V)
9	OSB IN
10	GND (V)
11	YC OUT

EXCEPT B MODEL


TO DI-43 BOARD
CN206
(See page 94.)

TO MA-140 BOARD
CN924
(See page 112.)

1	AGC OUT
2	GND (V)
3	Y OUT
4	GND (V)
5	OG OUT
6	GND (V)
7	OSB OUT
8	GND (V)

TO CN-62 BOARD
CN103
(See page 94.)

1	LINE3 OUT
2	GND (V)
3	LINE3 IN
4	GND (V)
5	I
6	GND (A)
7	LINE1 A RD IN
8	UNSW 12V
9	LINE1 A LJ IN
10	LINE3 OUT MUTE
11	TUNER A RD IN
12	TUNER SEL
13	TUNER A LJ IN



• Signal path

	VIDEO Signal			AUDIO Signal
	CHROMA	Y	Y/CHROMA	
REC			→→→	→
PB			←←←	

VI-116 (VIDEO INTERFACE), CN-62(VIDEO/AUDIO INTERFACE), DI-43(RELAY) PRINTED WIRING BOARDS

—Ref. No. VI-116 BOARD : 3,000 Series, CN-62 BOARD : 4,000 Series, DI-43 BOARD : 5,000 Series —

VI-116 BOARD

- D51 C-3
- D52 A-4
- D53 D-5
- D54 D-5
- D55 D-5

- IC01 D-4
- IC02 D-3
- IC03 C-1
- IC04 D-2
- IC51 C-6
- IC52 C-6
- IC53 B-7
- IC54 B-7
- IC55 C-7
- IC56 B-6
- IC01 A-2

- Q51 C-5
- Q52 B-4
- Q53 A-4
- Q54 B-3
- Q56 D-5
- Q57 D-5
- Q58 C-4
- Q52 A-5
- Q71 A-1
- Q72 A-1
- Q73 A-2
- Q74 A-2
- Q75 B-2
- Q76 B-3
- Q77 B-3
- Q78 B-2

DIODE

- D501 8-719-911-19 1SS119
- D502 8-719-911-19 1SS119
- D503 8-719-911-19 1SS119 (B)
- D504 8-719-911-19 1SS119 (B)
- D505 8-719-911-19 1SS119 (B)

IC


- IC502 8-759-048-09 MM1148XFF
- IC503 8-759-501-21 MM1149XF
- IC551 8-759-501-21 MM1149XF
- IC553 8-759-048-09 MM1148XFF
- IC554 8-759-048-09 MM1148XFF

- IC555 8-759-048-09 MM1148XFF (NP/VC)
- IC556 8-759-048-09 MM1148XFF


TRANSISTOR

- Q501 8-729-120-28 2SC1623-L5L6
- Q502 8-729-216-22 2SA1162
- Q503 8-729-120-28 2SC1623-L5L6
- Q504 8-729-900-53 DTC114EK
- Q506 8-729-901-06 DTA144EK (B)


VI-116 BOARD



DI-43 BOARD



CN-62 BOARD



CN-62 BOARD

- D101 A-1
- D102 A-1
- D103 B-1
- D104 B-1
- D105 D-2
- D106 D-2
- D107 D-3
- IC801 B-2
- IC802 C-3

IC

- IC802 8-759-909-71 BA4558F (NP/VC)

SLV-825/B/NC/NP/UB/VC

CG-15 (DISPLAY CONTROLLER) PRINTED WIRING BOARD

- Ref. No. CG-15 BOARD : 6,000 Series -

CG-15 BOARD

IC601	E-3
IC602	B-4
IC603	C-5
Q603	C-3
Q604	A-2
Q605	D-3
Q606	C-3
Q607	C-2
Q608	B-2
Q609	B-3


IC

IC601 8-759-078-01 uPD78013GC-VSX1760


TRANSISTOR

Q603 8-729-422-28 2SD601A-R
 Q604 8-729-422-37 2SB709A-R
 Q605 8-729-424-18 UN2113
 Q606 8-729-422-28 2SD601A-R
 Q607 8-729-421-19 UN2213

Q608 8-729-422-28 2SD601A-R (VC)
 Q609 8-729-421-19 UN2213 (VC)



16




C-G-15 (DISPLAY CONTROLLER) SCHEMATIC DIAGRAM

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

- Ref. No. CG-15 BOARD : 6,000 Series -

A
B
C
D
E
F
G
H
I
J

CG-15 BOARD



DG-11 (DIGITAL PICTURE PROCESS) SCHEMATIC DIAGRAM

- Ref. No. DG-11 BOARD : 7,000 Series -

A

B

C

D

E

F



G

H

I

J

K




IC101
SELECTOR

IC102

IC103
CHROMA DECODER

7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23



DG-11 BOARD

D101 C-2
 D105 H-2
 D106 D-13
 D109 F-13

IC101 B-2
 IC102 D-4
 IC103 F-2
 IC104 G-5
 IC105 H-5
 IC108 E-6

Q101 B-13
 Q102 A-13
 Q103 B-14
 Q108 C-12
 Q109 D-10
 Q110 E-10
 Q112 D-3
 Q113 D-12
 Q114 D-3
 Q116 D-14
 Q117 E-3
 Q118 E-14
 Q120 H-14
 Q121 H-13
 Q122 H-2
 Q123 H-1
 Q125 F-3
 Q126 F-13
 Q127 D-5

DIODE

D101 8-719-400-18 MA152WK
 D105 8-719-400-18 MA152WK
 D106 8-719-400-18 MA152WK
 D109 8-719-400-18 MA152WK

IC

IC104 8-759-322-68 HD49410
 IC108 8-759-008-74 MC14001BF

TRANSISTOR


Q101 8-729-305-25 2SA1052-C
 Q102 8-729-305-25 2SA1052-C
 Q103 8-729-305-25 2SA1052-C
 Q108 8-729-305-25 2SA1052-C
 Q109 8-729-305-25 2SA1052-C

 Q110 8-729-305-25 2SA1052-C
 Q112 8-729-901-00 DTC124EK
 Q113 8-729-305-25 2SA1052-C
 Q114 8-729-230-49 2SC2712-G
 Q116 8-729-305-25 2SA1052-C


 Q117 8-729-230-49 2SC2712-G
 Q118 8-729-305-25 2SA1052-C
 Q120 8-729-901-00 DTC124EK
 Q121 8-729-305-25 2SA1052-C
 Q122 8-729-230-49 2SC2712-G

 Q123 8-729-901-00 DTC124EK
 Q125 8-729-902-96 FMS1
 Q126 8-729-901-01 DTC144EK
 Q127 8-729-230-49 2SC2712-G


DG-11 BOARD (CONDUCTOR SIDE)




1-637-535 21




3 4 5 6 7



MA-140 (SERVO, SYSTEM CONTROL, MECHANISM DRIVE, AMP), VP-33(SERVO/SYSTEM CONTROL MICROPROCESSOR) PRINTED WIRING BOARDS
- Ref. No. MA-140 BOARD : 8,000 Series, VP-33 BOARD : 9,000 Series -






RF 501
RF CHANNEL
30
39
AERIAL
OUT
LOCAL
DX
IN

CNJ 902
EURO-AV
(LINE 1)

MA-140 BOARD


D301	K-14	0101	B-14
D302	K-14	0102	E-15
D304	K-15	0103	E-14
D400	D-4	0104	B-14
D401	C-3	0105	A-14
D402	C-3	0109	K-12
D403	E-1	0202	F-14
D404	E-1	0203	E-8
D405	F-2	0220	H-12
D406	F-2	0247	G-12
D450	D-3	0270	H-12
D451	E-3	0297	G-13
D452	E-4	0301	K-15
D502	B-8	0302	L-15
D505	A-5	0303	K-15
D506	A-11	0304	L-15
D901	B-14	0305	K-15
D902	D-15	0306	K-15
D903	E-15	0401	G-3
D904	E-15	0447	F-5
D905	F-15	0450	E-3
D906	H-15	0501	A-5
D907	K-15	0502	A-8
D910	F-15	0503	D-6
D911	G-15	0504	D-6
D912	J-15	0505	D-8
D913	D-15	0507	C-8
		0508	B-8
		0701	D-15
IC201	H-14		
IC202	F-10		

LINE OUT
AUDIO
R



D
E
F
G
H
I
J
K
L

16 1 2 3 4 5 6 7 8 9 10 11 12 13 14




MA-140 BOARD

D301	K-14	0101	B-14
D302	K-14	0102	E-15
D304	K-15	0103	E-14
D400	D-4	0104	B-14
D401	C-3	0105	A-14
D402	C-3	0109	K-12
D403	E-1	0202	F-14
D404	E-1	0203	E-8
D405	F-2	0220	H-12
D406	F-2	0247	G-12
D450	D-3	0270	H-12
D451	E-3	0297	G-13
D452	E-4	0301	K-15
D502	B-8	0302	L-15
D505	A-5	0303	K-15
D506	A-11	0304	L-15
D901	B-14	0305	K-15
D902	D-15	0306	K-15
D903	E-15	0401	G-3
D904	E-15	0447	F-5
D905	F-15	0450	E-3
D906	H-15	0501	A-5
D907	K-15	0502	A-8
D910	F-15	0503	D-6
D911	G-15	0504	D-6
D912	J-15	0505	D-8
D913	D-15	0507	C-8
		0508	B-8
		0701	D-15
IC201	H-14		
IC202	F-10		
IC203	J-13		
IC204	I-13		
IC401	D-4		
IC402	B-2		
IC403	E-2		
IC404	G-7		
IC501	B-7		
IC502	D-7		
IC503	B-5		
IC701	E-12		
IC702	F-11		


IC

IC401 8-752-836-00 CXP80724-040Q

6 7 8 9 10 11 12 13 14 15



MA-140 BOARD (1/3)



• Signal path

	VIDEO Signal			AUDIO Signal
	CHROMA	Y	Y/CHROMA	
REC			➡➡➡	➡
PB			➡➡➡	➡

• Signal path

	REC	REC/PB	PB
Drum speed servo		➡	
Drum phase servo		➡➡	
Drum servo (speed and phase)		➡➡➡	
Capstan speed servo		➡	
Capstan servo (speed and phase)		➡➡	
Ref, signal	➡		➡


TO CG-15 BOARD CN602 (See page 99.)


TO MD-58 BOARD CN004 (See page 124.)

TO MD-58 BOARD CN007 (See page 124.)

TO DRUM MOTOR

TO ACE HEAD CTL





IC202 21P

1	AU RD OUT
2	AU RD IN
3	AU LJ OUT
4	AU GND
5	SW GND
6	AU LJ IN
7	BLUE
8	AV CONT
9	SW GND
10	N. C.
11	GREEN
12	N. C.
13	SW GND
14	SW GND
15	RED
16	T
17	SW GND
18	SW GND
19	Y IN
20	Y OUT
21	SW GND

EURO AV

B, NP, VC MODEL

CH17 13P


1	TU A RD OUT
2	TU A LJ OUT
3	AU GND
4	L1 A RD OUT
5	L1 A LJ OUT
6	AU GND
7	TUNER SEL
8	L3 A MUTE
9	SW GND
10	SW GND
11	UNSW 12V
12	I S16
13	RGB CONT

TO VI-116 BOARD CN505 (See page 91.)

CH18 8P VEL

1	LS A RD IN
2	LS A LJ IN
3	A GND
4	C+ BET
5	SW GND
6	BLUE
7	GREEN
8	RED

TO CN-62 BOARD CN102 (See page 94.)



SLV-825/B/NC/NP/UB/VC

MA-140 (NORMAL AUDIO REC/PB AMP), VP-33(SERVO/SYSTEM CONTROL MICROPROCESSOR) SCHEMATIC DIAGRAMS/ PRINTED WIRING BOARD

- Ref. No. MA-140 BOARD : 8,000 Series, VP-33 BOARD : 9,000 Series -

A
B
C
D
E
F
G
H
I
J


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

VP-33 BOARD (825VC ONLY)

CN650 10P



GNB (UNSW)	1
TU VIDED IN	2
VPS RESET	3
UNSW 5V	4
BACK UP 5V	5
SI BUS	6
SO BUS	7
S CLK	8
VPS CS	9
DATA VALID	10

TO MA-140 BOARD
CN921
(See page 112.)




16

MA-140 BOARD (3 / 3)



IC701

NORMAL AUDIO REC/PB AMP




VC, NP, B MODEL


IC702 M5201L

VP-33


MA-140 BOARD (3 / 3)



VC, NP, B MODEL
 AEP, UB, NC MODEL
 R721 820: UB, AE, NC MODEL
 4700: VC, NP, B MODEL



TO
(1/3)



VP-33 BOARD


IC651 K-3
IC652 J-3

IC



IC652 8-759-147-30 uPD75004GB-VSX182 (VC)

MA-140 (TUNER, IF STAGE AMP) SCHEMATIC DIAGRAM

— Ref. No. MA-140 BOARD : 8,000 Series —



AGRAM





• Signal path

	VIDEO Signal			AUDIO Signal
	CHROMA	Y	Y/CHROMA	
REC			➡➡➡	
PB				

MD-58 (MECHANISM SENSOR) SCHEMATIC DIAGRAM

- Ref. No. MD-58 BOARD : 10,000 Series -





CN003 5P

1	MODE4
2	MODE3
3	MODE1
4	MODE2
5	GND (UNSW)

TO CAM ENCODER

CN004 19P

1	T. SENS
2	S. SENS
3	END LE0
4	C-UP/DOWN
5	REC PRF
6	MODE4
7	MODE3
8	MODE2
9	MODE1
10	S. REEL
11	T. REEL
12	UNSWV
13	MTR 12V
14	GND (UNSW)
15	GND (UNSW)
16	CAM (+)
17	CAM (+)
18	COM
19	COM

TO MA-140 BOARD CN909 (See page 112.)

CN005 3P EL2.0** 1

1	LOAD (-)
2	LOAD (+)
3	LOAD (-)

TO LOADING MOTOR

CN006 3P B-B 2.0**

1	CAM (-)
2	N.C
3	CAM (+)

TO CAM MOTOR

CN007 11P B-B 1.25**

1	LOAD (+)
2	MTR 12V
3	GND (MTR)
4	GND (MTR)
5	C. VS
6	CAP. RVS
7	BRK
8	CAP FG
9	LIMITER
10	GND (SW)
11	SW 5V

TO MA-140 BOARD CN911 (See page 112.)

MD-58 (MECHANISM SENSOR) PRINTED WIRING BOARD

- Ref. No. MD-58 BOARD : 10,000 Series -


MD-58 BOARD

- D001 D-5
- D004 D-2
- D005 D-9
- D006 F-6
- D007 F-5

- IC002 A-5

- PH001 F-6
- PH002 F-5

- Q001 C-1
- Q002 C-9



SLV-825/B/NC/NP/UB/VC


HF-26 (HI-FI AUDIO) PRINTED WIRING BOARD

- Ref. No. HF-26 BOARD : 17,000 Series -

HF-26 BOARD

D201	D-3
IC201	B-5
IC202	C-1
IC203	B-2
IC204	B-1
IC205	D-2

HF-26 BOARD





DIODE		IC	
D201	8-719-104-34 1S2836	IC201	8-759-057-63 AN3937NFBP
		IC202	8-759-946-44 TK15120M
		IC203	8-759-924-46 BA4560F
		IC204	8-759-946-44 TK15120M

HF-26 (HI-FI AUDIO) SCHEMATIC DIAGRAM

- Ref. No. HF-26 BOARD : 17,000 Series -

HF-26 BOARD





CN201 20P

1	MOD A OUT
2	GND (AU)
3	NOR A OUT
4	LEVEL VR (L)
5	LINE IN (L)
6	GND (AU)
7	LINE OUT (L)
8	H.P. OUT (L)
9	GND (AU)
10	UNSW 5.8V
11	SW 12V
12	GND (AU)
13	H.P. VR
14	H.P. OUT (R)
15	LINE OUT (R)
16	GND (AU)
17	LINE IN (R)
18	LEVEL VR (R)
19	LEVEL VR V _{CC}
20	A MUTE

TO
MA-140 BOARD
CN908
(See page 113.)


CN202 14P

1	N.C
2	PAL60
3	MONI (R)
4	MONI (L)
5	AF SW PLS
6	AF PB
7	SP
8	GND
9	AF PB RF
10	GND
11	AF REC RF
12	AF ENV

TO
MA-140 BOARD
CN907
(See page 113.)

IC205
REG.


E
F
G
H
I
J
K
L
M
N



• Signal path

	VIDEO Signal			AUDIO Signal
	CHROMA	Y	Y/CHROMA	
REC				➔
PB				↺

16



9	GND (AU)
10	UNSW 5.8V
11	SW 12V
12	GND (AU)
13	H.P. VR
14	H.P. OUT (R)
15	LINE OUT (R)
16	GND (AU)
17	LINE IN (R)
18	LEVEL VR (R)
19	LEVEL VR V CC
20	A MUTE


TO
MA-140 BOARD
CN908
(See page 113.)

CN202 14P	
1	N.C
2	PAL60
3	MONI (R)
4	MONI (L)
5	AF SW PLS
6	AF PB
7	SP
8	GND
9	AF PB RF
10	GND
11	AF REC RF
12	AF ENV
13	AF MIX
14	RF MONI





TO
MA-140 BOARD
CN907
(See page 113.)

MF-168/MF-169/MF-170 (FRONT PANEL), TK-17/TK-18 (RELAY) SCHEMATIC DIAGRAMS


- Ref. No. MF-168 BOARD : 11,000 Series, MF-169 BOARD : 12,000 Series, MF-170 BOARD : 13,000 Series,
TK-17 BOARD : 14,000 Series, TK-18 BOARD : 15,000 Series -



Series,



M
T
G
H
-
C
K
L
M
N



CN204	1	HEADPHONE L
	2	AUDIO GND
	3	HEADPHONE R
	4	MIC GND
	5	MIC
	6	LINE2 L
	7	AUDIO GND
	8	LINE2 R

TO MA-140 BOARD
CN926
(See page 114.)

CN605	16	MIC SW
	15	LANC I/O
	14	SW 9V
	13	SW 9V
	12	HEADPHONE LEVEL
	11	SW 5V
	10	SHARPNESS
	9	UNSW GND
	8	UNSW GND
	7	SECAM

TO MF-167 BOARD
CN605
(See page 139.)

EXCEPT UB MODEL

CN203	11	CASSETTE IN LED
	10	REC LED
	9	PLAY LED
	8	PAUSE LED
	7	JOB 0
	6	JOB 1
	5	A/B 4
	4	UNSW GND
	3	UNSW 5V
	2	FP ON
	1	SIRCS (LTD)

CN250	11	CASSETTE IN LED
	10	REC LED
	9	PLAY LED
	8	PAUSE LED
	7	JOB 0
	6	JOB 1
	5	A/B 4
	4	UNSW GND
	3	UNSW 5V
	2	FP ON
	1	SIRCS (LTD)

TK-18 BOARD


CN251	1	CASSETTE IN LED
	2	REC LED
	3	PLAY LED
	4	PAUSE LED
	5	JOB 0
	6	JOB 1
	7	A/B 4
	8	UNSW GND
	9	UNSW 5V
	10	UNSW 5V
	11	UNSW 5V
	12	SIRCS (LTD)

TO CONTROL SWITCH BLOCK CN2
(See page 143.)

CN202	10	HEADPHONE L
	9	AUDIO GND
	8	HEADPHONE R
	7	AUDIO GND
	6	LINE2 L
	5	AUDIO GND
	4	LINE2 R
	3	AUDIO GND
	2	MIC GND
	1	MIC (ORG)

CN301	10	HEADPHONE L
	9	AUDIO GND
	8	HEADPHONE R
	7	AUDIO GND
	6	LINE2 L
	5	AUDIO GND
	4	LINE2 R
	3	AUDIO GND
	2	MIC GND
	1	MIC (ORG)

MF-170 BOARD




CN302	1	UNSW GND
	2	LANC I/O
	3	UNSW GND
	4	MIC SW
	5	SW 9V
	6	AUDIO GND

CN303	1	LINE2 V
	2	N.C
	3	SW GND

TO VI-116 BOARD
CN507
(See page 91.)

MF-169 BOARD




MF-168/MF-169/MF-170 (FRONT PANEL), TK-17/TK-18 (RELAY) PRINTED WIRING BOARDS

- Ref. No. MF-168 BOARD : 11,000 Series, MF-169 BOARD : 12,000 Series, MF-170 BOARD : 13,000 Series,
TK-17 BOARD : 14,000 Series, TK-18 BOARD : 15,000 Series -


MF-168 BOARD

D01	A-9
D02	A-9
I201	D-3
I202	C-9
Q01	C-9
Q02	B-9
Q03	D-6
Q04	D-6
Q40	D-2


TK-17 BOARD



TK-18 BOARD




MF-168 BOARD




MF-170 BOARD

D301	A-8
D302	A-8
D303	A-5
D321	A-1
Q322	A-2

MF-170 BOARD



MF-169 BOARD



IC

IC201	8-759-923-90	BA4560 (EXCEPT UB)
IC201	8-759-924-46	BA4560F (UK)
IC202	8-759-032-32	MC74HC132AF

TRANSISTOR

Q201	8-729-230-49	2SC2712-G (UB)
Q202	8-729-421-19	UN2213 (UB)
Q203	8-729-140-75	2SD999-CLCK (EXCEPT UB)
Q204	8-729-140-75	2SD999-CLCK (EXCEPT UB)
Q240	8-729-230-49	2SC2712-G (UB)

TRANSISTOR

Q321	8-729-140-75	2SD999-CLCK (UB)
Q322	8-729-140-75	2SD999-CLCK (UB)

MF-169 BOARD

Q401	B-1
Q402	B-1

TRANSISTOR


Q401	8-729-421-19	UN2213-TX(B)
Q402	8-729-421-19	UN2213-TX(B)

SLV-825/B/NC/NP/UB/VC

MF-167 (DISPLAY PANEL) PRINTED WIRING BOARD

- Ref. No. MF-167 BOARD : 16,000 Series -

MF-167 BOARD



MF-167 BOARD

D601	D-7	IC601	C-5
D602	C-10	IC602	D-9
D603	C-9	IC603	B-5
D604	C-10	IC604	D-8
D605	C-10	IC605	D-3
D610	A-3		
D611	A-3	Q601	A-4
D612	C-7	Q602	A-3
D613	B-1	Q603	B-1
D614	D-7	Q604	D-7
D615	B-2	Q605	B-2
D616	C-4	Q606	B-2
D617	C-3	Q608	B-11
D618	C-3		
D619	C-3		
D620	C-3		

IC

IC601	8-759-078-00	MB89796B-VSX1760	(AEP/UB/NC/NP)
IC601	8-759-094-10	MB89796B-104	(VC)

MF-167 (DISPLAY PANEL) SCHEMATIC DIAGRAM

- Ref. No. MF-167 BOARD : 16,000 Series -

1 2 3 4 5 6 7 8 9 10 11 12


A
B
C
D
E
F
G
H
I
J

MF-167 BOARD

LCD601

IC603 IC604
RESET POWER FAIL

MF-167 BOARD



TO MF-168 BOARD
CN201
(See page 133.)


TO MF-169 BOARD
CN402
(See page 134.)

CN604 14P

1	SIRCS (F.P)
2	SIRCS
3	JOG 1
4	JOG 0
5	PAUSE LEB
6	PLAY LEB
7	REC LEB
8	CASSETTE IN LEB
9	A/B
10	SW SV
11	UNSW SV
12	SW SV
13	UNSW GND
14	UNSW GND

CN605

16	MIC SW
15	LANC I/O
14	SW SV
13	SW SV
12	HEADPHONE LEVEL
11	SW SV
10	SHARPNESS
9	UNSW GND
8	UNSW GND
7	SECAM
6	SW GND
5	MESECAM
4	A/B




GRAM


4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19

7 BOARD

LCD601



IC603 RESET
IC604 POWER FAIL
IC605 SIRCS




TO MA-140 BOARD
 CN904
 (See page 112)

TO MA-140 BOARD
 CN905
 (See page 112)

TO TK-17 BOARD
 CN150
 (See page 134.)



E
F
G
H
I
J
K
L
M
N

MF-167 BOARD



TO MF-168 BOARD
CN201
(See page 133.)

TO MF-169 BOARD
CN402
(See page 134.)





	JW601	JW602	JW603	R655	R654	R653	JW620	JW621
UB	○	○	○	○	○	○	○	○
AEP	○	○	○	○	○	○	○	○
VC	○	○	○	○	○	○	○	○
NC	○	○	○	○	○	○	○	○
NP	○	○	○	○	○	○	○	○
B	○	○	○	○	○	○	○	○

○: MOUNT

TC-27 (TRANSCODER) SCHEMATIC DIAGRAM (B Model)



- Ref. No. TC-27 BOARD : 18,000 Series -







IC106
OUTPUT SELECTOR



IC103
SECAM ENCODER



IC105
SECAM ENCODER




R	2 1 0	1-215-425-00	1.5K	
R	2 1 1	FOR ADJUSTMENT		
R	2 1 2	"		
R	2 1 3	"		
R	2 1 4	1-249-429-11	10K 1/4W	
R	2 1 5	1-219-149-11	FUSE RESISTOR	1 Ω 1/4W
R	2 1 6	1-219-112-11	"	10 Ω 1/4W
R	2 1 7	"	"	
D	1 0 1	8-719-510-06	S1WA60	
D	1 0 2	8-719-304-63	RM11C	(ORIGINAL ERA15-06)
D	1 0 3	8-719-948-45	ERA22-08	
D	1 0 4	8-719-200-02	10E-2	
D	1 0 5	8-719-912-20	ISS120	(ORIGINAL MA165)
D	1 0 6	8-719-109-63	RD3, GES-B2	
Q	1 0 1	8-729-204-04	2SC3559	(ORIGINAL 2SC4231)
Q	1 0 2	8-729-265-52	2SC2655	(" 2SC3377)
PC	1 0 1	9-903-923-01	GN3171	
Q	2 0 1	8-729-140-93	2SB733-34	
D	2 0 1	8-719-313-16	AU02A	(ORIGINAL ERA18-02)
D	2 0 2	8-719-114-82	RD16JSB1	
D	2 0 3	8-719-920-67	ERC91-02	
D	2 0 4	"	"	
D	2 0 5	8-719-981-00	ERC81-004	
D	2 0 6	"	"	
D	2 0 7	8-719-313-16	AU02A	
D	2 0 8	8-719-980-78	ERA83-006	(ORIGINAL ERA83-004)
D	2 0 9	8-719-110-88	RD392S-B	(" MA4890)
SCR	2 0 1	8-719-104-17	ZP5M	(ORIGINAL 2P4M 500V \rightarrow 600V)
IC	2 0 1	NOTHING	PQ12RF13	(PQ12RF11 9-902-066-01)
IC	2 0 2	8-759-632-07	M5227L	
IC	2 0 3	9-902-066-01	PQ12RF11	
IC	2 0 4	8-749-920-43	S1S050CA	(S1-3050CA)
IC	2 0 5	8-759-420-19	AN1431T	(ORIGINAL HA17431P)
L	1 8 1	1-421-915-11	CHALK COIL	
L	2 0 1	9-998-937-01	" 10 μ F	
AC	INLET	1-540-054-11	AC INLET	
T	1 0 1	NO SUBSTITUTION	(SWITCHING TRANS)	



TC-27 (TRANSCODER) PRINTED WIRING BOARD (B Model)

— Ref. No. TC-27 BOARD : 18,000 Series —




- TC-27 BOARD**
- | | |
|-------|-----|
| D101 | F-1 |
| IC101 | E-4 |
| IC102 | C-2 |
| IC103 | A-2 |
| IC104 | C-4 |
| IC105 | B-4 |
| IC106 | E-4 |
| IC107 | E-1 |
| Q101 | F-3 |
| Q102 | C-2 |
| Q103 | C-3 |
| Q104 | B-5 |
| Q105 | B-5 |
| Q107 | A-5 |
| Q109 | B-3 |
| Q110 | D-4 |
| Q111 | D-2 |
| Q112 | E-3 |
| Q113 | E-4 |
| Q114 | E-3 |
| Q115 | E-2 |
| Q116 | F-2 |
| Q117 | A-2 |
| Q118 | F-4 |
| Q119 | E-5 |
| Q120 | E-5 |
| Q121 | A-4 |
| Q122 | F-1 |
| Q123 | F-1 |
| Q124 | F-1 |
| Q125 | E-2 |

- DIODE
- | | |
|------|----------------------|
| D101 | 8-719-400-18 MA152WK |
|------|----------------------|
- IC
- | | |
|-------|------------------------|
| IC101 | 8-759-941-68 BA7131F |
| IC102 | 8-752-035-00 CXA1227Q |
| IC103 | 8-752-034-04 CXA1219M |
| IC104 | 8-752-035-00 CXA1227Q |
| IC105 | 8-752-034-04 CXA1219M |
| IC106 | 8-759-710-29 NJM2235M |
| IC107 | 8-759-008-67 MC14066BF |

- TRANSISTOR
- | | |
|------|--------------------------|
| Q101 | 8-729-216-22 2SA1162 |
| Q102 | 8-729-920-74 2SC2412K-QR |
| Q103 | 8-729-920-74 2SC2412K-QR |
| Q104 | 8-729-920-74 2SC2412K-QR |
| Q105 | 8-729-920-74 2SC2412K-QR |
| Q107 | 8-729-920-74 2SC2412K-QR |
| Q109 | 8-729-920-74 2SC2412K-QR |
| Q110 | 8-729-920-74 2SC2412K-QR |
| Q111 | 8-729-920-74 2SC2412K-QR |
| Q112 | 8-729-920-74 2SC2412K-QR |
| Q113 | 8-729-920-74 2SC2412K-QR |
| Q114 | 8-729-920-74 2SC2412K-QR |
| Q115 | 8-729-920-74 2SC2412K-QR |
| Q116 | 8-729-216-22 2SA1162 |
| Q117 | 8-729-920-74 2SC2412K-QR |
| Q118 | 8-729-216-22 2SA1162 |
| Q119 | 8-729-920-74 2SC2412K-QR |
| Q120 | 8-729-216-22 2SA1162 |
| Q121 | 8-729-920-74 2SC2412K-QR |
| Q122 | 8-729-901-01 DTC144EX |
| Q123 | 8-729-920-74 2SC2412K-QR |
| Q124 | 8-729-216-22 2SA1162 |
| Q125 | 8-729-901-01 DTC144EX |


SWITCH BLOCK



TO
TK-18 BOARD
CN251
(See page 132.)






	S1	S2	S3	S4	S5	S6	SA
A/00	EJECT	STOP	PLAY	REC	EBIT STANDBY	SYNCHRO EBIT	SHUTTLE A
A/01	EBIT MONITOR	H.S. REW	FF	REW	PAUSE		SHUTTLE B
A/02	INPUT SELECT	TAPE SPEED	EBIT ON/OFF	TIMER REC	QUICK TIMER	TV/VTR	SHUTTLE C
A/03	S19	S20	S21	S22	S23	S24	S0
A/04	CH+	CH-		REMOTE	AUTO TRACKING	MANUAL TRACK+	SHUTTLE B
	S25	S26	S27	S28	S29	S30	S31
		VPS ON/OFF	COUNTER RESET	MANUAL TRACK-			

SWITCH BLOCK




	S1	S2	S3	S4	S5	S6	SA
A/B0	EJECT	STOP	PLAY	REC	EDIT STANDBY	SYNCHRO EDIT	SHUTTLE A
A/B1	EDIT MONITOR	H.S. REW	FF	REW	PAUSE		SHUTTLE B
A/B2	INPUT SELECT	TAPE SPEED	EDIT ON/OFF	TIMER REC	QUICK TIMER	TV/VTR	SHUTTLE C
A/B3	CH+	CH-		REMOTE	AUTO TRACKING	MANUAL TRACK+	SHUTTLE D
A/B4	S25	S26	S27	S28	S29	S30	S31
	VPS	COUNTER ON/OFF	COUNTER RESET	MANUAL TRACK-			




















4-3. SEMICONDUCTORS




BA4560F
BA4558F
MM1148XFF
MM1149XF
TK15120M




BA6138
BA7021
LVA519S
MM1053XS





DTA114EK
DTA143EK
DTC114EK
DTC124EK
DTC144EK
UN2113
UN2213
2SA1052-C
2SA1162
2SB709A-R
2SC1623-L5L6
2SC2412K-QR
2SC2712-G
2SC3142-J4
2SD601A-FR




DTA144ES
DTC114ES



DTC144ES
UN411L
2SA1309A-R
2SC2785-HFE




KSA708
KSC1008



2SC1509

2SD655-E


2SB1000A-L
2SD999-CLCK
2SD1005-BV









RD13ES-B2

cathode
anode


RD33ES-B2
RD33ES-T2B
RD4.3ES-T2B
RD4.7ES-T2B
RD6.2ES-B2
RD6.8ES-B2
RD8.2ES-B2
11ES2
1SS119



RD9.1E-W



4-4. INDIC



• Interconnection of elect

Lead No.	1	2
Interconnected electrodes	F	F
	(+)	(+)
Lead No.	28	29
Interconnected electrodes	NP	NC

• Anode connection


	13G
S0	dB ₀₀ ~+10 R III
S1	t1
S2	t2
S3	t3
S4	t4
S5	t5
S6	t6
S7	t7
S8	t8
S9	t9
S10	t10
S11	t11
S12	t12
S13	t13
S14	t14
S15	t15
S16	t16

SLV-725 ~~REP~~ FEP/B/NC

SONY

SCALE FOR MICROFILM

SONY STANDARD
P-101-00-04 '81.4
PH-11



symbol	min.	typ.	max.
*R111	2.2K	OPEN	OPEN
*R206	33K	OPEN	OPEN
*R207	10K	16K	OPEN
*R211	47K	82K	OPEN
*R212	47K	OPEN	OPEN
*R213	220	350	550

- | | | | | | |
|-------|-------------------|------|-----------------------------|--------|--------------------|
| D101 | SIHBAE8 | D201 | 2SB733 or 2SA934 or 2SB1434 | SCR201 | 2P4M |
| D102 | ERA15-05 or AN01A | D202 | AL022 or ERA18-02 | IC201 | PO1 ZRF13 |
| D103 | ERA22-03 or EG01C | D203 | RO16J5B or MA415B | IC202 | MS237L |
| D104 | ERA15-02 or 11ES2 | D204 | SL28U or ERC91-02 or RL4Z | IC203 | PO99RF11 |
| D105 | MA165 | D205 | D3S4M or RX44 or ERCB1-004 | IC204 | SI-3050CA |
| D106 | RO3.BES or MA403B | D206 | AK04 or ERA03-004 | IC205 | HA17431 or AN1431T |
| Q101 | 2SC4231 | D208 | RO39ES or MA439B | | |
| Q102 | 2SC3377 | | | | |
| PC101 | ON3171 | | | | |

BT	1/4W (RESISTANCE)
DFN	1/4W (POWER)

CN1

1	DC	+35V
2	SW	GND
3	UNSW	12V
4	SW	9V
5	UNSW	6V
6	SW	5V
7	SW	GND
8	AU	GND


CN2

1	MTR	12V
2	MTR	12V
3	MTR	GND
4	MTR	GND
5	POWER	ON
6	SW	GND
7	SW	5V
8	UNSW	GND
9	UNSW	6V
10	DC	-3BV
11	DC	6V
12	DC	0V

UNIT	TOLERANCE	USED ON	RANK
mm			
ANGLE			FAMILY
3rd			
SCALE		ORIGINAL MODEL	VSX-1761
		MATERIAL (COLOR)	FRESH (COLOR)
		DESCRIPTION	
		(2)	
HISTORY	SUFFIX	ECN	REVISION
Y	COL	NO	SIGN.
DRAWN BY	PLANNED BY	CHECKED BY	APPROVED BY
MODEL	VSX-1761		
PART NO.			
0-479-456-01			
SR-425 回路图		PART NO.	
SB-D1594			
1-413-756-11			
		SHEET	10

UPC POWER BLOCK

4-4. INDICATOR TUBE, FLUORESCENT DESCRIPTION




• Interconnection of electrodes

Lead No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27
Interconnected electrodes (+)	F	F	NP	13G	12G	11G	50	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	S13	S14	S15	S16	10G	NP	NP	9G
Lead No.	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54
Interconnected electrodes (-)	NP	NC	NC	NC	8G	NC	NC	NC	7G	NC	6G	NC	5G	NC	4G	NC	3G	NC	NC	NC	2G	NC	1G	F	F	F	F


• Anode connection

	13G	12G	11G	10G	9G	8G	7G	6G	5G	4G	3G	2G	1G
S0	dB∞ ~+10 RII	L III											
S1	t1	t1	STEREO	LP	EDIT	PM(Bottom)	d2	d2	d2	d2	LINE	d2	d2
S2	t2	t2	<(Left)	b2 c2	a2	AM(Bottom)	a2	a2	a2	a2	SIMUL	a2	a2
S3	t3	t3	<(Center)	VPS	c2	OFF	c2	c2	c2	c2	TUNER	c2	c2
S4	t4	t4	<(Right)	SCAN	INDEX	REC	a2	a2	a2	a2		a2	a2
S5	t5	t5	<(Left)	INDEX	TIMER		f2	f2	f2	f2		f2	f2
S6	t6	t6t	MAIN/	SP	b2		b2	b2	b2	b2	I b2 I c2	b2	b2
S7	t7	t7	L	□	a2, d2		a2	a2	a2	a2	S	a2	a2
S8	t8	t8	>(Right)		d1, d2		d1	d1	col 4	d1	Y	d1	BS
S9	t9	t9	>(Left)	d1	d1		d1	d1	col 3	d1	d1	d1	CATV
S10	t10	t10	SUB/	e1	e1	PM(Upper)	e1	e1	col 2	e1	e1	e1	AUTO
S11	t11	t11	R	e1	e1	H	e1	e1	M(Bottom)	e1	e1	e1	
S12	t12	t12	NICAM	g1	g1	AM(Upper)	g1	g1	col 1	g1	g1	g1	
S13	t13	t13	>(Center)	f1	f1	DM	f1	f1	col 1	f1	f1	f1	
S14	t14	t14	>(Right)	b1	b1	D	b1	b1	M(Upper)	b1	b1	b1	PAL
S15	t15	t15	○	a1	a1	Su	a1	a1	Th	a1	a1	a1	SECAM
S16	t16	t16		EP	VTR	EVERY WEEK	Mo	Tu	We	Fr	Sa	ME	

PST572C
PST572H
PST572K-T




TDA8415




Top view

IDA5642
PC324C




TOP VIEW


04GB-VSX182




3GC-VSX1760




DTA114EK
DTA143EK
DTC114EK
DTC124EK
DTC144EK
UN2113
UN2213
2SA1052-C
2SA1162
2SB709A-R
2SC1623-L5L6
2SC2412K-QR
2SC2712-G
2SC3142-J4
2SD601A-R





DTA144ES
DTC114ES




DTC144ES
UN411L
2SA1309A-R
2SC2785-HFE




FMS1




KSA708
KSC1008




PT483F1S




2SC1509





2SD655-E




2SB1000A-L
2SD999-CLCK
2SD1005-BV




MA152WK




RD13ES-B2





RD33ES-B2
RD33ES-T2B
RD4.3ES-T2B
RD4.7ES-T2B
RD6.2ES-B2
RD6.8ES-B2
RD8.2ES-B2
11ES2
1SS119




RD9.1E-W




1S2836




BRPG5014X-K




GL451VS1




PY5504S-1



SLR34DC3
SLR-34UC3



SLR34MC3
SLR34VC3



SECTION 5 EXPLODED VIEWS


NOTE:

- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.


Les composants identifiés par une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

5-1. FRONT PANEL AND CABINET ASSEMBLIES



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
1	1-466-749-11	SWITCH BLOCK, CONTROL (AEP/B/NC/NP)		* 14	3-948-032-01	LABEL, MODEL NUMBER (NO. 2) (AEP)	
1	1-466-749-21	SWITCH BLOCK, CONTROL (VC)		* 14	3-948-035-01	LABEL, MODEL NUMBER (NO. 2) (B)	
1	1-466-749-51	SWITCH BLOCK, CONTROL (UB)		* 14	3-948-033-01	LABEL, MODEL NUMBER (NO. 2) (UB)	
2	X-3941-675-1	DOOR ASSY (AEP/VC:BLACK)		* 14	3-948-034-01	LABEL, MODEL NUMBER (NO. 2) (VC)	
2	X-3941-732-1	DOOR ASSY (NC/NP)		* 14	3-948-036-01	LABEL, MODEL NUMBER (NO. 2) (NC)	
2	X-3942-187-1	DOOR ASSY (VC:GOLD)		* 14	3-948-037-01	LABEL, MODEL NUMBER (NO. 2) (NP)	
2	X-3941-886-1	DOOR ASSY (B)		15	1-693-178-11	REMOTE COMMANDER (RMT-V127)	
2	X-3941-966-1	DOOR ASSY (UB)		16	X-3942-161-1	WOOD (R) ASSY, SIDE (VC:GOLD)	
3	3-948-155-01	KNOB, REC VOL (VC:BLACK)		16	X-3941-671-1	PANEL (R) ASSY, SIDE (EXCEPT VC:GOLD)	
3	3-948-155-11	KNOB, REC VOL (VC:GOLD)		* 17	3-944-553-21	COVER, UPPER (VC:GOLD)	
4	X-3941-674-1	PANEL ASSY, FRONT (AEP/VC:BLACK)		17	3-944-553-01	COVER, UPPER (UB)	
4	X-3941-731-1	PANEL ASSY, FRONT (NC/NP)		17	3-944-553-11	COVER, UPPER (AEP/B/NC/NP/VC:BLACK)	
4	X-3941-965-1	PANEL ASSY, FRONT (UB)		18	X-3942-162-1	WOOD (L) ASSY, SIDE (VC:GOLD)	
4	X-3942-186-1	PANEL ASSY, FRONT (VC:GOLD)		18	X-3941-673-1	PANEL (L) ASSY, SIDE (EXCEPT VC:GOLD)	
4	X-3941-733-1	PANEL ASSY, FRONT (B)		19	3-743-601-01	SCREW, SIDE WOOD	
5	X-3941-677-1	PLATE (R) ASSY, FULCRUM		20	3-712-786-21	DUMPER, OIL	
* 6	3-743-640-01	RETAINER, PC BOARD		21	X-3941-676-1	PLATE (L) ASSY, FULCRUM	
7	4-921-277-11	SCREW (B2, 6X8), TAPPING, BIND		22	3-948-151-01	GEAR (B), MIDWAY	
* 8	1-644-856-11	TK-17 BOARD		* 23	4-911-047-01	VIBRATION CONTROL (D)	
* 9	1-644-857-11	TK-18 BOARD		25	4-923-836-11	CUSHION	
10	3-948-122-01	FOOT (BASE)		26	3-951-155-01	DOOR	
11	X-3941-672-1	FOOT ASSY (FRONT) (AEP/B/NC/NP/VC:BLACK)		27	3-744-080-01	COVER, BATTERY	
11	X-3941-967-1	FOOT ASSY (FRONT) (UB/VC:GOLD)		28	3-744-078-01	RING, SHUTTLE	
12	X-4924-422-1	FOOT ASSY		29	3-744-077-01	KNOB, SHUTTLE	
* 13	3-944-552-01	PLATE, BOTTOM		30	3-710-901-11	SCREW, TAPPING	
* 13	X-3942-063-1	PLATE ASSY, BOTTOM (B)					

5-2. POWER SUPPLY BLOCK ASSEMBLY




Ref. No.	Part No.	Description	Remarks
51	3-948-152-01	KNOB, SLIDE (NTSC PB ON PAL TV)	
52	3-743-636-21	KNOB, SLIDE (COMMAND MODE)	
* 53	A-6755-463-A	MF-169 BOARD, COMPLETE (AEP/NC/NP/VC)	
* 53	A-6755-667-A	MF-169 BOARD, COMPLETE (UB)	
* 53	A-6755-811-A	MF-169 BOARD, COMPLETE (B)	
* 54	A-6755-467-A	MF-170 BOARD, COMPLETE (AEP/B/NC/NP/VC)	
* 54	A-6755-668-A	MF-170 BOARD, COMPLETE (UB)	
* 55	3-948-133-01	BRACKET (R), GROUND	
* 56	3-948-156-01	HOLDER, PWB	
* 57	3-948-134-01	BRACKET (L), GROUND	
* 58	3-948-157-01	HOLDER, FL	
* 59	A-6721-466-A	MF-167 BOARD, COMPLETE (AEP)	
* 59	A-6721-476-A	MF-167 BOARD, COMPLETE (NC)	
* 59	A-6721-477-A	MF-167 BOARD, COMPLETE (NP)	
* 59	A-6721-479-A	MF-167 BOARD, COMPLETE (VC)	
* 59	A-6721-499-A	MF-167 BOARD, COMPLETE (UB)	
* 59	A-6721-513-A	MF-167 BOARD, COMPLETE (B)	
* 60	A-6755-466-A	MF-168 BOARD, COMPLETE (AEP/B/NC/NP/VC)	
* 60	A-6755-660-A	MF-168 BOARD, COMPLETE (UB)	
61	3-741-948-11	SCREW (3), SPECIAL (+) TAPPING	

Ref. No.	Part No.	Description	Remarks
* 62	3-944-614-01	PLATE, GROUND, JK	
* 63	3-944-613-01	PLATE, GROUND, MF	
* 65	3-946-136-11	COVER (S), REAR	
△66	1-413-756-11	POWER BLOCK (SR-425) (AEP/B/E/NC/NP)	
△66	1-413-757-11	POWER BLOCK (SR-426) (UB)	
△66	1-413-758-11	POWER BLOCK (SR-427) (VC)	
* 67	A-6727-417-A	RP-147 BOARD, COMPLETE (AEP/NC/NP/VC)	
* 67	A-6727-459-A	RP-147 BOARD, COMPLETE (UB)	
* 67	A-6727-467-A	RP-147 BOARD, COMPLETE (B)	
68	3-736-055-01	SCREW (3X8), TAPPING	
* 69	3-350-683-01	CUSHION (LED), RUBBER	
70	1-696-439-11	WIRE, FLAT TYPE (10 CORE)	
71	1-696-440-11	WIRE, FLAT TYPE (16 CORE)	
* 72	A-6721-515-A	TC-27 BOARD COMPLETE (B)	
LCD601	1-519-507-41	INDICATOR TUBE, FLUORESCENT	

Note:
The components identified by mark **△** or dotted line with mark **△** are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque **△** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

5-3. MAIN BOARDS ASSEMBLY




Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
* 101	3-945-137-01	STOPPER (L), UPPER COVER		* 117	A-6755-812-A	VI-116 BOARD, COMPLETE (B)	
* 102	3-741-992-01	STOPPER, UPPER CASE		* 118	A-6755-468-A	CN-62 BOARD, COMPLETE (AEP/NC/E)	
103	3-703-150-11	STOPPER, WIRING		* 118	A-6755-568-A	CN-62 BOARD, COMPLETE (B/NP/VC)	
105	3-682-057-11	SPACER (SMALL)		* 118	A-6755-669-A	CN-62 BOARD, COMPLETE (UB)	
* 106	A-6755-563-A	VP-33 BOARD, COMPLETE (VC)		* 119	3-948-132-01	PLATE, ORNAMENTAL, JACK (AEP/UK/NC/E)	
* 106	A-6755-799-A	VP-33 BOARD, COMPLETE (B/NC/E)		119	3-948-132-31	PLATE, ORNAMENTAL, JACK (B)	
* 107	A-6756-465-A	MA-140 BOARD, COMPLETE (AEP)		119	3-948-132-11	PLATE, ORNAMENTAL, JACK (VC)	
* 107	A-6756-560-A	MA-140 BOARD, COMPLETE (NC/E)		119	3-948-132-21	PLATE, ORNAMENTAL, JACK (NP)	
* 107	A-6756-561-A	MA-140 BOARD, COMPLETE (NP)		121	3-736-704-01	HINGE, PC BOARD	
* 107	A-6756-564-A	MA-140 BOARD, COMPLETE (YC)		* 122	A-6727-418-A	YC-124 BOARD, COMPLETE (AEP/NC/NP)	
* 107	A-6756-661-A	MA-140 BOARD, COMPLETE (UB)		* 122	A-6727-465-A	YC-124 BOARD, COMPLETE (B)	
* 107	A-6756-813-A	MA-140 BOARD, COMPLETE (B)		* 122	A-6727-442-A	YC-124 BOARD, COMPLETE (VC)	
* 111	3-741-962-01	PLATE, GROUND, JMP		* 122	A-6727-456-A	YC-124 BOARD, COMPLETE (UB)	
* 111	A-6721-475-A	HF-26 BOARD, COMPLETE (AEP/B/NC/NP/VC)		* 123	3-948-127-01	HOLDER, HF	
* 112	A-6721-502-A	HF-26 BOARD, COMPLETE (UB)		124	1-696-438-11	WIRE, FLAT TYPE (13 CORE) (B/NP/VC)	
* 113	A-6721-481-A	CG-15 BOARD, COMPLETE (B/VC)		△IF501	1-466-539-11	IF BLOCK (IFZ-389ST) (AEP/VC)	
* 113	A-6756-559-A	CG-15 BOARD, COMPLETE (AEP/NC/NP/E)		△IF501	1-466-540-11	IF BLOCK (IFZ-389FE) (B)	
* 113	A-6756-671-A	CG-15 BOARD, COMPLETE (UB)		△IF501	1-466-541-11	IF BLOCK (IFZ-395NC) (UB)	
* 114	1-637-536-21	D1-43 BOARD		△IF501	1-466-538-11	IF BLOCK (IFZ-389NC) (NC/NP/E)	
* 115	A-6727-419-A	DG-11 BOARD, COMPLETE (AEP/B/NC/NP/VC)		△RF501	1-466-328-11	MODULATOR, RF (RFU-2017) (AEP/NC/NP/VC)	
* 115	A-6727-458-A	DG-11 BOARD, COMPLETE (UB)		△RF501	1-466-347-11	MODULATOR, RF (RFU-2024) (UB)	
* 116	3-948-126-01	HOLDER, DG		△RF501	1-466-348-11	MODULATOR, RF (RFU-2023) (B)	
* 117	A-6755-469-A	VI-116 BOARD, COMPLETE (AEP/NC/E)		△TU501	1-465-260-11	TUNER, ET (BTP-2C401) (AEP/NC/NP/VC)	
* 117	A-6755-569-A	VI-116 BOARD, COMPLETE (NP/VC)		△TU501	1-465-262-11	TUNER, ET (UB)	
* 117	A-6755-670-A	VI-116 BOARD, COMPLETE (UB)					

Note:
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.


Note:
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

5-4. FL CASSETTE COMPARTMENT ASSEMBLY




<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
151	3-945-199-11	DOOR, FL (BLACK)		157	3-736-100-01	GEAR (FL), WORM	
151	3-945-199-41	DOOR, FL (VC:GOLD)		158	X-3727-784-1	MOTOR ASSY (M904)	
152	A-6751-453-A	FL BLOCK ASSY		159	3-738-285-01	SPRING, TENSION	
153	3-736-163-01	LEVER, ERASING PROTECTION		160	3-716-144-02	RETAINER, WORM	
154	3-736-167-01	ARM, DOOR SWITCHING		161	X-3727-775-2	GEAR (RIGHT) ASSY, MIDWAY	
155	3-696-510-01	WASHER (3), STOPPER		163	3-736-044-02	GEAR (LEFT), MIDWAY	
156	3-736-164-01	WHEEL (FL), WORM					

5-5. MECHANISM CHASSIS ASSEMBLY (1)




<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
201	3-701-438-11	WASHER, 2.5		213	X-3942-218-1	ARM ASSY, RVS	
202	X-3727-776-1	ARM ASSY, PENDULUM		214	3-736-740-01	NUT (M2X0.25), NYLON	
203	3-669-595-00	WASHER (2), STOPPER		215	3-736-116-01	GEAR, COMMUNICATION	
204	3-736-172-02	RELEASE, LOCK, REEL		216	X-3727-770-1	PINCH ROLLER BLOCK ASSY	
205	X-3727-795-1	GEAR ASSY, RELAY		218	3-736-136-01	CAM, ELEVATOR	
206	3-736-074-01	RETAINER (SMALL), THRUST		219	3-943-700-01	GEAR (LO), PRESS CAM	
207	3-736-037-01	GEAR, REW		220	3-942-828-01	OPENER, LID	
208	X-3727-798-1	TABLE ASSY, REEL (T)		221	3-738-250-01	SCREW, AC ADJUSTMENT	
209	3-738-212-21	RETAINER, THRUST, REEL TABLE		222	3-736-025-01	SPRING (REV BRAKE), TENSION	
210	X-3733-335-1	BRAKE ASSY (AT), T SOFT		223	3-736-024-01	SPRING, TENSION	
211	3-736-105-01	ARM, REV BRAKE		224	3-736-020-11	SPRING, COMPRESSION	
212	3-736-143-01	GEAR, RVS CAM		227	3-739-621-01	SPRING, COMPRESSION	
				228	3-736-069-01	RETAINER	

5-6. MECHANISM CHASSIS ASSEMBLY (2)



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
251	A-6759-483-A	TAKE-UP BLOCK ASSY (AT), S		272	X-3733-336-2	BRAKE ASSY (2) (AT), S	
252	3-736-075-01	BRAKE, S SOFT		273	3-738-221-01	SPRING (MAIN BRAKE 1), TENSION	
253	3-738-212-21	RETAINER, THRUST, REEL TABLE		274	X-3727-791-2	BASE ASSY, DRUM	
254	X-3941-194-1	TABLE ASSY, REEL, S		275	3-733-389-11	SPRING, TENSION	
255	3-736-151-11	ARM (POM), TENSION REGULATOR		276	A-6747-267-A	ARM BLOCK ASSY (S), C ROLLER	
256	X-3727-797-1	BAND ASSY, TENSION REGULATOR		277	3-944-033-01	FLANGE, 7 GUIDE	
257	X-3727-786-1	SHUTTLE (LEFT) ASSY		278	3-736-730-01	SLEEVE, #7 GUIDE	
258	X-3733-301-1	ROLLER ASSY, GUIDE		279	3-749-099-01	SPRING (#7 GUIDE), COMPRESSION	
259	X-3727-767-1	BASE ASSY, STABILIZER		280	X-3727-787-1	SHUTTLE (RIGHT) ASSY	
260	1-543-647-11	HEAD, FE		281	X-3727-788-1	ROLLER ASSY, GUIDE, #2	
261	3-736-082-01	RETAINER, TS THRUST		282	3-736-745-01	SPRING	
262	3-741-925-01	RING, RETAINING		283	3-738-284-01	SPRING, TENSION	
263	X-3727-771-1	STABILIZER ASSY, TAPE		284	X-3733-304-1	GROUND ASSY, SHAFT	
266	3-942-866-01	NUT (M3) (3X0.5), NYLON		285	3-736-073-01	SLIDER, POLYETHYLENE	
267	A-6761-129-C	HEAD BLOCK ASSY, ACE		286	3-739-621-01	SPRING, COMPRESSION	
268	3-736-735-03	SPRING, TENSION		287	1-550-786-11	DRUM ASSY (DZH-52AR)	
269	3-736-047-01	SPRING (S SOFT), TENSION		288	3-942-867-01	NUT, AC HEIGHT ADJUSTMENT	
270	X-3729-926-1	BRAKE ASSY (2), T		289	X-3743-517-1	LEVER(S), RELEASE	
271	3-738-220-01	SPRING (MAIN BRAKE 2), TENSION		290	1-550-536-11	DRUM ASSY, ROTARY UPPER (DZR-17)	

5-7. MECHANISM CHASSIS ASSEMBLY (3)



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
301	3-736-015-01	WHEEL (CAM), WORM		326	3-736-142-01	ARM, TENSION REGULATOR FUNCTION	
302	3-736-158-01	PLATE, SLIDE, PENDULUM		327	3-736-140-01	ARM, S TAKE-UP	
303	A-6739-084-A	CHASSIS BLOCK ASSY, SUB		328	X-3733-302-1	MOTOR ASSY, CAM	
304	3-736-091-01	PIN, SWITCH		329	3-733-395-01	GEAR (CAM), WORM	
305	X-3729-924-1	ARM, PENDULUM FUNCTION		330	3-733-397-01	ARM, BRAKE FUNCTION	
306	1-692-062-11	SWITCH, ROTARY		331	X-3733-338-1	BRAKE ASSY (AT), CAP	
307	3-669-595-00	WASHER (2), STOPPER		332	3-733-398-01	PLATE, SLIDE, BRAKE	
308	3-736-013-01	BELT, TIMING		333	3-736-103-01	PLATE, SLIDE, LIMITER	
309	X-3727-782-1	PULLEY ASSY		334	3-736-016-01	ARM, LIMITER FUNCTION	
310	3-736-089-01	SPRING, TENSION		335	3-736-170-01	GEAR, RKB CAM	
311	3-733-386-01	SCREW (3X8), WASHER		336	8-835-489-01	MOTOR, DC U-26K	
312	X-3727-761-1	ARM ASSY, ADJUSTMENT		337	3-736-744-01	RETAINER, ROTOR	
* 313	A-6754-435-A	MD-58 BOARD, COMPLETE		338	3-733-396-01	HOLDER, CAM GEAR	
317	3-736-177-01	PLATE, SLIDE, MODE		339	3-736-176-01	GEAR, CAM	
318	3-733-394-01	GEAR, RVS RELAY		340	3-738-237-01	SPRING (CAP BRAKE), TENSION	
319	3-736-073-01	SLIDER, POLYETHYLENE		341	3-741-950-01	SPRING (AT), LEAF, SC GROUND	
320	3-736-148-01	GEAR (RIGHT), THREADING		* 343	1-633-460-11	PC BOARD, CA-41	
321	3-736-092-01	SPRING (RIGHT), TORSION		D001	8-719-985-00	DIODE GL451VS1	
322	X-3727-777-1	ARM (RIGHT) ASSY, THREADING		Q001	8-729-926-31	TRANSISTOR PT483FIS	
323	3-736-147-01	GEAR (LEFT), THREADING		Q002	8-729-926-31	TRANSISTOR PT483FIS	
324	3-736-040-01	SPRING (LEFT), TORSION					
325	X-3727-778-1	ARM (LEFT) ASSY, THREADING					

**SECTION 6
ELECTRICAL PARTS LIST**

NOTE:

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL: metal-film resistor
METAL OXIDE: Metal Oxide-film resistor
F: nonflammable
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u: μ , for example:
uA...: μ A..., uPA..., μ PA...,
uPB..., μ PB..., uPC..., μ PC...,
uPD..., μ PD...
- CAPACITORS:
uF: μ F
- COILS
uH: μ H

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
*	A-6756-559-A	CG-15 BOARD, COMPLETE (AEP/NC/NP) *****				< CONNECTOR >	
*	A-6756-671-A	CG-15 BOARD, COMPLETE (UB) *****		* CN601	1-563-312-11	CONNECTOR, BOARD TO BOARD 12P	
*	A-6721-481-A	CG-15 BOARD, COMPLETE (B/VC) *****		CN602	1-563-311-11	CONNECTOR, BOARD TO BOARD 10P	
		(Ref.No.6000 Series)				< VARIABLE CAPACITOR >	
		< CAPACITOR >		CV601	1-141-245-00	CAP, TRIMMER 30PF	
C601	1-163-036-00	CERAMIC CHIP 0.068uF	50V			< IC >	
C602	1-163-031-11	CERAMIC CHIP 0.01uF	50V	IC601	8-759-078-01	IC uPD78013GC-VSX1760	
C603	1-163-229-11	CERAMIC CHIP 12PF	5% 50V	IC602	8-759-078-02	IC N50555-VSX1760	
C604	1-163-227-11	CERAMIC CHIP 10PF	5% 50V	IC603	8-759-996-03	IC LVA519S	
C605	1-124-589-11	ELECT 47uF	20% 16V			< JUMPER RESISTOR >	
C606	1-163-031-11	CERAMIC CHIP 0.01uF	50V	JR601	1-216-296-00	METAL CHIP 0 5% 1/8W	
C607	1-124-903-11	ELECT 1uF	20% 50V	JR603	1-216-296-00	METAL CHIP 0 5% 1/8W	
C608	1-163-031-11	CERAMIC CHIP 0.01uF	50V	JR604	1-216-296-00	METAL CHIP 0 5% 1/8W	
C609	1-124-443-00	ELECT 100uF	20% 10V	JR606	1-216-296-00	METAL CHIP 0 5% 1/8W	
C610	1-163-237-11	CERAMIC CHIP 27PF	5% 50V			< COIL >	
C611	1-163-031-11	CERAMIC CHIP 0.01uF	50V	L601	1-410-521-11	INDUCTOR 100uH	
C614	1-163-031-11	CERAMIC CHIP 0.01uF	50V	L602	1-410-521-11	INDUCTOR 100uH	
C615	1-163-006-11	CERAMIC CHIP 560PF	10% 50V	L603	1-412-470-21	INDUCTOR 22uH	
C616	1-126-301-11	ELECT 1uF	20% 50V	L604	1-410-515-11	INDUCTOR 33uH	
C617	1-163-007-11	CERAMIC CHIP 680PF	10% 50V	L605	1-410-509-11	INDUCTOR 10uH	
C618	1-163-127-00	CERAMIC CHIP 270PF	5% 50V	L606	1-410-521-11	INDUCTOR 100uH	
C619	1-163-127-00	CERAMIC CHIP 270PF	5% 50V	L607	1-410-521-11	INDUCTOR 100uH	
C620	1-163-031-11	CERAMIC CHIP 0.01uF	50V	L608	1-410-316-11	INDUCTOR 1uH	
C621	1-124-126-00	ELECT 47uF	20% 10V	L609	1-410-521-11	INDUCTOR 100uH	
C622	1-163-031-11	CERAMIC CHIP 0.01uF	50V	L610	1-410-521-11	INDUCTOR 100uH	
C623	1-163-099-00	CERAMIC CHIP 18PF	5% 50V				
C624	1-163-097-00	CERAMIC CHIP 15PF	5% 50V				
C625	1-163-105-00	CERAMIC CHIP 33PF	5% 50V				
C626	1-126-157-11	ELECT 10uF	20% 16V				
C627	1-130-487-00	MYLAR 0.022uF	5% 50V				
C629	1-163-035-00	CERAMIC CHIP 0.047uF	50V				

Ref. No.	Part No.	Description	Remarks
< TRANSISTOR >			
Q603	8-729-422-28	TRANSISTOR 2SD601A-R	
Q604	8-729-422-37	TRANSISTOR 2SB709A-R	
Q605	8-729-424-18	TRANSISTOR UN2113	
Q606	8-729-422-28	TRANSISTOR 2SD601A-R	
Q607	8-729-421-19	TRANSISTOR UN2213	
Q608	8-729-422-28	TRANSISTOR 2SD601A-R	
Q609	8-729-421-19	TRANSISTOR UN2213	
< RESISTOR >			
R601	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R602	1-216-085-00	METAL CHIP 33K 5% 1/10W	
R603	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R604	1-216-097-00	METAL CHIP 100K 5% 1/10W	
△R605	1-249-413-11	CARBON 470 5% 1/4W F	
R606	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R607	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
△R608	1-249-422-11	CARBON 2.7K 5% 1/4W F	
R609	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R610	1-216-041-00	METAL CHIP 470 5% 1/10W	
R611	1-216-063-00	METAL CHIP 3.9K 5% 1/10W	
R612	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R613	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R614	1-216-063-00	METAL CHIP 3.9K 5% 1/10W	
R615	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
R616	1-216-041-00	METAL CHIP 470 5% 1/10W	
R617	1-216-043-00	METAL CHIP 560 5% 1/10W	
R618	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R619	1-216-041-00	METAL CHIP 470 5% 1/10W	
R620	1-216-295-00	METAL CHIP 0 5% 1/10W	
R623	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R624	1-216-043-00	METAL CHIP 560 5% 1/10W	
R625	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R629	1-216-043-00	METAL CHIP 560 5% 1/10W	
R630	1-216-121-00	METAL CHIP 1M 5% 1/10W	
R640	1-216-075-00	METAL CHIP 12K 5% 1/10W	
R641	1-216-083-00	METAL CHIP 27K 5% 1/10W	
R642	1-216-059-00	METAL CHIP 2.7K 5% 1/10W	
R643	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R644	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R645	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R647	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R648	1-216-041-00	METAL CHIP 470 5% 1/10W	
R649	1-216-041-00	METAL CHIP 470 5% 1/10W	
< VARIABLE RESISTOR >			
RV601	1-241-079-11	RES. ADJ. CARBON 4.7K (AEP/UB/NC/NP)	
RV601	1-241-629-11	RES. ADJ. CARBON 4.7K (B/VC)	

Ref. No.	Part No.	Description	Remarks
< VIBRATOR >			
X601	1-577-157-11	VIBRATOR, CERAMIC 8MHZ	
X602	1-577-289-11	VIBRATOR, CRYSTAL 17.7MHZ	

*	A-6755-468-A	CN-62 BOARD, COMPLETE (AEP/NC)	

*	A-6755-669-A	CN-62 BOARD, COMPLETE (UB)	

*	A-6755-568-A	CN-62 BOARD, COMPLETE (B/NP/VC)	(Ref. No. 4000 Series)

< CAPACITOR >			
C101	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V	
C102	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V	
C103	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V	
C104	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V	
C105	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C106	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C107	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C108	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C801	1-124-589-11	ELECT 47uF 20% 16V (B/NP/VC)	
C802	1-163-031-11	CERAMIC CHIP 0.01uF 50V (B/NP/VC)	
C803	1-163-031-11	CERAMIC CHIP 0.01uF 50V (B/NP/VC)	
C804	1-163-031-11	CERAMIC CHIP 0.01uF 50V (B/NP/VC)	
C805	1-126-157-11	ELECT 10uF 20% 16V (B/NP/VC)	
C806	1-126-157-11	ELECT 10uF 20% 16V (B/NP/VC)	
C807	1-126-157-11	ELECT 10uF 20% 16V (B/NP/VC)	
C808	1-126-157-11	ELECT 10uF 20% 16V (B/NP/VC)	
C809	1-126-157-11	ELECT 10uF 20% 16V (B/NP/VC)	
C810	1-126-157-11	ELECT 10uF 20% 16V (B/NP/VC)	
C812	1-124-589-11	ELECT 47uF 20% 16V (B/NP/VC)	
C813	1-124-589-11	ELECT 47uF 20% 16V (B/NP/VC)	
< CONNECTOR >			
* CN102	1-573-735-41	PIN, CONNECTOR 8P	
CN103	1-691-277-11	CONNECTOR, BOARD TO BOARD 13P	
< JACK >			
CNJ101	1-561-534-41	SOCKET 21P (EURO-AV(LINE 3))	
< DIODE >			
D101	8-719-109-97	DIODE RD6.8ES-B2	
D102	8-719-109-97	DIODE RD6.8ES-B2	
D103	8-719-109-97	DIODE RD6.8ES-B2	
D104	8-719-109-97	DIODE RD6.8ES-B2	
D105	8-719-109-97	DIODE RD6.8ES-B2	

<p>Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.</p>	<p>Note: Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
--	---

CN-62 DG-11

Ref. No.	Part No.	Description	Remarks
D106	8-719-109-97	DIODE RD6.8ES-B2	
D107	8-719-108-12	DIODE RD9.1E-W	
< IC >			
IC801	8-759-300-71	IC TC4053BF (B/NP/VC)	
IC802	8-759-909-71	IC BA4558F (B/NP/VC)	
< COIL >			
L101	1-408-425-00	INDUCTOR 220uH	
L102	1-408-425-00	INDUCTOR 220uH	
L103	1-408-425-00	INDUCTOR 220uH	
L104	1-408-425-00	INDUCTOR 220uH	
L801	1-410-521-11	INDUCTOR 100uH (NP/VC)	
< RESISTOR >			
R101	1-216-041-00	METAL CHIP 470 5% 1/10W	
R102	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
R103	1-216-041-00	METAL CHIP 470 5% 1/10W	
R104	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
R105	1-216-022-00	METAL CHIP 75 5% 1/10W	
R106	1-216-069-00	METAL CHIP 6.8K 5% 1/10W	
R107	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R801	1-216-097-00	METAL CHIP 100K 5% 1/10W (B/NP/VC)	
R802	1-216-097-00	METAL CHIP 100K 5% 1/10W (B/NP/VC)	
R803	1-216-097-00	METAL CHIP 100K 5% 1/10W (B/NP/VC)	
R804	1-216-097-00	METAL CHIP 100K 5% 1/10W (B/NP/VC)	
R805	1-216-113-00	METAL CHIP 470K 5% 1/10W (B/NP/VC)	
R806	1-216-113-00	METAL CHIP 470K 5% 1/10W (B/NP/VC)	
R807	1-216-113-00	METAL CHIP 470K 5% 1/10W (B/NP/VC)	
R808	1-216-113-00	METAL CHIP 470K 5% 1/10W (B/NP/VC)	
R809	1-216-049-00	METAL CHIP 1K 5% 1/10W (B/NP/VC)	
R810	1-216-049-00	METAL CHIP 1K 5% 1/10W (B/NP/VC)	
R811	1-216-081-00	METAL CHIP 22K 5% 1/10W (B/NP/VC)	
R812	1-216-081-00	METAL CHIP 22K 5% 1/10W (B/NP/VC)	
R815	1-216-025-00	METAL CHIP 100 5% 1/10W (B/NP/VC)	
R816	1-216-025-00	METAL CHIP 100 5% 1/10W (B/NP/VC)	

*	A-6727-419-A DG-11 BOARD, COMPLETE (EXCEPT UB)		

*	A-6727-458-A DG-11 BOARD, COMPLETE (UB)		

(Ref. No. 7000 Series)			
< CAPACITOR >			
C101	1-163-125-00	CERAMIC CHIP 220PF 5% 50V	
C102	1-163-139-00	CERAMIC CHIP 820PF 5% 50V	
C103	1-163-097-00	CERAMIC CHIP 15PF 5% 50V	
C104	1-124-499-11	ELECT. NONPOLAR 1uF 20% 50V	
C105	1-163-031-11	CERAMIC CHIP 0.01uF 50V	

Ref. No.	Part No.	Description	Remarks
C106	1-126-177-11	ELECT 100uF 20% 10V	
C107	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C108	1-126-101-11	ELECT 100uF 20% 16V	
C109	1-126-157-11	ELECT 10uF 20% 16V	
C113	1-126-163-11	ELECT 4.7uF 20% 50V	
C114	1-126-301-11	ELECT 1uF 20% 50V	
C115	1-126-099-11	ELECT 2.2uF 20% 35V	
C124	1-163-135-00	CERAMIC CHIP 560PF 5% 50V	
C125	1-126-301-11	ELECT 1uF 20% 50V	
C127	1-163-135-00	CERAMIC CHIP 560PF 5% 50V	
C128	1-126-301-11	ELECT 1uF 20% 50V	
C129	1-163-989-11	CERAMIC CHIP 0.033uF 10% 25V	
C130	1-124-257-00	ELECT 2.2uF 20% 50V	
C131	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C132	1-124-464-11	ELECT 0.22uF 20% 50V	
C133	1-126-163-11	ELECT 4.7uF 20% 50V	
C134	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C135	1-163-229-11	CERAMIC CHIP 12PF 5% 50V	
C136	1-163-229-11	CERAMIC CHIP 12PF 5% 50V	
C137	1-126-157-11	ELECT 10uF 20% 16V	
C138	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C139	1-126-177-11	ELECT 100uF 20% 10V	
C140	1-163-019-00	CERAMIC CHIP 0.0068uF 10% 50V	
C141	1-163-141-00	CERAMIC CHIP 0.001uF 5% 50V	
C142	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C143	1-124-257-00	ELECT 2.2uF 20% 50V	
C144	1-163-137-00	CERAMIC CHIP 680PF 5% 50V	
C145	1-163-137-00	CERAMIC CHIP 680PF 5% 50V	
C146	1-163-145-00	CERAMIC CHIP 0.0015uF 5% 50V	
C147	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
C148	1-126-301-11	ELECT 1uF 20% 50V	
C149	1-163-093-00	CERAMIC CHIP 10PF 5% 50V	
C150	1-126-177-11	ELECT 100uF 20% 10V	
C151	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C152	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C153	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C154	1-163-989-11	CERAMIC CHIP 0.033uF 10% 25V	
C155	1-124-257-00	ELECT 2.2uF 20% 50V	
C156	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C157	1-124-464-11	ELECT 0.22uF 20% 50V	
C158	1-126-163-11	ELECT 4.7uF 20% 50V	
C159	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C161	1-163-229-11	CERAMIC CHIP 12PF 5% 50V	
C162	1-163-229-11	CERAMIC CHIP 12PF 5% 50V	
C163	1-126-157-11	ELECT 10uF 20% 16V	
C164	1-163-019-00	CERAMIC CHIP 0.0068uF 10% 50V	
C165	1-163-141-00	CERAMIC CHIP 0.001uF 5% 50V	
C166	1-124-257-00	ELECT 2.2uF 20% 50V	
C167	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C168	1-163-137-00	CERAMIC CHIP 680PF 5% 50V	

Ref. No.	Part No.	Description	Remarks
C169	1-163-137-00	CERAMIC CHIP 680PF 5% 50V	
C170	1-163-145-00	CERAMIC CHIP 0.0015uF 5% 50V	
C171	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
C172	1-126-301-11	ELECT 1uF 20% 50V	
C174	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C175	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C176	1-126-177-11	ELECT 100uF 20% 10V	
C177	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C179	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
C180	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
C181	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
C182	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
C183	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
C184	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
C187	1-126-157-11	ELECT 10uF 20% 16V	
C188	1-126-157-11	ELECT 10uF 20% 16V	
C189	1-126-157-11	ELECT 10uF 20% 16V	
C190	1-126-157-11	ELECT 10uF 20% 16V	
C191	1-126-177-11	ELECT 100uF 20% 10V	
C192	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C193	1-164-234-11	CERAMIC CHIP 1uF 10V	
C194	1-124-442-00	ELECT 330uF 20% 6.3V	
C196	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C197	1-126-177-11	ELECT 100uF 20% 10V	
C198	1-126-177-11	ELECT 100uF 20% 10V	
C199	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C200	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C201	1-126-177-11	ELECT 100uF 20% 10V	
C202	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
C204	1-126-301-11	ELECT 1uF 20% 50V	
C205	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C208	1-163-245-11	CERAMIC CHIP 56PF 5% 50V	
C210	1-163-109-00	CERAMIC CHIP 47PF 5% 50V	
C250	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C251	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C252	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C253	1-163-133-00	CERAMIC CHIP 470PF 5% 50V	
C254	1-163-130-00	CERAMIC CHIP 360PF 5% 50V	
C255	1-163-128-00	CERAMIC CHIP 300PF 5% 50V	
C256	1-163-125-00	CERAMIC CHIP 220PF 5% 50V	
< CONNECTOR >			
CN101	1-569-772-21	CONNECTOR, BOARD TO BOARD 9P	
CN103	1-568-152-21	CONNECTOR, BOARD TO BOARD 13P	
< DIODE >			
D101	8-719-400-18	DIODE MA152WK	
D105	8-719-400-18	DIODE MA152WK	
D106	8-719-400-18	DIODE MA152WK	
D109	8-719-400-18	DIODE MA152WK	

Ref. No.	Part No.	Description	Remarks
< FERRITE BEAD >			
FB101	1-410-397-21	FERRITE BEAD INDUCTOR	
FB102	1-410-397-21	FERRITE BEAD INDUCTOR	
< FILTER >			
FL101	1-236-101-11	ENCAPSULATED COMPONENT	
FL102	1-236-101-11	ENCAPSULATED COMPONENT	
FL103	1-236-101-11	ENCAPSULATED COMPONENT	
FL104	1-236-101-11	ENCAPSULATED COMPONENT	
FL109	1-236-071-11	ENCAPSULATED COMPONENT	
FL109	1-236-593-11	FILTER, LOW PASS	
FL110	1-236-071-11	ENCAPSULATED COMPONENT	
FL110	1-236-593-11	FILTER, LOW PASS	
FL111	1-424-228-11	FILTER, NOISE	
FL111	1-424-415-11	FILTER, NOISE	
FL112	1-424-228-11	FILTER, NOISE	
FL112	1-424-415-11	FILTER, NOISE	
FL113	1-424-228-11	FILTER, NOISE	
FL113	1-424-415-11	FILTER, NOISE	
FL114	1-424-228-11	FILTER, NOISE	
FL114	1-424-415-11	FILTER, NOISE	
FL115	1-424-228-11	FILTER, NOISE	
FL115	1-424-415-11	FILTER, NOISE	
FL116	1-424-228-11	FILTER, NOISE	
FL116	1-424-415-11	FILTER, NOISE	
FL117	1-424-228-11	FILTER, NOISE	
FL117	1-424-415-11	FILTER, NOISE	
FL118	1-236-071-11	ENCAPSULATED COMPONENT	
FL118	1-236-593-11	FILTER, LOW PASS	
FL119	1-236-986-11	FILTER, BAND PASS	
FL120	1-239-449-11	FILTER, BAND PASS	
FL121	1-236-844-11	FILTER, LOW PASS	
FL122	1-236-071-11	ENCAPSULATED COMPONENT	
FL122	1-236-593-11	FILTER, LOW PASS	
< IC >			
IC101	8-759-322-29	IC HA118088MP	
IC102	8-759-323-11	IC HA11567MP	
IC103	8-759-322-34	IC HA11535MP	
IC104	8-759-322-68	IC HD49410	
IC105	8-759-322-32	IC HM53461ZP-12	
IC108	8-759-008-74	IC MC14001BF	
< COIL >			
L101	1-407-169-XX	INDUCTOR 100uH	
L102	1-407-169-XX	INDUCTOR 100uH	
L105	1-407-169-XX	INDUCTOR 100uH	
L106	1-407-169-XX	INDUCTOR 100uH	
L107	1-407-169-XX	INDUCTOR 100uH	

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
L108	1-407-169-XX	INDUCTOR 100uH		R148	1-216-037-00	METAL CHIP 330 5% 1/10W	
L109	1-407-169-XX	INDUCTOR 100uH		R149	1-216-045-00	METAL CHIP 680 5% 1/10W	
L110	1-407-169-XX	INDUCTOR 100uH		R150	1-216-049-00	METAL CHIP 1K 5% 1/10W	
< TRANSISTOR >				R151	1-216-049-00	METAL CHIP 1K 5% 1/10W	
Q101	8-729-305-25	TRANSISTOR 2SA1052-C		R152	1-216-049-00	METAL CHIP 1K 5% 1/10W	
Q102	8-729-305-25	TRANSISTOR 2SA1052-C		R153	1-216-085-00	METAL CHIP 33K 5% 1/10W	
Q103	8-729-305-25	TRANSISTOR 2SA1052-C		R154	1-216-013-00	METAL CHIP 33 5% 1/10W	
Q108	8-729-305-25	TRANSISTOR 2SA1052-C		R155	1-216-033-00	METAL CHIP 220 5% 1/10W	
Q109	8-729-305-25	TRANSISTOR 2SA1052-C		R156	1-216-071-00	METAL CHIP 8.2K 5% 1/10W	
Q110	8-729-305-25	TRANSISTOR 2SA1052-C		R157	1-216-059-00	METAL CHIP 2.7K 5% 1/10W	
Q112	8-729-901-00	TRANSISTOR DTC124EK		R158	1-216-039-00	METAL CHIP 390 5% 1/10W	
Q113	8-729-305-25	TRANSISTOR 2SA1052-C		R159	1-216-055-00	METAL CHIP 1.8K 5% 1/10W	
Q114	8-729-230-49	TRANSISTOR 2SC2712-G		R165	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
Q116	8-729-305-25	TRANSISTOR 2SA1052-C		R166	1-216-689-11	METAL CHIP 39K 0.5% 1/10W	
Q117	8-729-230-49	TRANSISTOR 2SC2712-G		R167	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
Q118	8-729-305-25	TRANSISTOR 2SA1052-C		R168	1-216-103-00	METAL CHIP 180K 5% 1/10W	
Q120	8-729-901-00	TRANSISTOR DTC124EK		R170	1-216-049-00	METAL CHIP 1K 5% 1/10W	
Q121	8-729-305-25	TRANSISTOR 2SA1052-C		R171	1-216-041-00	METAL CHIP 470 5% 1/10W	
Q122	8-729-230-49	TRANSISTOR 2SC2712-G		R172	1-216-041-00	METAL CHIP 470 5% 1/10W	
Q123	8-729-901-00	TRANSISTOR DTC124EK		R173	1-216-029-00	METAL CHIP 150 5% 1/10W	
Q125	8-729-902-96	TRANSISTOR FMS1		R174	1-216-041-00	METAL CHIP 470 5% 1/10W	
Q126	8-729-901-01	TRANSISTOR DTC144EK		R175	1-216-041-00	METAL CHIP 470 5% 1/10W	
Q127	8-729-230-49	TRANSISTOR 2SC2712-G		R176	1-216-047-00	METAL CHIP 820 5% 1/10W	
< RESISTOR >				R177	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R101	1-216-049-00	METAL CHIP 1K 5% 1/10W		R178	1-216-047-00	METAL CHIP 820 5% 1/10W	
R102	1-216-049-00	METAL CHIP 1K 5% 1/10W		R179	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R103	1-216-049-00	METAL CHIP 1K 5% 1/10W		R180	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R104	1-216-049-00	METAL CHIP 1K 5% 1/10W		R181	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R105	1-216-049-00	METAL CHIP 1K 5% 1/10W		R182	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R106	1-216-049-00	METAL CHIP 1K 5% 1/10W		R183	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R107	1-216-049-00	METAL CHIP 1K 5% 1/10W		R184	1-216-085-00	METAL CHIP 33K 5% 1/10W	
R108	1-216-049-00	METAL CHIP 1K 5% 1/10W		R185	1-216-013-00	METAL CHIP 33 5% 1/10W	
R109	1-216-117-00	METAL CHIP 680K 5% 1/10W		R186	1-216-033-00	METAL CHIP 220 5% 1/10W	
R110	1-216-117-00	METAL CHIP 680K 5% 1/10W		R187	1-216-071-00	METAL CHIP 8.2K 5% 1/10W	
R111	1-216-097-00	METAL CHIP 100K 5% 1/10W		R188	1-216-059-00	METAL CHIP 2.7K 5% 1/10W	
R112	1-216-049-00	METAL CHIP 1K 5% 1/10W		R189	1-216-039-00	METAL CHIP 390 5% 1/10W	
R114	1-216-033-00	METAL CHIP 220 5% 1/10W		R190	1-216-055-00	METAL CHIP 1.8K 5% 1/10W	
R115	1-216-049-00	METAL CHIP 1K 5% 1/10W		R196	1-216-689-11	METAL CHIP 39K 0.5% 1/10W	
R116	1-216-077-00	METAL CHIP 15K 5% 1/10W		R197	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
R117	1-216-117-00	METAL CHIP 680K 5% 1/10W		R198	1-216-103-00	METAL CHIP 180K 5% 1/10W	
R127	1-216-073-00	METAL CHIP 10K 5% 1/10W		R199	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R139	1-216-049-00	METAL CHIP 1K 5% 1/10W		R200	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R140	1-216-049-00	METAL CHIP 1K 5% 1/10W		R201	1-216-672-11	METAL CHIP 7.5K 0.5% 1/10W	
R141	1-216-073-00	METAL CHIP 10K 5% 1/10W		R202	1-216-688-11	METAL CHIP 36K 0.5% 1/10W	
R143	1-216-049-00	METAL CHIP 1K 5% 1/10W		R203	1-216-631-11	METAL CHIP 150 0.5% 1/10W	
R144	1-216-049-00	METAL CHIP 1K 5% 1/10W		R204	1-216-679-11	METAL CHIP 15K 0.5% 1/10W	
R145	1-216-073-00	METAL CHIP 10K 5% 1/10W		R205	1-216-672-11	METAL CHIP 7.5K 0.5% 1/10W	
R146	1-216-061-00	METAL CHIP 3.3K 5% 1/10W		R206	1-216-679-11	METAL CHIP 15K 0.5% 1/10W	
R147	1-216-059-00	METAL CHIP 2.7K 5% 1/10W		R207	1-216-688-11	METAL CHIP 36K 0.5% 1/10W	
				R208	1-216-631-11	METAL CHIP 150 0.5% 1/10W	

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
R209	1-216-079-00	METAL CHIP	18K 5% 1/10W	*	1-637-536-21	DI-43 BOARD	
R215	1-216-073-00	METAL CHIP	10K 5% 1/10W		*****		(Ref. No. 5000 Series)
R216	1-216-075-00	METAL CHIP	12K 5% 1/10W		< CAPACITOR >		
R218	1-216-125-00	METAL CHIP	1.5M 5% 1/10W		C301	1-126-157-11 ELECT	10uF 20% 16V
R219	1-216-125-00	METAL CHIP	1.5M 5% 1/10W		< CONNECTOR >		
R220	1-216-295-00	METAL CHIP	0 5% 1/10W		CN201	1-569-678-21	CONNECTOR, BOARD TO BOARD 9P
R221	1-216-295-00	METAL CHIP	0 5% 1/10W		CN203	1-568-104-21	CONNECTOR, BOARD TO BOARD 13P
R222	1-216-109-00	METAL CHIP	330K 5% 1/10W	*	CN206	1-573-735-11	PIN, CONNECTOR 8P
R223	1-216-295-00	METAL CHIP	0 5% 1/10W	*	CN207	1-573-739-21	PIN, CONNECTOR 12P
R227	1-216-063-00	METAL CHIP	3.9K 5% 1/10W		< RESISTOR >		
R230	1-216-295-00	METAL CHIP	0 5% 1/10W		R301	1-216-041-00	METAL CHIP 470 5% 1/10W
R250	1-216-089-00	METAL CHIP	47K 5% 1/10W		R302	1-216-041-00	METAL CHIP 470 5% 1/10W
R251	1-216-073-00	METAL CHIP	10K 5% 1/10W		*****		
R252	1-216-081-00	METAL CHIP	22K 5% 1/10W	*	A-6721-475-A	HF-26 BOARD, COMPLETE (EXCEPT B/UB)	
R253	1-216-081-00	METAL CHIP	22K 5% 1/10W		*****		
R254	1-216-073-00	METAL CHIP	10K 5% 1/10W	*	A-6721-502-A	HF-26 BOARD, COMPLETE (B/UB)	
R255	1-216-067-00	METAL CHIP	5.6K 5% 1/10W		*****		(Ref. No. 17000 Series)
R256	1-216-073-00	METAL CHIP	10K 5% 1/10W		< CAPACITOR >		
R257	1-216-073-00	METAL CHIP	10K 5% 1/10W		C201	1-124-443-00	ELECT 100uF 20% 10V
R258	1-216-077-00	METAL CHIP	15K 5% 1/10W		C202	1-124-443-00	ELECT 100uF 20% 10V
R259	1-216-073-00	METAL CHIP	10K 5% 1/10W		C204	1-126-101-11	ELECT 100uF 20% 16V
R260	1-216-041-00	METAL CHIP	470 5% 1/10W		C205	1-163-031-11	CERAMIC CHIP 0.01uF 50V
R261	1-216-041-00	METAL CHIP	470 5% 1/10W		C206	1-124-925-11	ELECT 2.2uF 20% 100V
R262	1-216-041-00	METAL CHIP	470 5% 1/10W		C207	1-124-126-00	ELECT 47uF 20% 10V
R263	1-216-629-11	METAL CHIP	120 0.5% 1/10W		C208	1-124-927-11	ELECT 4.7uF 20% 100V
R264	1-216-063-00	METAL CHIP	3.9K 5% 1/10W		C209	1-124-907-11	ELECT 10uF 20% 50V
R265	1-216-063-00	METAL CHIP	3.9K 5% 1/10W		C212	1-124-126-00	ELECT 47uF 20% 10V
R266	1-216-049-00	METAL CHIP	1K 5% 1/10W		C213	1-124-126-00	ELECT 47uF 20% 10V
R267	1-216-049-00	METAL CHIP	1K 5% 1/10W		C214	1-124-126-00	ELECT 47uF 20% 10V
R268	1-216-049-00	METAL CHIP	1K 5% 1/10W		C215	1-124-907-11	ELECT 10uF 20% 50V
R269	1-216-049-00	METAL CHIP	1K 5% 1/10W		C216	1-124-927-11	ELECT 4.7uF 20% 100V
		< VARIABLE RESISTOR >			C217	1-124-925-11	ELECT 2.2uF 20% 100V
RV101	1-241-079-11	RES, ADJ, CARBON 4.7K			C218	1-124-925-11	ELECT 2.2uF 20% 100V
RV102	1-241-077-11	RES, ADJ, CARBON 2.2K			C219	1-124-907-11	ELECT 10uF 20% 50V
RV103	1-241-081-11	RES, ADJ, CARBON 22K			C220	1-124-907-11	ELECT 10uF 20% 50V
RV104	1-241-081-11	RES, ADJ, CARBON 22K			C221	1-130-483-00	MYLAR 0.01uF 5% 50V
		< TRANSFORMER >			C222	1-124-927-11	ELECT 4.7uF 20% 100V
T101	1-402-700-11	COIL, PEAKING 14.3MHz			C223	1-126-176-11	ELECT 220uF 20% 10V
T102	1-411-119-11	COIL, PEAKING 16.1MHz			C224	1-124-925-11	ELECT 2.2uF 20% 100V
		< VIBRATOR >			C225	1-130-487-00	MYLAR 0.022uF 5% 50V
X101	1-579-222-11	OSCILLATOR, CRYSTAL 4.43MHz			C226	1-126-096-11	ELECT 10uF 20% 35V
X102	1-577-611-11	OSCILLATOR, CERAMIC 500kHz			C227	1-124-234-00	ELECT 22uF 20% 16V
X103	1-579-222-11	OSCILLATOR, CRYSTAL 4.43MHz			C228	1-130-473-00	MYLAR 0.0015uF 5% 50V
X104	1-577-611-11	OSCILLATOR, CERAMIC 500kHz					

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
C229	1-130-475-00	MYLAR 0.0022uF 5% 50V		JR219	1-216-296-00	METAL CHIP 0 5% 1/8W	
C230	1-130-475-00	MYLAR 0.0022uF 5% 50V		JR221	1-216-296-00	METAL CHIP 0 5% 1/8W	
C231	1-163-031-11	CERAMIC CHIP 0.01uF 50V		JR222	1-216-296-00	METAL CHIP 0 5% 1/8W	
C232	1-124-443-00	ELECT 100uF 20% 10V		JR224	1-216-296-00	METAL CHIP 0 5% 1/8W	
C233	1-130-477-00	MYLAR 0.0033uF 5% 50V		JR225	1-216-296-00	METAL CHIP 0 5% 1/8W	
C234	1-124-903-11	ELECT 1uF 20% 50V		JR226	1-216-296-00	METAL CHIP 0 5% 1/8W	
C235	1-163-031-11	CERAMIC CHIP 0.01uF 50V				< COIL >	
C236	1-163-031-11	CERAMIC CHIP 0.01uF 50V		L202	1-408-424-00	INDUCTOR 180uH	
C237	1-163-133-00	CERAMIC CHIP 470PF 5% 50V				< RESISTOR >	
C239	1-130-475-00	MYLAR 0.0022uF 5% 50V		ΔR203	1-249-408-11	CARBON 180 5% 1/4W F	
C240	1-130-475-00	MYLAR 0.0022uF 5% 50V		ΔR205	1-249-408-11	CARBON 180 5% 1/4W F	
C241	1-130-473-00	MYLAR 0.0015uF 5% 50V		R209	1-247-891-00	CARBON 330K 5% 1/4W	
C242	1-124-234-00	ELECT 22uF 20% 16V		R212	1-216-049-00	METAL CHIP 1K 5% 1/10W	
C244	1-126-096-11	ELECT 10uF 20% 35V		R213	1-216-113-00	METAL CHIP 470K 5% 1/10W	
C245	1-130-487-00	MYLAR 0.022uF 5% 50V		R215	1-249-429-11	CARBON 10K 5% 1/4W	
C246	1-124-925-11	ELECT 2.2uF 20% 100V		ΔR216	1-249-417-11	CARBON 1K 5% 1/4W F	
C247	1-126-176-11	ELECT 220uF 20% 10V		R218	1-216-679-11	METAL CHIP 15K 0.5% 1/10W	
C248	1-124-927-11	ELECT 4.7uF 20% 100V		R220	1-216-223-00	METAL GLAZE 11K 5% 1/8W	
C249	1-130-483-00	MYLAR 0.01uF 5% 50V		R221	1-216-049-00	METAL CHIP 1K 5% 1/10W	
C250	1-163-031-11	CERAMIC CHIP 0.01uF 50V		R222	1-216-206-00	METAL GLAZE 2.2K 5% 1/8W	
C251	1-163-038-00	CERAMIC CHIP 0.1uF 25V		R223	1-216-059-00	METAL CHIP 2.7K 5% 1/10W	
C255	1-163-237-11	CERAMIC CHIP 27PF 5% 50V		R224	1-216-083-00	METAL CHIP 27K 5% 1/10W	
		< CONNECTOR >		R225	1-216-677-11	METAL CHIP 12K 0.5% 1/10W	
CN201	1-573-834-11	CONNECTOR, BOARD TO BOARD 20P		R226	1-249-429-11	CARBON 10K 5% 1/4W	
CN202	1-573-828-11	CONNECTOR, BOARD TO BOARD 14P		ΔR227	1-249-417-11	CARBON 1K 5% 1/4W F	
		< DIODE >		R231	1-216-679-11	METAL CHIP 15K 0.5% 1/10W	
D201	8-719-104-34	DIODE 1S2836		R232	1-216-677-11	METAL CHIP 12K 0.5% 1/10W	
		< IC >		R233	1-216-049-00	METAL CHIP 1K 5% 1/10W	
IC201	8-759-057-63	IC AN3937NFBP		R234	1-216-049-00	METAL CHIP 1K 5% 1/10W	
IC202	8-759-946-44	IC TK15120M		R235	1-216-055-00	METAL CHIP 1.8K 5% 1/10W	
IC203	8-759-924-46	IC BA4560F				< VARIABLE RESISTOR >	
IC204	8-759-946-44	IC TK15120M		RV201	1-241-077-11	RES, ADJ, CARBON 2.2K	
IC205	8-759-938-15	IC BA178M05		RV202	1-241-764-11	RES, ADJ, CERMET 10K	
		< JUMPER RESISTOR >		RV204	1-241-080-11	RES, ADJ, CARBON 10K	
JR203	1-216-296-00	METAL CHIP 0 5% 1/8W		RV205	1-241-763-11	RES, ADJ, CERMET 4.7K	
JR207	1-216-296-00	METAL CHIP 0 5% 1/8W		RV206	1-241-077-11	RES, ADJ, CARBON 2.2K	
JR208	1-216-295-00	METAL CHIP 0 5% 1/10W		RV207	1-241-764-11	RES, ADJ, CERMET 10K	
JR209	1-216-296-00	METAL CHIP 0 5% 1/8W		RV208	1-241-080-11	RES, ADJ, CARBON 10K	
JR211	1-216-296-00	METAL CHIP 0 5% 1/8W		RV209	1-241-763-11	RES, ADJ, CERMET 4.7K	
JR212	1-216-296-00	METAL CHIP 0 5% 1/8W					
JR213	1-216-296-00	METAL CHIP 0 5% 1/8W					
JR215	1-216-296-00	METAL CHIP 0 5% 1/8W					
JR217	1-216-296-00	METAL CHIP 0 5% 1/8W					
JR218	1-216-296-00	METAL CHIP 0 5% 1/8W					

Note:
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
*	A-6756-465-A	MA-140 BOARD, COMPLETE (AEP) *****	
*	A-6756-661-A	MA-140 BOARD, COMPLETE (UB) *****	
*	A-6756-560-A	MA-140 BOARD, COMPLETE (NC) *****	
*	A-6756-561-A	MA-140 BOARD, COMPLETE (NP) *****	
*	A-6756-564-A	MA-140 BOARD, COMPLETE (VC) *****	
*	A-6756-813-A	MA-140 BOARD, COMPLETE (B) *****	

(Ref. No. 8000 Series)

1-555-110-00 CABLE, PIN
3-831-441-XX CUSHION

< CAPACITOR >

C107	1-124-443-00	ELECT	100uF	20%	10V
C108	1-124-471-00	ELECT	1000uF	20%	6.3V
C110	1-162-306-11	CERAMIC	0.01uF	20%	16V
C111	1-124-126-00	ELECT	47uF	20%	10V
C114	1-124-471-00	ELECT	1000uF	20%	6.3V
C116	1-124-477-11	ELECT	47uF	20%	25V
C117	1-162-306-11	CERAMIC	0.01uF	20%	16V
C201	1-124-907-11	ELECT	10uF	20%	50V
C202	1-124-907-11	ELECT	10uF	20%	50V
C203	1-124-907-11	ELECT	10uF	20%	50V
C204	1-124-907-11	ELECT	10uF	20%	50V
C205	1-124-927-11	ELECT	4.7uF	20%	100V
C206	1-124-927-11	ELECT	4.7uF	20%	100V
C207	1-124-907-11	ELECT	10uF	20%	50V
C209	1-124-907-11	ELECT	10uF	20%	50V (EXCEPT B/UB)
C209	1-126-157-11	ELECT	10uF	20%	16V (B/UB)
C210	1-124-907-11	ELECT	10uF	20%	50V
C211	1-162-284-31	CERAMIC	150PF	10%	50V
C212	1-162-294-31	CERAMIC	0.001uF	10%	50V
C215	1-124-907-11	ELECT	10uF	20%	50V
C216	1-162-294-31	CERAMIC	0.001uF	10%	50V
C217	1-162-294-31	CERAMIC	0.001uF	10%	50V
C220	1-124-907-11	ELECT	10uF	20%	50V (EXCEPT B/UB)
C220	1-126-157-11	ELECT	10uF	20%	16V (B/UB)
C225	1-124-907-11	ELECT	10uF	20%	50V
C227	1-124-907-11	ELECT	10uF	20%	50V
C251	1-124-907-11	ELECT	10uF	20%	50V
C252	1-124-907-11	ELECT	10uF	20%	50V
C253	1-124-907-11	ELECT	10uF	20%	50V
C254	1-124-907-11	ELECT	10uF	20%	50V
C255	1-126-163-11	ELECT	4.7uF	20%	50V
C256	1-126-163-11	ELECT	4.7uF	20%	50V
C257	1-124-907-11	ELECT	10uF	20%	50V
C259	1-126-157-11	ELECT	10uF	20%	16V
C260	1-124-907-11	ELECT	10uF	20%	50V

Ref. No.	Part No.	Description	Remarks
C261	1-162-284-31	CERAMIC	150PF 10% 50V
C262	1-162-294-31	CERAMIC	0.001uF 10% 50V
C265	1-126-157-11	ELECT	10uF 20% 16V
C266	1-162-294-31	CERAMIC	0.001uF 10% 50V
C267	1-162-294-31	CERAMIC	0.001uF 10% 50V
C270	1-126-157-11	ELECT	10uF 20% 16V
C275	1-124-907-11	ELECT	10uF 20% 50V
C277	1-164-096-11	CERAMIC	0.01uF 50V
C281	1-124-907-11	ELECT	10uF 20% 50V
C282	1-126-157-11	ELECT	10uF 20% 16V

C283	1-164-096-11	CERAMIC	0.01uF 50V
C285	1-124-907-11	ELECT	10uF 20% 50V
C286	1-124-907-11	ELECT	10uF 20% 50V
C287	1-124-903-11	ELECT	1uF 20% 50V

(EXCEPT B/UB/VC)

C287	1-124-499-11	ELECT, NONPOLAR R	1uF 20% 50V (B/UB/VC)
C289	1-124-907-11	ELECT	10uF 20% 50V
C290	1-162-306-11	CERAMIC	0.01uF 20% 16V
C291	1-124-907-11	ELECT	10uF 20% 50V
C298	1-124-477-11	ELECT	47uF 20% 25V
C301	1-124-925-11	ELECT	2.2uF 20% 100V
C302	1-124-907-11	ELECT	10uF 20% 50V
C303	1-162-306-11	CERAMIC	0.01uF 20% 16V
C400	1-164-085-11	CERAMIC	0.001uF 10% 50V
C401	1-164-052-11	CERAMIC	18PF 5% 50V
C402	1-164-052-11	CERAMIC	18PF 5% 50V
C403	1-164-096-11	CERAMIC	0.01uF 50V
C404	1-164-096-11	CERAMIC	0.01uF 50V
C405	1-164-096-11	CERAMIC	0.01uF 50V
C406	1-126-245-11	ELECT	330uF 20% 6.3V
C407	1-136-161-00	MYLAR	0.047uF 10% 50V
C408	1-130-485-00	MYLAR	0.015uF 5% 50V
C409	1-124-925-11	ELECT	2.2uF 20% 100V
C410	1-162-306-11	CERAMIC	0.01uF 20% 16V
C411	1-124-598-11	ELECT	22uF 20% 25V
C412	1-126-101-11	ELECT	100uF 20% 16V
C413	1-164-085-11	CERAMIC	0.001uF 10% 50V
C414	1-124-472-11	ELECT	470uF 20% 10V
C415	1-124-126-00	ELECT	47uF 20% 10V
C416	1-164-159-11	CERAMIC	0.1uF 50V
C417	1-124-443-00	ELECT	100uF 20% 10V (EXCEPT B/UB)
C417	1-126-177-11	ELECT	100uF 20% 10V (B/UB)
C418	1-164-085-11	CERAMIC	0.001uF 10% 50V
C419	1-162-835-11	CERAMIC	0.0047uF 10% 16V
C420	1-162-847-11	CERAMIC	0.047uF 10% 16V
C421	1-124-477-11	ELECT	47uF 20% 25V
C422	1-162-849-11	CERAMIC	0.068uF 10% 16V
C423	1-126-233-11	ELECT	22uF 20% 50V
C424	1-162-851-11	CERAMIC	0.1uF 10% 16V
C425	1-124-925-11	ELECT	2.2uF 20% 100V

MA-140

Ref. No.	Part No.	Description	Remarks
C426	1-162-849-11	CERAMIC	0.068uF 10% 16V
C427	1-124-455-00	ELECT	100uF 20% 16V (B/UB)
C427	1-126-101-11	ELECT	100uF 20% 16V (EXCEPT B/UB)
C429	1-136-161-00	MYLAR	0.047uF 10% 50V (AEP/NC)
C429	1-164-098-11	CERAMIC	0.047uF 12V (B/UB/NP/VC)
C501	1-126-160-11	ELECT	1uF 20% 50V (UB)
C501	1-124-903-11	ELECT	1uF 20% 50V (NC/NP)
C502	1-124-903-11	ELECT	1uF 20% 50V (EXCEPT B/UB)
C503	1-126-157-11	ELECT	10uF 20% 16V (EXCEPT UB)
C504	1-124-907-11	ELECT	10uF 20% 50V (UB)
C521	1-126-157-11	ELECT	10uF 20% 16V
C522	1-136-159-00	MYLAR	0.033uF 10% 50V (EXCEPT B/UB)
C531	1-124-927-11	ELECT	4.7uF 20% 100V
C532	1-162-306-11	CERAMIC	0.01uF 20% 16V
C533	1-126-233-11	ELECT	22uF 20% 50V
C534	1-124-126-00	ELECT	47uF 20% 10V
C535	1-126-103-11	ELECT	470uF 20% 16V
C536	1-126-233-11	ELECT	22uF 20% 50V
C537	1-124-126-00	ELECT	47uF 20% 10V (AEP/B/VC)
C538	1-124-477-11	ELECT	47uF 20% 25V
C539	1-124-477-11	ELECT	47uF 20% 25V (EXCEPT B/UB)
C540	1-130-483-00	MYLAR	0.01uF 5% 50V (AEP/NC/VC)
C540	1-136-153-00	FILM	0.01uF 5% 50V (NP)
C546	1-124-477-11	ELECT	47uF 20% 25V (UB/NC/NP)
C547	1-124-126-00	ELECT	47uF 20% 10V (UB/NC/NP)
C548	1-162-851-11	CERAMIC	0.1uF 10% 16V (UB/NP/B)
C548	1-164-159-11	CERAMIC	0.1uF 50V (NC)
C551	1-126-160-11	ELECT	1uF 20% 50V (UB)
C551	1-124-903-11	ELECT	1uF 20% 50V (NC/NP)
C552	1-124-903-11	ELECT	1uF 20% 50V (EXCEPT B/UB)
C553	1-124-907-11	ELECT	10uF 20% 50V (B/UB)
C554	1-124-907-11	ELECT	10uF 20% 50V (UB)
C555	1-124-907-11	ELECT	10uF 20% 50V (B)
C571	1-162-212-31	CERAMIC	36PF 5% 50V
C572	1-162-205-31	CERAMIC	18PF 5% 50V (B/UB/NC/NP)
C572	1-162-219-11	CERAMIC	68uF 5% 50V (AEP)
C572	1-162-889-11	CERAMIC	68PF 5% 50V (VC)
C574	1-162-847-11	CERAMIC	0.047uF 10% 16V
C575	1-162-306-11	CERAMIC	0.01uF 20% 16V (UB/NC/NP)
C585	1-126-160-11	ELECT	1uF 20% 50V (UB/NC/NP)
C590	1-124-234-00	ELECT	22uF 20% 16V
C701	1-124-903-11	ELECT	1uF 20% 50V (EXCEPT B/UB)
C701	1-126-160-11	ELECT	1uF 20% 50V (B/UB)
C702	1-124-126-00	ELECT	47uF 20% 10V
C703	1-124-589-11	ELECT	47uF 20% 16V
C704	1-126-301-11	ELECT	1uF 20% 50V
C705	1-130-488-00	MYLAR	0.027uF 5% 50V
C706	1-130-492-11	MYLAR	0.056uF 5% 50V
C707	1-126-163-11	ELECT	4.7uF 20% 50V
C708	1-124-589-11	ELECT	47uF 20% 16V

Ref. No.	Part No.	Description	Remarks
C709	1-124-126-00	ELECT	47uF 20% 10V
C710	1-164-083-11	CERAMIC	680PF 10% 50V
C711	1-164-092-11	CERAMIC	0.0033uF 10% 25V
C712	1-124-465-00	ELECT	0.47uF 20% 50V
C713	1-124-903-11	ELECT	1uF 20% 50V
C714	1-130-483-00	MYLAR	0.01uF 5% 50V
C715	1-124-126-00	ELECT	47uF 20% 10V
C716	1-164-078-11	CERAMIC	270PF 10% 50V
C717	1-124-903-11	ELECT	1uF 20% 50V
C718	1-124-598-11	ELECT	22uF 20% 25V
C719	1-164-085-11	CERAMIC	0.001uF 10% 50V
C720	1-164-086-11	CERAMIC	0.0012uF 10% 50V
C721	1-164-077-11	CERAMIC	220PF 10% 50V
C724	1-137-612-11	FILM	0.0068uF 5% 100V
C725	1-164-087-11	CERAMIC	0.0015uF 10% 50V
C726	1-164-095-11	CERAMIC	0.01uF 10% 16V
C730	1-164-096-11	CERAMIC	0.01uF 50V
C740	1-126-320-11	ELECT	10uF 20% 16V (VC/NP/B)
C750	1-124-907-11	ELECT	10uF 20% 50V (VC/NP/B)
C760	1-164-096-11	CERAMIC	0.01uF 50V (VC/NP/B)
C901	1-124-907-11	ELECT	10uF 20% 50V
C902	1-162-851-11	CERAMIC	0.1uF 10% 16V
C905	1-164-159-11	CERAMIC	0.1uF 50V
C906	1-164-159-11	CERAMIC	0.1uF 50V
C910	1-124-584-00	ELECT	100uF 20% 10V
< CONNECTOR >			
* CN713	1-508-797-00	PIN, CONNECTOR 4P	
* CN901	1-560-894-00	PIN, CONNECTOR 6P	
CN902	1-506-473-11	PIN, CONNECTOR 8P	
* CN903	1-568-789-11	PIN, CONNECTOR 12P	
CN904	1-568-095-11	CONNECTOR (PLUG) 24P (EXCEPT B/UB)	
CN904	1-691-702-11	CONNECTOR, BOARD TO BOARD 20P (B/UB)	
CN905	1-691-703-11	CONNECTOR, BOARD TO BOARD 24P (B/UB)	
CN905	1-568-095-11	CONNECTOR (PLUG) 24P (EXCEPT B/UB)	
CN907	1-573-846-11	CONNECTOR, BOARD TO BOARD 14P	
CN908	1-573-852-11	CONNECTOR, BOARD TO BOARD 20P	
CN909	1-569-338-11	CONNECTOR, BOARD TO BOARD 19P	
* CN910	1-573-128-11	PIN, CONNECTOR 5P	
CN911	1-569-337-11	CONNECTOR, BOARD TO BOARD 11P	
* CN912	1-508-742-00	PIN, CONNECTOR 3P	
* CN913	1-573-131-41	PIN, CONNECTOR 8P	
* CN914	1-568-789-11	PIN, CONNECTOR 12P	
* CN915	1-573-129-31	PIN, CONNECTOR 6P	
* CN916	1-568-788-21	PIN, CONNECTOR 11P	
CN917	1-563-590-11	CONNECTOR, FLEXIBLE 13P (B/NP/VC)	
CN918	1-506-473-11	PIN, CONNECTOR 8P	
* CN919	1-573-134-41	PIN, CONNECTOR 11P	
CN920	1-569-341-11	CONNECTOR, BOARD TO BOARD 19P	
CN921	1-573-842-11	CONNECTOR, BOARD TO BOARD 10P (VC)	
CN922	1-566-128-11	CONNECTOR, BOARD TO BOARD 10P	

Ref. No.	Part No.	Description	Remarks
* CN923	1-506-775-11	CONNECTOR, BOARD TO BOARD 12P	
* CN925	1-573-128-31	PIN, CONNECTOR 5P (B)	
CN926	1-506-473-11	PIN, CONNECTOR 8P	
< JACK >			
CNJ901	1-565-351-41	JACK, PIN 3P (LINE OUT)	
CNJ902	1-561-534-00	SOCKET 21P (EURO-AV(LINE1))	
CNJ903	1-507-562-00	JACK (OUT)	
CNJ904	1-507-562-00	JACK (CONTROL S)	
< DIODE >			
D301	8-719-911-19	DIODE 1SS119	
D302	8-719-911-19	DIODE 1SS119	
D303	8-719-109-97	DIODE RD6.8ES-B2	
D304	8-719-109-97	DIODE RD6.8ES-B2	
D400	8-719-911-19	DIODE 1SS119	
D401	8-719-109-93	DIODE RD6.2ES-B2	
D402	8-719-109-93	DIODE RD6.2ES-B2	
D403	8-719-111-67	DIODE RD4.3ES-T2B	
D404	8-719-111-75	DIODE RD4.7ES-T2B	
D405	8-719-911-19	DIODE 1SS119	
D406	8-719-200-82	DIODE 11ES2	
D450	8-719-911-19	DIODE 1SS119 (VC/NP/B)	
D451	8-719-911-19	DIODE 1SS119 (VC/NP/B)	
D452	8-719-911-19	DIODE 1SS119 (VC/NP/B)	
D502	8-719-911-19	DIODE 1SS119	
D505	8-719-113-96	DIODE RD33ES-T2B (EXCEPT B/NC/UK)	
D505	8-719-110-78	DIODE RD33ES-B2 (B/NC/UK)	
D506	8-719-200-82	DIODE 11ES2 (UB/NP/NC)	
D580	8-719-911-19	DIODE 1SS119 (UB)	
D901	8-719-200-82	DIODE 11ES2	
D902	8-719-108-12	DIODE RD9.1E-W	
D903	8-719-109-97	DIODE RD6.8ES-B2	
D904	8-719-109-97	DIODE RD6.8ES-B2	
D905	8-719-110-36	DIODE RD13ES-B2	
D906	8-719-109-97	DIODE RD6.8ES-B2	
D907	8-719-109-97	DIODE RD6.8ES-B2 (EXCEPT B/UB)	
D907	8-719-108-12	DIODE RD9.1E-W (B/UB)	
D910	8-719-108-12	DIODE RD9.1E-W	
D911	8-719-108-12	DIODE RD9.1E-W	
D912	8-719-109-97	DIODE RD6.8ES-B2	
D913	8-719-108-12	DIODE RD9.1E-W	
< IC >			
IC201	8-759-520-50	IC BH7733S	
IC202	8-759-961-38	IC BA6138	
IC203	8-759-140-53	IC MC14053BCP	
IC204	8-759-945-58	IC RC4558P	
IC401	8-752-836-00	IC CXP80724-040Q	

Ref. No.	Part No.	Description	Remarks
IC402	8-759-246-14	IC TA8823N	
IC403	8-759-503-91	IC TL082ACP	
△IC404	8-759-983-45	IC BA6238A	
IC501	8-759-512-95	IC TDA8415 (EXCEPT B/UB)	
IC502	8-759-602-48	IC M5201L (B/UB)	
IC503	8-759-602-48	IC M5201L (UB)	
IC701	8-759-805-20	IC LA7297	
IC702	8-759-602-48	IC M5201L (VC/NP/B)	
< IF BLOCK >			
△IF501	1-466-539-11	IF BLOCK (1FZ-389ST) (AEP/VC)	
△IF501	1-466-541-11	IF BLOCK (1FZ-395NC) (UB)	
△IF501	1-466-538-11	IF BLOCK (1FZ-389NC) (NC/NP)	
△IF501	1-466-540-11	IF BLOCK (1FZ-389FE) (B)	
< COIL >			
L102	1-408-421-00	INDUCTOR 100uH	
L110	1-410-513-11	INDUCTOR 22uH	
L215	1-410-336-11	INDUCTOR 220uH	
L265	1-410-336-11	INDUCTOR 220uH	
L281	1-410-521-11	INDUCTOR 100uH	
L282	1-410-521-11	INDUCTOR 100uH	
L283	1-410-336-11	INDUCTOR 220uH	
L284	1-410-336-11	INDUCTOR 220uH	
L285	1-410-336-11	INDUCTOR 220uH	
L286	1-410-336-11	INDUCTOR 220uH	
L290	1-408-409-00	INDUCTOR 10uH	
L301	1-408-409-00	INDUCTOR 10uH	
L302	1-408-401-00	INDUCTOR 2.2uH	
L400	1-408-409-00	INDUCTOR 10uH	
L401	1-408-421-00	INDUCTOR 100uH	
L404	1-408-421-00	INDUCTOR 100uH	
L501	1-410-509-11	INDUCTOR 10uH (AEP/B/VC)	
L502	1-410-509-11	INDUCTOR 10uH (EXCEPT UB/B)	
L503	1-410-509-11	INDUCTOR 10uH (UB/NC/NP)	
L504	1-410-513-11	INDUCTOR 22uH	
L505	1-410-513-11	INDUCTOR 22uH	
L506	1-410-509-11	INDUCTOR 10uH (UB/NC/NP)	
L507	1-410-501-11	INDUCTOR 2.2uH	
L508	1-410-501-11	INDUCTOR 2.2uH	
L532	1-410-501-11	INDUCTOR 2.2uH	
L533	1-410-501-11	INDUCTOR 2.2uH	
L534	1-410-501-11	INDUCTOR 2.2uH	
L701	1-412-451-21	INDUCTOR 8.2mH	
L702	1-410-120-11	INDUCTOR 1.2mH	
L703	1-408-421-00	INDUCTOR 100uH	
L704	1-410-091-31	INDUCTOR 22mH	
L760	1-410-509-11	INDUCTOR 10uH (VC/NP/B)	
L901	1-408-413-00	INDUCTOR 22uH (EXCEPT B/UB)	
L901	1-410-513-11	INDUCTOR 22uH (B/UB)	
L902	1-410-501-11	INDUCTOR 2.2uH	

Note:
The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
L903	1-410-501-11	INDUCTOR 2.2uH	
< DECODER BLOCK >			
NCM501	1-466-543-11	DECORDER BLOCK (NCA-395) (UB)	
NCM501	1-466-542-11	DECORDER BLOCK (NCA-389) (NC/NP)	
< TRANSISTOR >			
Q101	8-729-423-42	TRANSISTOR 2SA1309A-R	
Q102	8-729-423-42	TRANSISTOR 2SA1309A-R	
Q103	8-729-900-89	TRANSISTOR DTC144ES	
Q104	8-729-423-42	TRANSISTOR 2SA1309A-R	
Q105	8-729-900-89	TRANSISTOR DTC144ES	
Q109	8-729-423-42	TRANSISTOR 2SA1309A-R	
Q202	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q203	8-729-119-78	TRANSISTOR 2SC2785-HFE (EXCEPT B/UB)	
Q203	8-729-900-89	TRANSISTOR DTC144ES (B/UB)	
Q220	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q247	8-729-119-78	TRANSISTOR 2SC2785-HFE (VC/NP/B)	
Q270	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q297	8-729-119-78	TRANSISTOR 2SC2785-HFE (VC/NP/B)	
Q298	8-729-900-89	TRANSISTOR DTC144ES	
Q301	8-729-119-78	TRANSISTOR 2SC2785-HFE (EXCEPT UB)	
Q302	8-729-900-65	TRANSISTOR DTA144ES	
Q303	8-729-900-89	TRANSISTOR DTC144ES	
Q304	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q305	8-729-900-80	TRANSISTOR DTC144ES	
Q306	8-729-423-42	TRANSISTOR 2SA1309A-R	
Q401	8-729-423-42	TRANSISTOR 2SA1309A-R (AEP)	
Q401	8-729-422-71	TRANSISTOR UN411L (EXCEPT AEP)	
Q447	8-729-900-65	TRANSISTOR DTA144ES	
Q450	8-729-900-89	TRANSISTOR DTC144ES (VC/NP/B)	
Q501	8-729-111-55	TRANSISTOR 2SC1509	
Q502	8-729-303-37	TRANSISTOR 2SD655-E	
Q503	8-729-119-78	TRANSISTOR 2SC2785-HFE (EXCEPT B/UB)	
Q504	8-729-900-89	TRANSISTOR DTC144ES (UB)	
Q505	8-729-423-42	TRANSISTOR 2SA1309A-R	
Q507	8-729-119-78	TRANSISTOR 2SC2785-HFE (UB/NP/NC/B)	
Q508	8-729-900-80	TRANSISTOR DTC144ES (EXCEPT UB)	
Q701	8-729-140-96	TRANSISTOR KSC1008	
< RESISTOR >			
R101	1-247-804-11	CARBON 75 5% 1/4W	
ΔR105	1-249-405-11	CARBON 100 5% 1/4W F	
ΔR106	1-249-406-11	CARBON 120 5% 1/4W F	
ΔR107	1-249-405-11	CARBON 100 5% 1/4W F	
ΔR108	1-249-403-11	CARBON 68 5% 1/4W F	
ΔR112	1-249-405-11	CARBON 100 5% 1/4W F	
ΔR113	1-249-407-11	CARBON 150 5% 1/4W F	

Ref. No.	Part No.	Description	Remarks
ΔR114	1-249-403-11	CARBON 68 5% 1/4W F	
R132	1-249-426-11	CARBON 5.6K 5% 1/4W	
ΔR133	1-249-417-11	CARBON 1K 5% 1/4W F	
ΔR134	1-249-417-11	CARBON 1K 5% 1/4W F	
R201	1-249-431-11	CARBON 15K 5% 1/4W	
R202	1-249-431-11	CARBON 15K 5% 1/4W	
R203	1-249-431-11	CARBON 15K 5% 1/4W	
ΔR204	1-249-423-11	CARBON 3.3K 5% 1/4W F	
R205	1-249-429-11	CARBON 10K 5% 1/4W	
R206	1-249-431-11	CARBON 15K 5% 1/4W	
R208	1-247-891-00	CARBON 330K 5% 1/4W	
R209	1-249-429-11	CARBON 10K 5% 1/4W	
ΔR210	1-249-422-11	CARBON 2.7K 5% 1/4W F	
R211	1-249-433-11	CARBON 22K 5% 1/4W	
R212	1-249-437-11	CARBON 47K 5% 1/4W (EXCEPT B/UB)	
R212	1-247-899-11	CARBON 680K 5% 1/4W (B/UB)	
R213	1-247-899-11	CARBON 680K 5% 1/4W (B/UB)	
R213	1-249-437-11	CARBON 47K 5% 1/4W (EXCEPT B/UB)	
R214	1-249-437-11	CARBON 47K 5% 1/4W	
R215	1-249-437-11	CARBON 47K 5% 1/4W	
R216	1-249-435-11	CARBON 33K 5% 1/4W	
ΔR217	1-249-413-11	CARBON 470 5% 1/4W F	
R218	1-249-426-11	CARBON 5.6K 5% 1/4W	
ΔR219	1-249-413-11	CARBON 470 5% 1/4W F	
R220	1-249-429-11	CARBON 10K 5% 1/4W	
R221	1-249-441-11	CARBON 100K 5% 1/4W	
R222	1-249-441-11	CARBON 100K 5% 1/4W	
ΔR224	1-249-414-11	CARBON 560 5% 1/4W F	
ΔR225	1-249-405-11	CARBON 100 5% 1/4W F	
ΔR227	1-249-405-11	CARBON 100 5% 1/4W F	
R228	1-249-437-11	CARBON 47K 5% 1/4W	
R241	1-249-439-11	CARBON 68K 5% 1/4W	
R242	1-249-439-11	CARBON 68K 5% 1/4W (B/UB)	
R242	1-249-438-11	CARBON 56K 5% 1/4W (EXCEPT B/UB)	
R243	1-249-438-11	CARBON 56K 5% 1/4W (EXCEPT B/UB)	
R243	1-249-439-11	CARBON 68K 5% 1/4W (B/UB)	
R246	1-249-438-11	CARBON 56K 5% 1/4W (EXCEPT B/UB)	
R246	1-249-439-11	CARBON 68K 5% 1/4W (B/UB)	
R247	1-249-440-11	CARBON 82K 5% 1/4W (VC/NP/B)	
R251	1-249-431-11	CARBON 15K 5% 1/4W	
R252	1-249-431-11	CARBON 15K 5% 1/4W	
R253	1-249-431-11	CARBON 15K 5% 1/4W	
R254	1-249-423-11	CARBON 3.3K 5% 1/4W F	
R255	1-249-429-11	CARBON 10K 5% 1/4W	
R256	1-249-431-11	CARBON 15K 5% 1/4W	
R258	1-247-891-00	CARBON 330K 5% 1/4W	
R259	1-249-429-11	CARBON 10K 5% 1/4W	

Note:
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
△R260	1-249-422-11	CARBON	2.7K 5% 1/4W F
R261	1-249-433-11	CARBON	22K 5% 1/4W
R262	1-249-437-11	CARBON	47K 5% 1/4W (EXCEPT B/UB)
R262	1-247-899-11	CARBON	680K 5% 1/4W (B/UB)
R263	1-247-899-11	CARBON	680K 5% 1/4W (B/UB)
R263	1-249-437-11	CARBON	47K 5% 1/4W (EXCEPT B/UB)
R264	1-249-437-11	CARBON	47K 5% 1/4W
R265	1-249-437-11	CARBON	47K 5% 1/4W
R266	1-249-435-11	CARBON	33K 5% 1/4W
△R267	1-249-413-11	CARBON	470 5% 1/4W F
R268	1-249-426-11	CARBON	5.6K 5% 1/4W
△R269	1-249-413-11	CARBON	470 5% 1/4W F
R270	1-249-429-11	CARBON	10K 5% 1/4W
R271	1-249-441-11	CARBON	100K 5% 1/4W
R272	1-249-441-11	CARBON	100K 5% 1/4W
△R274	1-249-414-11	CARBON	560 5% 1/4W F
△R275	1-249-405-11	CARBON	100 5% 1/4W F
△R277	1-249-405-11	CARBON	100 5% 1/4W F
R278	1-249-437-11	CARBON	47K 5% 1/4W
R281	1-249-431-11	CARBON	15K 5% 1/4W
R282	1-249-438-11	CARBON	56K 5% 1/4W (EXCEPT B/UB)
R282	1-249-439-11	CARBON	68K 5% 1/4W (B/UB)
△R284	1-249-417-11	CARBON	1K 5% 1/4W F
R285	1-249-431-11	CARBON	15K 5% 1/4W
R286	1-249-438-11	CARBON	56K 5% 1/4W (EXCEPT B/UB)
R286	1-249-439-11	CARBON	68K 5% 1/4W (B/UB)
R287	1-249-429-11	CARBON	10K 5% 1/4W
R288	1-249-429-11	CARBON	10K 5% 1/4W
R291	1-249-439-11	CARBON	68K 5% 1/4W
R292	1-249-439-11	CARBON	68K 5% 1/4W (B/UB)
R292	1-249-438-11	CARBON	56K 5% 1/4W (EXCEPT B/UB)
R293	1-249-438-11	CARBON	56K 5% 1/4W (EXCEPT B/UB)
R293	1-249-439-11	CARBON	68K 5% 1/4W (B/UB)
R296	1-249-438-11	CARBON	56K 5% 1/4W (EXCEPT B/UB)
R296	1-249-439-11	CARBON	68K 5% 1/4W (B/UB)
R297	1-249-440-11	CARBON	82K 5% 1/4W (VC/NP/B)
R298	1-249-429-11	CARBON	10K 5% 1/4W
R299	1-249-437-11	CARBON	47K 5% 1/4W
R301	1-249-429-11	CARBON	10K 5% 1/4W
△R302	1-249-421-11	CARBON	2.2K 5% 1/4W F
R303	1-247-891-00	CARBON	330K 5% 1/4W
R304	1-247-887-00	CARBON	220K 5% 1/4W
△R305	1-249-417-11	CARBON	1K 5% 1/4W F
△R306	1-249-405-11	CARBON	100 5% 1/4W F
R307	1-249-441-11	CARBON	100K 5% 1/4W
△R308	1-249-417-11	CARBON	1K 5% 1/4W F
△R401	1-249-425-11	CARBON	4.7K 5% 1/4W F
△R402	1-249-425-11	CARBON	4.7K 5% 1/4W F
△R403	1-249-421-11	CARBON	2.2K 5% 1/4W F

Ref. No.	Part No.	Description	Remarks
R405	1-249-429-11	CARBON	10K 5% 1/4W
R406	1-249-437-11	CARBON	47K 5% 1/4W
△R407	1-249-417-11	CARBON	1K 5% 1/4W F
△R408	1-249-417-11	CARBON	1K 5% 1/4W F
△R409	1-249-417-11	CARBON	1K 5% 1/4W F
R410	1-249-429-11	CARBON	10K 5% 1/4W
R411	1-249-429-11	CARBON	10K 5% 1/4W
R412	1-249-437-11	CARBON	47K 5% 1/4W
R413	1-249-436-11	CARBON	39K 5% 1/4W
R414	1-249-429-11	CARBON	10K 5% 1/4W
R415	1-249-429-11	CARBON	10K 5% 1/4W
R416	1-249-429-11	CARBON	10K 5% 1/4W
△R418	1-249-417-11	CARBON	1K 5% 1/4W F
R419	1-249-436-11	CARBON	39K 5% 1/4W
R420	1-249-429-11	CARBON	10K 5% 1/4W
R421	1-249-429-11	CARBON	10K 5% 1/4W
△R422	1-249-421-11	CARBON	2.2K 5% 1/4W F
R423	1-247-885-00	CARBON	180K 5% 1/4W
△R424	1-249-421-11	CARBON	2.2K 5% 1/4W F
R425	1-249-439-11	CARBON	68K 5% 1/4W
R426	1-249-434-11	CARBON	27K 5% 1/4W
△R427	1-249-423-11	CARBON	3.3K 5% 1/4W F
R428	1-247-705-11	CARBON	270 5% 1/4W
△R429	1-249-427-11	CARBON	6.8K 5% 1/4W F
△R431	1-249-421-11	CARBON	2.2K 5% 1/4W F
△R432	1-249-405-11	CARBON	100 5% 1/4W F
△R433	1-249-417-11	CARBON	1K 5% 1/4W F
R434	1-249-441-11	CARBON	100K 5% 1/4W
R435	1-247-901-11	CARBON	820K 5% 1/4W
R436	1-249-411-11	CARBON	330 5% 1/4W
R437	1-249-437-11	CARBON	47K 5% 1/4W
R438	1-249-437-11	CARBON	47K 5% 1/4W
R439	1-249-439-11	CARBON	68K 5% 1/4W
△R440	1-249-425-11	CARBON	4.7K 5% 1/4W F
R441	1-249-441-11	CARBON	100K 5% 1/4W
△R442	1-249-417-11	CARBON	1K 5% 1/4W F
R443	1-215-429-00	METAL	2.2K 1% 1/6W
R444	1-249-429-11	CARBON	10K 5% 1/4W
R445	1-249-429-11	CARBON	10K 5% 1/4W
R446	1-249-435-11	CARBON	33K 5% 1/4W
△R447	1-249-421-11	CARBON	2.2K 5% 1/4W F
R448	1-215-429-00	METAL	2.2K 1% 1/6W
R450	1-249-429-11	CARBON	10K 5% 1/4W (VC/NP/E)
R501	1-249-429-11	CARBON	10K 5% 1/4W (UB)
R502	1-249-429-11	CARBON	10K 5% 1/4W (UB)
R504	1-249-429-11	CARBON	10K 5% 1/4W (UB)
R505	1-249-429-11	CARBON	10K 5% 1/4W (UB)
R506	1-249-429-11	CARBON	10K 5% 1/4W (UB)
R507	1-249-441-11	CARBON	100K 5% 1/4W (UB)
R508	1-249-441-11	CARBON	100K 5% 1/4W (UB)

Note:
The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
R509	1-249-441-11	CARBON 100K 5%	1/4W (EXCEPT UB)
R510	1-249-441-11	CARBON 100K 5%	1/4W (EXCEPT UB)
△R522	1-249-419-11	CARBON 1.5K 5%	1/4W F (EXCEPT B/UB)
△R523	1-249-417-11	CARBON 1K 5%	1/4W F (EXCEPT B/UB)
△R524	1-249-421-11	CARBON 2.2K 5%	1/4W F
R525	1-247-895-00	CARBON 470K 5%	1/4W
R526	1-249-437-11	CARBON 47K 5%	1/4W (UB)
R527	1-249-437-11	CARBON 47K 5%	1/4W (B/UB)
△R528	1-249-417-11	CARBON 1K 5%	1/4W F (EXCEPT B/UB)
△R529	1-249-417-11	CARBON 1K 5%	1/4W F (EXCEPT B/UB)
△R530	1-249-420-11	CARBON 1.8K 5%	1/4W F (EXCEPT B/UB)
△R531	1-249-417-11	CARBON 1K 5%	1/4W F
△R535	1-249-417-11	CARBON 1K 5%	1/4W F (EXCEPT B)
△R536	1-249-417-11	CARBON 1K 5%	1/4W F (EXCEPT B)
△R537	1-249-428-11	CARBON 8.2K 5%	1/4W F (UB/NP/NC/B)
R538	1-249-430-11	CARBON 12K 5%	1/4W (UB/NP/NC/B)
△R539	1-249-423-11	CARBON 3.3K 5%	1/4W F (AEP/B/VC)
R540	1-249-433-11	CARBON 22K 5%	1/4W (AEP/B/VC)
R551	1-249-429-11	CARBON 10K 5%	1/4W (B/UB)
R552	1-249-429-11	CARBON 10K 5%	1/4W (B/UB)
R553	1-249-429-11	CARBON 10K 5%	1/4W (B)
R554	1-249-429-11	CARBON 10K 5%	1/4W (UB)
R555	1-249-429-11	CARBON 10K 5%	1/4W (UB)
R556	1-249-429-11	CARBON 10K 5%	1/4W (UB)
R557	1-249-441-11	CARBON 100K 5%	1/4W (UB)
R558	1-249-441-11	CARBON 100K 5%	1/4W (UB)
R559	1-249-441-11	CARBON 100K 5%	1/4W (B/UB)
R560	1-249-441-11	CARBON 100K 5%	1/4W (B/UB)
△R572	1-249-417-11	CARBON 1K 5%	1/4W F
△R573	1-249-425-11	CARBON 4.7K 5%	1/4W F (B/UB/NP/NC)
R573	1-249-421-11	CARBON 2.2K 5%	1/4W (AEP/VC)
△R574	1-249-405-11	CARBON 100 5%	1/4W F
R575	1-249-429-11	CARBON 10K 5%	1/4W (B/UB/NP/NC)
△R575	1-249-425-11	CARBON 4.7K 5%	1/4W F (AEP/VC)
R580	1-249-429-11	CARBON 10K 5%	1/4W (UB)
R585	1-249-425-11	CARBON 4.7K 5%	1/4W F (UB/NP/NC)
R701	1-249-429-11	CARBON 10K 5%	1/4W
R702	1-249-429-11	CARBON 10K 5%	1/4W
R703	1-249-429-11	CARBON 10K 5%	1/4W
△R704	1-249-407-11	CARBON 150 5%	1/4W F
△R705	1-249-421-11	CARBON 2.2K 5%	1/4W F
△R706	1-249-428-11	CARBON 8.2K 5%	1/4W F
R707	1-249-410-11	CARBON 270 5%	1/4W F
△R708	1-249-393-11	CARBON 10 5%	1/4W F
R710	1-249-436-11	CARBON 39K 5%	1/4W
△R711	1-249-416-11	CARBON 820 5%	1/4W F
R712	1-247-887-00	CARBON 220K 5%	1/4W
R713	1-249-411-11	CARBON 330 5%	1/4W
R714	1-249-429-11	CARBON 10K 5%	1/4W
R715	1-249-437-11	CARBON 47K 5%	1/4W

Ref. No.	Part No.	Description	Remarks
R716	1-249-433-11	CARBON 22K 5%	1/4W
R717	1-247-903-00	CARBON 1M 5%	1/4W
△R719	1-249-427-11	CARBON 6.8K 5%	1/4W F
R720	1-249-430-11	CARBON 12K 5%	1/4W (EXCEPT B/UB)
R720	1-249-433-11	CARBON 22K 5%	1/4W (B/UB)
△R721	1-249-425-11	CARBON 4.7K 5%	1/4W F (VC/NP/B)
△R721	1-249-416-11	CARBON 820 5%	1/4W F (AE/NC/UB)
R722	1-249-438-11	CARBON 56K 5%	1/4W
R725	1-249-432-11	CARBON 18K 5%	1/4W
R729	1-249-426-11	CARBON 5.6K 5%	1/4W
R730	1-249-433-11	CARBON 22K 5%	1/4W
△R733	1-249-387-11	CARBON 3.3 5%	1/4W F
R740	1-249-440-11	CARBON 82K 5%	1/4W (VC/NP/B)
R741	1-249-437-11	CARBON 47K 5%	1/4W (VC/NP/B)
R742	1-249-437-11	CARBON 47K 5%	1/4W (VC/NP/B)
R746	1-249-437-11	CARBON 47K 5%	1/4W (VC/NP/B)
R747	1-249-437-11	CARBON 47K 5%	1/4W (VC/NP/B)
R750	1-249-429-11	CARBON 10K 5%	1/4W (VC/NP/B)
R790	1-249-440-11	CARBON 82K 5%	1/4W (B)

< RF MODULATOR >

△RF501	1-466-328-11	MODULATOR, RF (RFU-2017) (EXCEPT B/UB)	(RF CHANNEL)
△RF501	1-466-347-11	MODULATOR, RF (RFU-2024) (UB) (RF CHANNEL)	
△RF501	1-466-348-11	MODULATOR, RF (RFU-2023) (B) (RF CHANNEL)	

< VARIABLE RESISTOR >

RV201	1-241-077-11	RES, ADJ, CARBON 2.2K	
RV400	1-241-083-11	RES, ADJ, CARBON 47K	
RV401	1-241-083-11	RES, ADJ, CARBON 47K	
RV501	1-241-079-11	RES, ADJ, CARBON 4.7K (EXCEPT B/UB)	
RV701	1-241-085-11	RES, ADJ, CARBON 220K	

< TRANSFORMER >

T701	1-433-352-11	TRANSFORMER, BIAS OSCILLATION	
------	--------------	-------------------------------	--

< TUNER >

△TU501	1-465-260-11	TUNER, ET (BTP-2C401) (EXCEPT B/UB)	
△TU501	1-465-262-11	TUNER, ET (UB/B)	

< VIBRATOR >

X401	1-578-774-11	VIBRATOR, CRYSTAL 12MHz	
X501	1-567-925-11	VIBRATOR, CRYSTAL 10MHz (EXCEPT B/UB)	

Note:

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
C613	1-161-494-00	CERAMIC 0.022uF 25V	
C614	1-162-306-11	CERAMIC 0.01uF 20% 16V	
< CONNECTOR >			
CN601	1-568-081-11	CONNECTOR (RECEPTALE) 24P (EXCEPT B/UB/VC)	
CN601	1-568-079-11	CONNECTOR (RECEPTALE) 20P (B/UB/VC)	
CN602	1-568-081-11	CONNECTOR (RECEPTALE) 24P	
* CN603	1-573-387-11	CONNECTOR, BOARD TO BOARD 12P	
CN604	1-568-673-11	CONNECTOR, BOARD TO BOARD 14P	
CN605	1-563-597-11	CONNECTOR, FLEXIBLE 20P (EXCEPT B/UB/VC)	
CN605	1-563-593-11	CONNECTOR, FLEXIBLE 16P (B/UB/VC)	
< VARIABLE CAPACITOR >			
CV601	1-141-291-11	CAP, TRIMMER (EXCEPT B/UB/VC)	
CV601	1-141-227-00	CAP, TRIMMER 20PF (B/UB/VC)	
< DIODE >			
D601	8-719-110-08	DIODE RD8.2ES-B2	
D602	8-719-911-19	DIODE 1SS119 (EXCEPT B/UB/VC)	
D602	8-719-200-82	DIODE 11ES2 (B/UB/VC)	
D603	8-719-911-19	DIODE 1SS119	
D604	8-719-911-19	DIODE 1SS119	
D605	8-719-911-19	DIODE 1SS119 (EXCEPT B/UB/VC)	
D605	8-719-200-82	DIODE 11ES2 (B/UB/VC)	
D610	8-719-911-19	DIODE 1SS119	
D611	8-719-911-19	DIODE 1SS119	
D612	8-719-911-19	DIODE 1SS119	
D613	8-719-911-19	DIODE 1SS119	
D614	8-719-911-19	DIODE 1SS119	
D615	8-719-911-19	DIODE 1SS119	
D616	8-719-109-93	DIODE RD6.2ES-B2	
D617	8-719-940-88	DIODE SLR-34UC3 (EXCEPT B/UB/VC)	
D617	8-719-946-30	DIODE SLR34DC3 (B/UB/VC)	
D618	8-719-940-82	DIODE SLR34MC3	
D619	8-719-940-99	DIODE SLR34VC3	
D620	8-719-940-99	DIODE SLR34VC3	
< IC >			
IC601	8-759-078-00	IC MB89796B-VSX1760 (AEP/UB/NC/NP)	
IC601	8-759-094-10	IC MB89796B-104 (B/UB)	
IC602	8-759-748-54	IC CAT35C202P	
IC603	8-759-515-58	IC PST572H (EXCEPT B/UB)	
IC603	8-759-520-98	IC PST572K-T (B/UB)	
IC604	8-759-510-43	IC PST572C	
IC605	1-466-131-21	IC GPIU52X	

Ref. No.	Part No.	Description	Remarks
< COIL >			
L601	1-410-361-21	INDUCTOR 12uH	
L602	1-410-501-11	INDUCTOR 2.2uH (EXCEPT B/UB/VC)	
L602	1-408-401-00	INDUCTOR 2.2uH (B/UB/VC)	
L604	1-410-517-11	INDUCTOR 47uH	
L605	1-410-501-11	INDUCTOR 2.2uH	
L607	1-410-336-11	INDUCTOR 220uH	
L609	1-410-501-11	INDUCTOR 2.2uH	
L610	1-410-501-11	INDUCTOR 2.2uH	
< LIQUID CRYSTAL DISPLAY >			
LCD601	1-519-507-41	INDICATOR TUBE, FLUORESCENT	
< TRANSISTOR >			
Q601	8-729-900-89	TRANSISTOR DTC144ES	
Q602	8-729-900-89	TRANSISTOR DTC144ES	
Q603	8-729-900-80	TRANSISTOR DTC114ES	
Q604	8-729-900-80	TRANSISTOR DTC114ES	
Q605	8-729-900-80	TRANSISTOR DTC114ES	
Q606	8-729-900-80	TRANSISTOR DTC114ES	
Q608	8-729-900-80	TRANSISTOR DTC114ES (VC)	
< RESISTOR >			
R601	1-249-435-11	CARBON 33K 5% 1/4W	
△R602	1-249-393-11	CARBON 10 5% 1/4W F	
R603	1-249-440-11	CARBON 82K 5% 1/4W	
R604	1-249-441-11	CARBON 100K 5% 1/4W	
R605	1-249-429-11	CARBON 10K 5% 1/4W	
R607	1-249-437-11	CARBON 47K 5% 1/4W	
△R608	1-249-425-11	CARBON 4.7K 5% 1/4W F (VC)	
R609	1-249-429-11	CARBON 10K 5% 1/4W (EXCEPT B/UB)	
△R609	1-249-425-11	CARBON 4.7K 5% 1/4W F (B/UB)	
R610	1-249-429-11	CARBON 10K 5% 1/4W	
R617	1-249-404-00	CARBON 82 5% 1/4W	
△R618	1-249-407-11	CARBON 150 5% 1/4W F	
△R619	1-249-409-11	CARBON 220 5% 1/4W F	
△R620	1-249-409-11	CARBON 220 5% 1/4W F	
△R622	1-249-405-11	CARBON 100 5% 1/4W F	
R623	1-249-429-11	CARBON 10K 5% 1/4W	
R624	1-249-429-11	CARBON 10K 5% 1/4W	
R625	1-249-429-11	CARBON 10K 5% 1/4W	
R626	1-249-429-11	CARBON 10K 5% 1/4W	
R627	1-249-429-11	CARBON 10K 5% 1/4W	
R628	1-249-429-11	CARBON 10K 5% 1/4W	
R629	1-249-429-11	CARBON 10K 5% 1/4W	
R630	1-249-429-11	CARBON 10K 5% 1/4W	
R653	1-249-437-11	CARBON 47K 5% 1/4W (AEP/B/NC/NP)	
R654	1-249-437-11	CARBON 47K 5% 1/4W (NC/VC)	

Note:
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
R655	1-249-437-11	CARBON 47K 5% 1/4W (NP)	
R662	1-249-417-11	CARBON 1K 5% 1/4W F	
R664	1-249-417-11	CARBON 1K 5% 1/4W F	
R670	1-249-425-11	CARBON 4.7K 5% 1/4W F	
R671	1-249-425-11	CARBON 4.7K 5% 1/4W F	
R698	1-249-433-11	CARBON 22K 5% 1/4W (B)	
R699	1-249-437-11	CARBON 47K 5% 1/4W	
< VARIABLE RESISTOR >			
RV601	1-241-358-11	RES. VAR. CARBON 20K (LEFT)	
RV602	1-241-358-11	RES. VAR. CARBON 20K (RIGHT)	
RV603	1-230-522-11	RES. ADJ. METAL 4.7K (EXCEPT B/UB)	
RV603	1-230-523-11	RES. ADJ. METAL 10K (B/UB)	
RV604	1-230-523-11	RES. ADJ. METAL 10K (B/UB)	
RV604	1-230-522-11	RES. ADJ. METAL 4.7K (EXCEPT B/UB)	
< VIBRATOR >			
X601	1-567-098-00	OSCILLATOR, CRYSTAL 32.768kHz	
X602	1-577-157-11	VIBRATOR, CERAMIC (EXCEPT B/UB)	
X602	1-579-125-11	VIBRATOR, CERAMIC (B/UB)	

*	A-6755-466-A	MF-168 BOARD, COMPLETE (EXCEPT UB)	

*	A-6755-660-A	MF-168 BOARD, COMPLETE (UB)	

(Ref. No. 11000 Series)			
	4-352-844-01	PIN, LEAD, COATING (UB)	
	3-950-546-01	HOLDER, LED	
< CAPACITOR >			
C201	1-126-160-11	ELECT 1uF 20% 50V	
C202	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C203	1-163-017-00	CERAMIC CHIP 0.0047uF 5% 50V	
C204	1-126-163-11	ELECT 4.7uF 20% 50V (EXCEPT B/UB)	
C204	1-124-589-11	ELECT 47uF 20% 16V (B/UB)	
C205	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C206	1-126-157-11	ELECT 10uF 20% 16V	
C207	1-163-105-00	CERAMIC CHIP 33PF 5% 50V	
C208	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C209	1-124-589-11	ELECT 47uF 20% 16V	
< CONNECTOR >			
CN201	1-568-667-11	CONNECTOR, BOARD TO BOARD 14P	
CN202	1-563-584-11	CONNECTOR, FLEXIBLE 7P (EXCEPT B/UB)	
CN202	1-563-587-11	CONNECTOR, FLEXIBLE 10P (B/UB)	
CN203	1-695-309-11	CONNECTOR, BOARD TO BOARD 11P	
CN204	1-506-487-11	PIN, CONNECTOR 8P	

Ref. No.	Part No.	Description	Remarks
< DIODE >			
D201	8-719-955-04	LED PY5504S-1 (EXCEPT B/UB)	
D201	8-719-988-92	LED BRPG5014X-K (B/UB)	
D202	8-719-988-92	LED BRPG5014X-K (B/UB)	
D202	8-719-955-04	LED PY5504S-1 (EXCEPT B/UB)	
< IC >			
IC201	8-759-923-90	IC BA4560 (EXCEPT B/UB)	
IC201	8-759-924-46	IC BA4560F (B/UB)	
IC202	8-759-032-32	IC MC74HC132AF	
< JUMPER RESISTOR >			
JR201	1-216-295-00	METAL CHIP 0 5% 1/10W (EXCEPT UB)	
JR202	1-216-295-00	METAL CHIP 0 5% 1/10W (EXCEPT UB)	
JR230	1-216-295-00	METAL CHIP 0 5% 1/10W (B/UB)	
JR232	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR233	1-216-295-00	METAL CHIP 0 5% 1/10W	
< COIL >			
L201	1-410-521-11	INDUCTOR 100uH	
< TRANSISTOR >			
Q201	8-729-230-49	TRANSISTOR 2SC2712-G	
Q202	8-729-421-19	TRANSISTOR UN2213	
Q203	8-729-140-75	TRANSISTOR 2SD999-CLCK	
Q204	8-729-140-75	TRANSISTOR 2SD999-CLCK	
Q240	8-729-230-49	TRANSISTOR 2SC2712-G	
< RESISTOR >			
R201	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R202	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R203	1-216-295-00	METAL CHIP 0 5% 1/10W	
R205	1-216-029-00	METAL CHIP 150 5% 1/10W	
R206	1-216-029-00	METAL CHIP 150 5% 1/10W	
R207	1-216-029-00	METAL CHIP 150 5% 1/10W	
R208	1-216-029-00	METAL CHIP 150 5% 1/10W	
R209	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R210	1-216-069-00	METAL CHIP 6.8K 5% 1/10W	
R211	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R212	1-216-097-00	METAL CHIP 100K 5% 1/10W	
R213	1-216-097-00	METAL CHIP 100K 5% 1/10W	
R214	1-216-101-00	METAL CHIP 150K 5% 1/10W	
R215	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R216	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R217	1-216-041-00	METAL CHIP 470 5% 1/10W	
R218	1-216-001-00	METAL CHIP 10 5% 1/10W (EXCEPT UB)	
R219	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (EXCEPT UB)	
R220	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R221	1-216-073-00	METAL CHIP 10K 5% 1/10W	

MF-168

MF-169

MF-170

Ref. No.	Part No.	Description	Quantity	Power	Notes	Remarks
R223	1-216-031-00	METAL CHIP	180	5%	1/10W (EXCEPT B/UB)	
R223	1-216-025-00	METAL CHIP	100	5%	1/10W (B/UB)	
R224	1-216-027-00	METAL CHIP	120	5%	1/10W (B/UB)	
R224	1-216-029-00	METAL CHIP	150	5%	1/10W (EXCEPT B/UB)	
R225	1-216-023-00	METAL CHIP	82	5%	1/10W (EXCEPT B/UB)	
R225	1-216-033-00	METAL CHIP	220	5%	1/10W (B/UB)	
R226	1-216-027-00	METAL CHIP	120	5%	1/10W (B/UB)	
R226	1-216-029-00	METAL CHIP	150	5%	1/10W (EXCEPT B/UB)	
R241	1-216-049-00	METAL CHIP	1K	5%	1/10W	

< SWITCH >

S201	1-571-977-11	SWITCH, TACTIL (ON/STANDBY)
S202	1-571-300-21	SWITCH, ROTARY

*	A-6755-463-A	MF-169 BOARD, COMPLETE (EXCEPT B/UB)	

*	A-6755-667-A	MF-169 BOARD, COMPLETE (UB)	

*	A-6755-811-A	MF-169 BOARD, COMPLETE (B)	

(Ref. No. 12000 Series)

< CONNECTOR >

CN401	1-568-671-11	CONNECTOR, BOARD TO BOARD 11P (EXCEPT B/UB)
CN401	1-568-668-11	CONNECTOR, BOARD TO BOARD 6P (B/UB)
CN402	1-563-619-21	CONNECTOR, FLEXIBLE 16P (B/UB)
CN402	1-563-623-11	CONNECTOR, FLEXIBLE 20P (EXCEPT B/UB)

< JUMPER RESISTOR >

JR401	1-216-295-00	METAL CHIP	0	5%	1/10W
JR402	1-216-296-00	METAL CHIP	0	5%	1/8W
JR403	1-216-296-00	METAL CHIP	0	5%	1/8W
JR404	1-216-296-00	METAL CHIP	0	5%	1/8W
JR405	1-216-296-00	METAL CHIP	0	5%	1/8W
JR406	1-216-295-00	METAL CHIP	0	5%	1/10W (EXCEPT UB)
JR409	1-216-295-00	METAL CHIP	0	5%	1/10W (EXCEPT UB)
JW004	1-216-296-00	METAL CHIP	0	5%	1/8W (EXCEPT UB)
JW013	1-216-295-00	METAL CHIP	0	5%	1/10W (EXCEPT UB)
JW085	1-216-296-00	METAL CHIP	0	5%	1/8W (EXCEPT UB)
JW087	1-216-295-00	METAL CHIP	0	5%	1/10W (EXCEPT UB)
JW088	1-216-295-00	METAL CHIP	0	5%	1/10W (EXCEPT UB)
JW089	1-216-295-00	METAL CHIP	0	5%	1/10W (EXCEPT UB)

< RESISTOR >

R401	1-216-049-00	METAL CHIP	1K	5%	1/10W
R402	1-216-069-00	METAL CHIP	6.8K	5%	1/10W (B/UB)
R402	1-216-063-00	METAL CHIP	3.9K	5%	1/10W (EXCEPT B/UB)
R403	1-216-067-00	METAL CHIP	5.6K	5%	1/10W
R404	1-216-069-00	METAL CHIP	6.8K	5%	1/10W

Ref. No.	Part No.	Description	Quantity	Power	Notes	Remarks
R405	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
R406	1-216-041-00	METAL CHIP	470	5%	1/10W	
R407	1-216-041-00	METAL CHIP	470	5%	1/10W	
R408	1-216-089-00	METAL CHIP	47K	5%	1/10W	
R409	1-216-073-00	METAL CHIP	10K	5%	1/10W (B)	

< TRANSISTOR >

Q401	8-729-421-19	TRANSISTOR UN2213-TX (B)
Q402	8-729-421-19	TRANSISTOR UN2213-TX (B)

< VARIABLE RESISTOR >

RV401	1-241-061-11	RES, VAR, CARBON 2K (SHARPNES)
RV402	1-238-420-11	RES, VAR, CARBON 10K (PHONE LEVEL)

< SWITCH >

S401	1-572-907-11	SWITCH, SLIDE (COMMAND MODE)
S402	1-570-847-11	SWITCH, SLIDE (B)
S403	1-570-836-11	SWITCH, SLIDE (B)
S404	1-572-908-11	SWITCH, SLIDE (NTSC PB ON PAL TV)
S405	1-571-977-11	SWITCH, TACTIL (CL)

*	A-6755-467-A	MF-170 BOARD, COMPLETE (EXCEPT UB)	

*	A-6755-668-A	MF-170 BOARD, COMPLETE (UB)	

(Ref. No. 13000 Series)

< CAPACITOR >

C300	1-163-133-00	CERAMIC CHIP	470PF	5%	50V
C302	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C303	1-163-133-00	CERAMIC CHIP	470PF	5%	50V
C304	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C306	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C308	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C310	1-136-015-00	CERAMIC CHIP	0.0033uF		50V
C311	1-136-015-00	CERAMIC CHIP	0.0033uF		50V
C313	1-163-031-11	CERAMIC CHIP	0.01uF		50V
C314	1-136-015-00	CERAMIC CHIP	0.0033uF		50V

< CONNECTOR >

CN301	1-563-610-11	CONNECTOR, FLEXIBLE 7P (EXCEPT B/UB)
CN301	1-563-613-21	CONNECTOR, FLEXIBLE 10P (B/UB)
CN302	1-568-662-11	CONNECTOR, BOARD TO BOARD 6P (B/UB)
CN302	1-568-665-11	CONNECTOR, BOARD TO BOARD 11P (EXCEPT B/UB)
CN303	1-506-468-11	PIN, CONNECTOR 3P (B/UB)

Ref. No.	Part No.	Description	Remarks
< JACK >			
CNJ301	0-479-451-00	JACK (MIC) (EXCEPT B/UB)	
CNJ301	1-695-312-11	JACK (SMALL TYPE) (MONO) (MIC) (B/UB)	
CNJ302	1-565-735-21	JACK, PIN 3P (PHONES)	
CNJ303	1-565-669-21	JACK, SMALL TYPE (LINE-2)	
CNJ304	1-568-800-11	JACK, ULTRA SMALL (CONTROL L)	
< DIODE >			
D301	8-719-109-93	DIODE RD6. 2ES-B2	
D302	8-719-109-93	DIODE RD6. 2ES-B2	
D303	8-719-109-93	DIODE RD6. 2ES-B2	
D321	8-719-109-93	DIODE RD6. 2ES-B2	
< JUMPER RESISTOR >			
JR301	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR302	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR303	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR311	1-216-295-00	METAL CHIP 0 5% 1/10W	
< COIL >			
L301	1-410-336-11	INDUCTOR 220uH	
L302	1-410-336-11	INDUCTOR 220uH	
L303	1-410-336-11	INDUCTOR 220uH	
L304	1-410-336-11	INDUCTOR 220uH	
< TRANSISTOR >			
Q321	8-729-140-75	TRANSISTOR 2SD999-CLCK	
Q322	8-729-140-75	TRANSISTOR 2SD999-CLCK	
< RESISTOR >			
R301	1-216-022-00	METAL CHIP 75 5% 1/10W	
R302	1-216-295-00	METAL CHIP 0 5% 1/10W	
R303	1-216-295-00	METAL CHIP 0 5% 1/10W	
R304	1-216-295-00	METAL CHIP 0 5% 1/10W	
R321	1-216-001-00	METAL CHIP 10 5% 1/10W	
R322	1-216-051-00	METAL CHIP 1.2K 5% 1/10W	

Ref. No.	Part No.	Description	Remarks
*	A-6727-417-A	RP-147 BOARD, COMPLETE (EXCEPT UB)	

*	A-6727-459-A	RP-147 BOARD, COMPLETE (UB)	

*	A-6727-467-A	RP-147 BOARD, COMPLETE (B)	

(Ref.No.1000 Series)			
< CAPACITOR >			
C201	1-126-157-11	ELECT 10uF 20% 16V	
C202	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C260	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C261	1-124-584-00	ELECT 100uF 20% 10V	
C262	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C263	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C264	1-124-257-00	ELECT 2.2uF 20% 50V	
C265	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C267	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C268	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C269	1-163-121-00	CERAMIC CHIP 150PF 5% 50V	
C270	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C273	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C274	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C275	1-126-160-11	ELECT 1uF 20% 50V	
C276	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C277	1-137-398-91	FILM 0.068uF 5% 100V	
C279	1-163-986-00	CERAMIC CHIP 0.027uF 10% 25V	
C280	1-163-011-11	CERAMIC CHIP 0.0015uF 10% 50V	
C281	1-124-589-11	ELECT 47uF 20% 16V	
C286	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C701	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C703	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C704	1-163-105-00	CERAMIC CHIP 33PF 5% 50V	
C705	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C706	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C707	1-124-257-00	ELECT 2.2uF 20% 50V	
C708	1-163-035-00	CERAMIC CHIP 0.047uF 50V	
C709	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C710	1-126-233-11	ELECT 22uF 20% 50V	
C801	1-163-033-00	CERAMIC CHIP 0.022uF 50V	
C802	1-163-033-00	CERAMIC CHIP 0.022uF 50V	
C803	1-163-033-00	CERAMIC CHIP 0.022uF 50V	
C804	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C805	1-163-033-00	CERAMIC CHIP 0.022uF 50V	
C806	1-163-117-00	CERAMIC CHIP 100PF 5% 50V	
C807	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C808	1-124-584-00	ELECT 100uF 20% 10V	
C809	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C810	1-124-584-00	ELECT 100uF 20% 10V	

RP-147

Ref. No.	Part No.	Description	Remarks
C811	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C812	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C813	1-164-336-11	CERAMIC CHIP 0.33uF	25V
C814	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C815	1-163-077-00	CERAMIC CHIP 0.1uF	10% 25V
C816	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C817	1-164-161-11	CERAMIC CHIP 0.0022uF	10% 100V
C818	1-163-107-00	CERAMIC CHIP 39PF	5% 50V
C819	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C820	1-163-113-00	CERAMIC CHIP 68PF	5% 50V
C821	1-163-115-00	CERAMIC CHIP 82PF	5% 50V
C822	1-163-129-00	CERAMIC CHIP 330PF	5% 50V
C823	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C824	1-124-126-00	ELECT 47uF	20% 10V
C826	1-124-589-11	ELECT 47uF	20% 16V
C827	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C828	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C829	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C830	1-163-097-00	CERAMIC CHIP 15PF	5% 50V
C831	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C833	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C834	1-163-087-00	CERAMIC CHIP 4PF	50V (B)
C834	1-163-097-00	CERAMIC CHIP 15PF	5% 50V (EXCEPT B)
C835	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C836	1-163-099-00	CERAMIC CHIP 18PF	5% 50V
C839	1-163-099-00	CERAMIC CHIP 18PF	5% 50V
C840	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C881	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
C882	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
C883	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
C884	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
C890	1-164-232-11	CERAMIC CHIP 0.01uF	50V
C892	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C893	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C894	1-163-121-00	CERAMIC CHIP 150PF	5% 50V
C895	1-163-245-11	CERAMIC CHIP 56PF	5% 50V
C896	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C897	1-126-157-11	ELECT 10uF	20% 16V
C902	1-163-129-00	CERAMIC CHIP 330PF	5% 50V (B)
< CONNECTOR >			
CN260	1-506-482-11	PIN, CONNECTOR 3P	
* CN801	1-563-590-11	CONNECTOR, FLEXIBLE 13P	
CN802	1-569-338-11	CONNECTOR, BOARD TO BOARD 19P	
* CN803	1-564-031-00	PIN, CONNECTOR 6P	
* CN804	1-564-018-51	PIN, CONNECTOR 8P	

Ref. No.	Part No.	Description	Remarks
< DIODE >			
D790	8-719-911-19	DIODE 1SS119	
D791	8-719-911-19	DIODE 1SS119	
D801	8-719-911-19	DIODE 1SS119	
D802	8-719-911-19	DIODE 1SS119	
D803	8-719-911-19	DIODE 1SS119	
D805	8-719-911-19	DIODE 1SS119	
D806	8-719-400-18	DIODE MA152WK	
D807	8-719-911-19	DIODE 1SS119	
D899	8-719-911-19	DIODE 1SS119	
< IC >			
IC260	8-759-055-49	IC AN3327K	
IC801	8-759-046-75	IC HA118162NT	
< JUMPER RESISTOR >			
JR067	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR401	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR402	1-216-296-00	METAL CHIP 0 5% 1/8W (EXCEPT UB)	
JR403	1-216-296-00	METAL CHIP 0 5% 1/8W (EXCEPT UB)	
JR404	1-216-296-00	METAL CHIP 0 5% 1/8W (EXCEPT UB)	
JR405	1-216-296-00	METAL CHIP 0 5% 1/8W (EXCEPT UB)	
JR406	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR407	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR801	1-216-296-00	METAL CHIP 0 5% 1/8W (EXCEPT UB)	
< COIL >			
L201	1-410-509-11	INDUCTOR 10uH	
L260	1-410-521-11	INDUCTOR 100uH	
L265	1-408-426-00	INDUCTOR 270uH	
L701	1-410-521-11	INDUCTOR 100uH	
L702	1-410-519-11	INDUCTOR 68uH	
L801	1-410-521-11	INDUCTOR 100uH (B)	
L802	1-410-521-11	INDUCTOR 100uH	
L803	1-410-521-11	INDUCTOR 100uH	
L804	1-410-521-11	INDUCTOR 100uH	
L805	1-410-514-11	INDUCTOR 27uH	
L806	1-410-515-11	INDUCTOR 33uH (B)	
L806	1-410-512-11	INDUCTOR 18uH (EXCEPT B)	
L807	1-410-516-11	INDUCTOR 39uH	
L808	1-410-509-11	INDUCTOR 10uH	
L809	1-410-512-11	INDUCTOR 18uH	
L810	1-410-524-41	INDUCTOR 180uH	
L811	1-410-521-11	INDUCTOR 100uH	
L812	1-410-521-11	INDUCTOR 100uH	
L813	1-410-509-11	INDUCTOR 10uH	
L814	1-410-509-11	INDUCTOR 10uH	
L890	1-410-507-11	INDUCTOR 6.8uH	
L891	1-410-521-11	INDUCTOR 100uH	
L902	1-410-524-41	INDUCTOT 180uH (B)	

Ref. No.	Part No.	Description	Remarks
< TRANSISTOR >			
Q201	8-729-140-97	TRANSISTOR 2SB734-34	
Q260	8-729-103-72	TRANSISTOR 2SD1005-BV	
Q701	8-729-422-28	TRANSISTOR 2SD601A-R	
Q703	8-729-422-28	TRANSISTOR 2SD601A-R	
Q705	8-729-422-37	TRANSISTOR 2SB709A-R	
Q706	8-729-421-19	TRANSISTOR UN2213	
Q707	8-729-422-28	TRANSISTOR 2SD601A-R	
Q801	8-729-422-28	TRANSISTOR 2SD601A-R	
Q802	8-729-422-28	TRANSISTOR 2SD601A-R	
Q803	8-729-424-18	TRANSISTOR UN2113	
Q804	8-729-422-28	TRANSISTOR 2SD601A-R	
Q805	8-729-422-37	TRANSISTOR 2SB709A-R	
Q806	8-729-422-37	TRANSISTOR 2SB709A-R	
Q807	8-729-422-28	TRANSISTOR 2SD601A-R	
Q808	8-729-901-01	TRANSISTOR DTC144EK	
Q809	8-729-422-28	TRANSISTOR 2SD601A-R	
Q810	8-729-901-47	TRANSISTOR DTA143EK	
Q811	8-729-301-98	TRANSISTOR 2SB1000A-L	
Q813	8-729-424-18	TRANSISTOR UN2113	
Q814	8-729-421-19	TRANSISTOR UN2213	
Q890	8-729-216-22	TRANSISTOR 2SA1162	
Q891	8-729-216-22	TRANSISTOR 2SA1162	
Q892	8-729-421-19	TRANSISTOR UN2213	
< RESISTOR >			
R201	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R202	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R262	1-216-174-00	METAL GLAZE 100 5% 1/8W	
R263	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
R265	1-216-033-00	METAL CHIP 220 5% 1/10W	
R266	1-216-051-00	METAL CHIP 1.2K 5% 1/10W	
R267	1-216-025-00	METAL CHIP 100 5% 1/10W	
R272	1-216-073-00	METAL CHIP 10K 5% 1/10W	
△R273	1-249-387-11	CARBON 3.3 5% 1/4W F	
R275	1-216-079-00	METAL CHIP 18K 5% 1/10W	
R701	1-216-079-00	METAL CHIP 18K 5% 1/10W	
R702	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R703	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
R704	1-216-033-00	METAL CHIP 220 5% 1/10W	
R705	1-216-045-00	METAL CHIP 680 5% 1/10W	
R706	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R707	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R708	1-216-041-00	METAL CHIP 470 5% 1/10W	
R709	1-216-033-00	METAL CHIP 220 5% 1/10W	
R710	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	

Ref. No.	Part No.	Description	Remarks
R711	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R712	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R713	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R714	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R801	1-216-029-00	METAL CHIP 150 5% 1/10W	
R802	1-216-037-00	METAL CHIP 330 5% 1/10W	
R803	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R804	1-216-626-11	METAL CHIP 91 1% 1/10W	
R805	1-216-613-11	METAL CHIP 27 0.5% 1/10W	
R806	1-216-029-00	METAL CHIP 150 5% 1/10W	
R807	1-216-029-00	METAL CHIP 150 5% 1/10W	
R808	1-216-615-11	METAL CHIP 33 0.5% 1/10W	
R809	1-216-621-11	METAL CHIP 56 0.50% 1/10W	
R810	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R811	1-216-037-00	METAL CHIP 330 5% 1/10W	
R812	1-216-029-00	METAL CHIP 150 5% 1/10W	
R813	1-216-047-00	METAL CHIP 820 5% 1/10W	
R815	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R816	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R817	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R818	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R819	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R820	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R821	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R822	1-216-039-00	METAL CHIP 390 5% 1/10W	
R823	1-216-047-00	METAL CHIP 820 5% 1/10W	
R824	1-216-039-00	METAL CHIP 390 5% 1/10W	
R825	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
R826	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R827	1-216-045-00	METAL CHIP 680 5% 1/10W	
R828	1-216-043-00	METAL CHIP 560 5% 1/10W	
R829	1-216-049-00	METAL CHIP 1K 5% 1/10W (B)	
R829	1-216-041-00	METAL CHIP 470 5% 1/10W (EXCEPT B)	
R830	1-216-047-00	METAL CHIP 820 5% 1/10W (EXCEPT B)	
R830	1-216-041-00	METAL CHIP 470 5% 1/10W (B)	
R831	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R832	1-216-051-00	METAL CHIP 1.2K 5% 1/10W	
R833	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R834	1-216-067-00	METAL CHIP 5.6K 5% 1/10W	
R835	1-216-059-00	METAL CHIP 2.7K 5% 1/10W	
R836	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R838	1-216-057-00	METAL CHIP 2.2K 5% 1/10W	
R839	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R891	1-216-011-00	METAL CHIP 27 5% 1/10W	
R894	1-216-041-00	METAL CHIP 470 5% 1/10W	
R895	1-216-054-00	METAL CHIP 1.6K 5% 1/10W	
R896	1-216-095-00	METAL CHIP 82K 5% 1/10W	
R897	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R898	1-216-689-11	METAL CHIP 39K 0.5% 1/10W	
R899	1-249-433-11	CARBON 22K 5% 1/4W	

<p>Note: The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.</p>	<p>Note: Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
--	--

RP-147	TK-17	TK-18	VI-116
--------	-------	-------	--------

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
		< TRANSFORMER >	
T260	1-406-349-11	TRANSFORMER, OSCILLATION	

*	1-644-856-14	TK-17 BOARD COMPLETE	(Ref. No. 14000 Series)
		< CONNECTOR >	
* CN150	1-573-386-11	CONNECTOR, BOARD TO BOARD 12P	
* CN151	1-562-882-11	SOCKET, CONNECTOR 12P	

		TK-18 BOARD, COMPLETE	
		*****	(Ref. No. 15000 Series)
*	1-644-857-11	TK-18 BOARD	
		< CONNECTOR >	
CN250	1-695-310-11	CONNECTOR, BOARD TO BOARD 11P	
* CN251	1-562-882-11	SOCKET, CONNECTOR 12P	

*	A-6755-469-A	VI-116 BOARD, COMPLETE (AEP/NC)	

*	A-6755-670-A	VI-116 BOARD, COMPLETE (UB)	

*	A-6755-569-A	VI-116 BOARD, COMPLETE (NP/VC)	

*	A-6755-812-A	VI-116 BOARD, COMPLETE (B)	(Ref. No. 3000 Series)

		< CAPACITOR >	
C501	1-124-126-00	ELECT 47uF 20% 10V	
C502	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C503	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C504	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C505	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C506	1-124-126-00	ELECT 47uF 20% 10V	
C507	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C508	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C509	1-124-907-11	ELECT 10uF 20% 50V	
C510	1-124-907-11	ELECT 10uF 20% 50V (EXCEPT B)	

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
C511	1-124-907-11	ELECT 10uF 20% 50V	
C512	1-124-907-11	ELECT 10uF 20% 50V	
C513	1-124-907-11	ELECT 10uF 20% 50V	
C514	1-124-907-11	ELECT 10uF 20% 50V	
C515	1-124-907-11	ELECT 10uF 20% 50V	
C516	1-124-907-11	ELECT 10uF 20% 50V	
C517	1-124-907-11	ELECT 10uF 20% 50V	
C518	1-163-093-00	CERAMIC CHIP 10PF 5% 50V (EXCEPT B)	
C519	1-163-031-11	CERAMIC CHIP 0.01uF 50V (EXCEPT B)	
C520	1-163-125-00	CERAMIC CHIP 220PF 5% 50V (EXCEPT B)	
C521	1-163-029-11	CERAMIC CHIP 0.0047uF 50V	
C522	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V	
C523	1-124-927-11	ELECT 4.7uF 20% 100V	
C524	1-124-907-11	ELECT 10uF 20% 50V	
C525	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C527	1-163-031-11	CERAMIC CHIP 0.01uF 50V (B)	
C551	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C552	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C554	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C556	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C557	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C558	1-163-031-11	CERAMIC CHIP 0.01uF 50V (B/NP/VC)	
C559	1-163-031-11	CERAMIC CHIP 0.01uF 50V (EXCEPT B)	
C560	1-124-907-11	ELECT 10uF 20% 50V	
C561	1-124-907-11	ELECT 10uF 20% 50V	
C562	1-124-927-11	ELECT 4.7uF 20% 100V	
C568	1-124-907-11	ELECT 10uF 20% 50V	
C569	1-124-907-11	ELECT 10uF 20% 50V	
C570	1-124-907-11	ELECT 10uF 20% 50V	
C571	1-124-907-11	ELECT 10uF 20% 50V	
C572	1-124-907-11	ELECT 10uF 20% 50V (B/NP/VC)	
C573	1-124-907-11	ELECT 10uF 20% 50V (B/NP/VC)	
C574	1-124-907-11	ELECT 10uF 20% 50V (EXCEPT B)	
C575	1-124-907-11	ELECT 10uF 20% 50V (EXCEPT B)	
C576	1-124-907-11	ELECT 10uF 20% 50V	
C580	1-124-907-11	ELECT 10uF 20% 50V (EXCEPT B)	
C581	1-124-907-11	ELECT 10uF 20% 50V	
C582	1-124-907-11	ELECT 10uF 20% 50V (EXCEPT B)	
C701	1-124-126-00	ELECT 47uF 20% 10V (B/NP/VC)	
C702	1-163-031-11	CERAMIC CHIP 0.01uF 50V (B/NP/VC)	
C703	1-163-031-11	CERAMIC CHIP 0.01uF 50V (B/NP/VC)	
C704	1-163-031-11	CERAMIC CHIP 0.01uF 50V (B/NP/VC)	
C706	1-124-907-11	ELECT 10uF 20% 50V (B/NP/VC)	
C707	1-124-907-11	ELECT 10uF 20% 50V (B/NP/VC)	
C708	1-124-907-11	ELECT 10uF 20% 50V (B/NP/VC)	

Ref. No.	Part No.	Description	Remarks
< CONNECTOR >			
CNS01	1-691-276-11	CONNECTOR, BOARD TO BOARD 13P	
* CNS02	1-568-788-21	PIN, CONNECTOR 11P (EXCEPT B)	
* CNS02	1-568-789-11	PIN, CONNECTOR 12P (B)	
* CNS03	1-573-129-31	PIN, CONNECTOR 6P	
* CNS04	1-568-788-21	PIN, CONNECTOR 11P	
CNS05	1-563-590-11	CONNECTOR, FLEXIBLE 13P (B/NP/VC)	
* CNS06	1-573-131-11	PIN, CONNECTOR 8P	
CNS07	1-506-468-11	PIN, CONNECTOR 3P	
< DIODE >			
D501	8-719-911-19	DIODE 1SS119 (EXCEPT B)	
D502	8-719-911-19	DIODE 1SS119	
D503	8-719-911-19	DIODE 1SS119 (B)	
D504	8-719-911-19	DIODE 1SS119 (B)	
D505	8-719-911-19	DIODE 1SS119 (B)	
< IC >			
IC501	8-759-503-52	IC MM1053XS	
IC502	8-759-048-09	IC MM1148XFF	
IC503	8-759-501-21	IC MM1149XF	
IC504	8-759-504-44	IC MM1031XMR	
IC551	8-759-501-21	IC MM1149XF	
IC552	8-759-420-62	IC AN3916 (EXCEPT B)	
IC552	8-759-504-44	IC MM1031XMR (B)	
IC553	8-759-048-09	IC MM1148XFF	
IC554	8-759-048-09	IC MM1148XFF	
IC555	8-759-048-09	IC MM1148XFF (B/NP/VC)	
IC556	8-759-048-09	IC MM1148XFF (EXCEPT B)	
IC701	8-759-056-91	IC BA7611AN (B/NP/VC)	
< JUMPER RESISTOR >			
JR502	1-216-295-00	METAL CHIP 0 5% 1/10W (EXCEPT B)	
JR503	1-216-295-00	METAL CHIP 0 5% 1/10W (EXCEPT B)	
JR552	1-216-295-00	METAL CHIP 0 5% 1/10W (AEP/UB/NC)	
JR901	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR902	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR903	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR904	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR905	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR906	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR907	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR908	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR909	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR910	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR911	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR912	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR913	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR914	1-216-295-00	METAL CHIP 0 5% 1/10W	

Ref. No.	Part No.	Description	Remarks
< COIL >			
L501	1-410-521-11	INDUCTOR 100uH	
L502	1-410-521-11	INDUCTOR 100uH	
L701	1-410-521-11	INDUCTOR 100uH (B/NP/VC)	
< TRANSISTOR >			
Q501	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
Q502	8-729-216-22	TRANSISTOR 2SA1162	
Q503	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
Q504	8-729-900-53	TRANSISTOR DTC114EK (EXCEPT B)	
Q506	8-729-901-06	TRANSISTOR DTA144EK (B)	
Q507	8-729-901-01	TRANSISTOR DTC144EK (B)	
Q508	8-729-901-01	TRANSISTOR DTC144EK (B)	
Q552	8-729-216-22	TRANSISTOR 2SA1162 (EXCEPT B)	
Q701	8-729-216-22	TRANSISTOR 2SA1162 (B/NP/VC)	
Q702	8-729-120-28	TRANSISTOR 2SC1623-L5L6 (B/NP/VC)	
Q703	8-729-216-22	TRANSISTOR 2SA1162 (B/NP/VC)	
Q704	8-729-901-01	TRANSISTOR DTC144EK (B/NP/VC)	
Q705	8-729-901-01	TRANSISTOR DTC144EK (B)	
Q706	8-729-901-01	TRANSISTOR DTC144EK (B)	
Q707	8-729-901-01	TRANSISTOR DTC144EK (B)	
Q708	8-729-901-01	TRANSISTOR DTC144EK (B)	
< RESISTOR >			
R501	1-216-025-00	METAL CHIP 100 5% 1/10W	
R502	1-216-049-00	METAL CHIP 1K 5% 1/10W (EXCEPT B)	
R502	1-216-097-00	METAL CHIP 100K 5% 1/10W (B)	
R503	1-216-025-00	METAL CHIP 100 5% 1/10W	
R504	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
R505	1-216-121-00	METAL CHIP 1M 5% 1/10W	
R506	1-216-059-00	METAL CHIP 2.7K 5% 1/10W	
R507	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R508	1-216-063-00	METAL CHIP 3.9K 5% 1/10W	
R509	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R510	1-216-097-00	METAL CHIP 100K 5% 1/10W	
R511	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
R512	1-216-073-00	METAL CHIP 10K 5% 1/10W (EXCEPT B)	
R513	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (B)	
R514	1-216-073-00	METAL CHIP 10K 5% 1/10W (B)	
R515	1-216-037-00	METAL CHIP 330 5% 1/10W (B)	
R516	1-216-049-00	METAL CHIP 1K 5% 1/10W (B)	
R551	1-216-025-00	METAL CHIP 100 5% 1/10W	
R552	1-216-049-00	METAL CHIP 1K 5% 1/10W (EXCEPT B)	
R553	1-216-049-00	METAL CHIP 1K 5% 1/10W (EXCEPT B)	
R556	1-216-025-00	METAL CHIP 100 5% 1/10W (EXCEPT B)	
R557	1-216-049-00	METAL CHIP 1K 5% 1/10W (EXCEPT B)	
R560	1-216-025-00	METAL CHIP 100 5% 1/10W	
R561	1-216-025-00	METAL CHIP 100 5% 1/10W	
R562	1-216-025-00	METAL CHIP 100 5% 1/10W (B/NP/VC)	

VI-116 VP-33 YC-124

Ref. No.	Part No.	Description	Remarks
R580	1-216-049-00	METAL CHIP 1K 5% 1/10W (EXCEPT B)	
R581	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R582	1-216-047-00	METAL CHIP 820 5% 1/10W (B)	
R598	1-249-407-11	CARBON 150 1/4W (EXCEPT B)	
R701	1-216-025-00	METAL CHIP 100 5% 1/10W (NP/VC)	
R702	1-216-063-00	METAL CHIP 3.9K 5% 1/10W (NP/VC)	
R703	1-216-049-00	METAL CHIP 1K 5% 1/10W (B/NP/VC)	
R704	1-216-021-00	METAL CHIP 68 5% 1/10W (B/NP/VC)	
R705	1-216-069-00	METAL CHIP 6.8K 5% 1/10W (B/NP/VC)	
R706	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (B/NP/VC)	
R707	1-216-073-00	METAL CHIP 10K 5% 1/10W (NP/VC)	
R708	1-216-049-00	METAL CHIP 1K 5% 1/10W (NP/VC)	
R709	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (B)	
R710	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (B)	
R711	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (B)	
< VARIABLE RESISTOR >			
RV551	1-241-083-11	RES, ADJ, CARBON 47K (AEP/UB/NC)	
RV551	1-241-632-11	RES, ADJ, CARBON 47K (NP/VC)	

*	A-6755-563-A	VP-33 BOARD, COMPLETE (VC)	

*	A-6755-799-A	VP-33 BOARD, COMPLETE (B)	

(Ref. No. 9000 Series)			
< CAPACITOR >			
C651	1-163-121-00	CERAMIC CHIP 150PF 5% 50V (VC)	
C652	1-163-989-11	CERAMIC CHIP 0.033uF 10% 25V (VC)	
C653	1-163-035-00	CERAMIC CHIP 0.047uF 50V (VC)	
C654	1-163-038-00	CERAMIC CHIP 0.1uF 25V (VC)	
C655	1-163-035-00	CERAMIC CHIP 0.047uF 50V (VC)	
C658	1-126-157-11	ELECT 10uF 20% 16V (VC)	
< CONNECTOR >			
CN650	1-573-824-11	CONNECTOR, BOARD TO BOARD 10P (VC)	
< DIODE >			
D651	8-719-104-34	DIODE 1S2835 (VC)	
< IC >			
IC651	8-759-030-60	IC SDA5642 (VC)	
IC652	8-759-147-30	IC uPD75004GB-VSX182 (VC)	
< COIL >			
L651	1-410-509-11	INDUCTOR 10uH (VC)	

Ref. No.	Part No.	Description	Remarks
< TRANSISTOR >			
Q651	8-729-421-19	TRANSISTOR UN2213 (VC)	
< RESISTOR >			
R651	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (VC)	
R652	1-216-121-00	METAL CHIP 1M 5% 1/10W (VC)	
R653	1-249-429-11	CARBON 10K 5% 1/4W (VC)	
R654	1-216-097-00	METAL CHIP 100K 5% 1/10W (VC)	
R655	1-216-119-00	METAL CHIP 820K 5% 1/10W (VC)	
R656	1-216-025-00	METAL CHIP 100 5% 1/10W (VC)	
R657	1-216-119-00	METAL CHIP 820K 5% 1/10W (VC)	
R658	1-249-426-11	CARBON 5.6K 5% 1/4W (VC)	
R659	1-216-073-00	METAL CHIP 10K 5% 1/10W (VC)	
R660	1-216-073-00	METAL CHIP 10K 5% 1/10W (VC)	
R661	1-216-073-00	METAL CHIP 10K 5% 1/10W (VC)	
R662	1-216-073-00	METAL CHIP 10K 5% 1/10W (VC)	
R663	1-216-101-00	METAL CHIP 150K 5% 1/10W (VC)	
< VIBRATOR >			
X651	1-577-291-11	OSCILLATOR, CERAMIC(WITH C) 4.19MHZ (VC)	

*	A-6727-418-A	YC-124 BOARD, COMPLETE (AEP/NC/NP)	

*	A-6727-456-A	YC-124 BOARD, COMPLETE (UB)	

*	A-6727-442-A	YC-124 BOARD, COMPLETE (VC)	

*	A-6727-465-A	YC-124 BOARD, COMPLETE (B)	

(Ref. No. 2000 Series)			
*	3-948-127-01	HOLDER, HF	
< CAPACITOR >			
C101	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C102	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C103	1-124-927-11	ELECT 4.7uF 20% 100V	
C104	1-126-233-11	ELECT 22uF 20% 50V	
C105	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
C106	1-124-927-11	ELECT 4.7uF 20% 100V	
C107	1-124-927-11	ELECT 4.7uF 20% 100V	
C108	1-163-093-00	CERAMIC CHIP 10PF 5% 50V	
C109	1-124-584-00	ELECT 100uF 20% 10V	
C110	1-163-035-00	CERAMIC CHIP 0.047uF 50V	
C111	1-163-129-00	CERAMIC CHIP 330PF 5% 50V	
C112	1-163-131-00	CERAMIC CHIP 390PF 5% 50V	
C113	1-163-139-00	CERAMIC CHIP 820PF 5% 50V	
C114	1-163-031-11	CERAMIC CHIP 0.01uF 50V	
C115	1-163-031-11	CERAMIC CHIP 0.01uF 50V	

Ref. No.	Part No.	Description	Remarks
C116	1-216-295-00	METAL CHIP 0	5% 1/10W
C117	1-163-097-00	CERAMIC CHIP 15PF	5% 50V
C118	1-124-927-11	ELECT 4.7uF	20% 100V
C119	1-163-088-00	CERAMIC CHIP 5PF	50V
C120	1-216-295-00	METAL CHIP 0	5% 1/10W
C121	1-163-129-00	CERAMIC CHIP 330PF	5% 50V (B)
C122	1-163-033-00	CERAMIC CHIP 0.022uF	50V
C123	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C124	1-163-033-00	CERAMIC CHIP 0.022uF	50V
C125	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C126	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C127	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C128	1-163-107-00	CERAMIC CHIP 39PF	5% 50V
C130	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C131	1-124-584-00	ELECT 100uF	20% 10V
C132	1-163-115-00	CERAMIC CHIP 82PF	5% 50V
C133	1-163-105-00	CERAMIC CHIP 33PF	5% 50V
C134	1-163-133-00	CERAMIC CHIP 470PF	5% 50V
C135	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C136	1-163-113-00	CERAMIC CHIP 68PF	5% 50V
C137	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C138	1-124-925-11	ELECT 2.2uF	20% 100V
C139	1-163-119-00	CERAMIC CHIP 120PF	5% 50V
C141	1-124-126-00	ELECT 47uF	20% 10V
C143	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C144	1-124-126-00	ELECT 47uF	20% 10V
C146	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C147	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C149	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C150	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C151	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C153	1-124-126-00	ELECT 47uF	20% 10V
C154	1-163-105-00	CERAMIC CHIP 33PF	5% 50V
C155	1-163-119-00	CERAMIC CHIP 120PF	5% 50V
C156	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
C160	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C163	1-124-927-11	ELECT 4.7uF	20% 100V
C170	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
C172	1-163-033-00	CERAMIC CHIP 0.022uF	50V (B)
C180	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C181	1-163-133-00	CERAMIC CHIP 470PF	5% 50V (B)
C182	1-163-113-00	CERAMIC CHIP 68PF	5% 50V
C183	1-163-129-00	CERAMIC CHIP 330PF	5% 50V
C185	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C190	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C300	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
C301	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C302	1-124-442-00	ELECT 330uF	20% 6.3V
C303	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C304	1-163-038-00	CERAMIC CHIP 0.1uF	25V (EXCEPT B)

Ref. No.	Part No.	Description	Remarks
C305	1-163-033-00	CERAMIC CHIP 0.022uF	50V
C306	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C307	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C308	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C309	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
C310	1-163-125-00	CERAMIC CHIP 220PF	5% 50V
C311	1-163-239-11	CERAMIC CHIP 33PF	5% 50V
C312	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C313	1-124-584-00	ELECT 100uF	20% 10V
C314	1-124-584-00	ELECT 100uF	20% 10V
C315	1-164-330-21	CERAMIC CHIP 0.22uF	10% 16V
C316	1-126-163-11	ELECT 4.7uF	20% 50V
C317	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C318	1-163-036-00	CERAMIC CHIP 0.068uF	50V
C319	1-164-492-11	CERAMIC CHIP 0.15uF	10% 16V
C320	1-163-117-00	CERAMIC CHIP 100PF	5% 50V
C321	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C323	1-124-927-11	ELECT 4.7uF	20% 100V
C325	1-164-004-11	CERAMIC CHIP 0.1uF	10% 25V
C326	1-163-809-11	CERAMIC CHIP 0.047uF	10% 25V
C327	1-164-336-11	CERAMIC CHIP 0.33uF	25V
C328	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C329	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C330	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C331	1-163-121-00	CERAMIC CHIP 150PF	5% 50V
C332	1-124-903-11	ELECT 1uF	20% 50V (EXCEPT B)
C332	1-124-902-00	ELECT 0.47uF	20% 50V (B)
C333	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C334	1-124-902-00	ELECT 0.47uF	20% 50V
C335	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C336	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C337	1-163-099-00	CERAMIC CHIP 18PF	5% 50V
C338	1-124-126-00	ELECT 47uF	20% 10V
C339	1-124-589-11	ELECT 47uF	20% 16V
C340	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C341	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B/VC)
C342	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C343	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B/VC)
C345	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C346	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C348	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C350	1-163-129-00	CERAMIC CHIP 330PF	5% 50V
C358	1-163-119-00	CERAMIC CHIP 120PF	5% 50V
C360	1-124-126-00	ELECT 47uF	20% 10V
C361	1-164-182-11	CERAMIC CHIP 0.0033uF	10% 50V
C362	1-163-121-00	CERAMIC CHIP 150PF	5% 50V
C363	1-124-903-11	ELECT 1uF	20% 50V
C364	1-124-126-00	ELECT 47uF	20% 10V
C365	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C366	1-124-903-11	ELECT 1uF	20% 50V

Ref. No.	Part No.	Description	Remarks
C367	1-124-907-11	ELECT 10uF 20%	50V
C368	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C369	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C370	1-163-103-00	CERAMIC CHIP 27PF	5% 50V
C371	1-163-103-00	CERAMIC CHIP 27PF	5% 50V
C372	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C373	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
C374	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C375	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C376	1-163-213-00	CERAMIC CHIP 0.0022uF	5% 50V
C377	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C378	1-163-213-00	CERAMIC CHIP 0.0022uF	5% 50V
C379	1-163-035-00	CERAMIC CHIP 0.047uF	50V
C380	1-124-903-11	ELECT 1uF	20% 50V
C381	1-124-907-11	ELECT 10uF	20% 50V
C382	1-123-382-00	ELECT 3.3uF	20% 100V
C383	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C384	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C385	1-124-907-11	ELECT 10uF	20% 50V
C386	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C387	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C388	1-124-907-11	ELECT 10uF	20% 50V
C389	1-163-109-00	CERAMIC CHIP 47PF	5% 50V
C390	1-163-097-00	CERAMIC CHIP 15PF	5% 50V
C391	1-163-113-00	CERAMIC CHIP 68PF	5% 50V
C392	1-163-113-00	CERAMIC CHIP 68PF	5% 50V
C393	1-124-034-51	ELECT 33uF	20% 16V
C394	1-126-160-11	ELECT 1uF	20% 50V
C395	1-163-038-00	CERAMIC CHIP 0.1uF	25V
C396	1-124-903-11	ELECT 1uF	20% 50V
C398	1-124-907-11	ELECT 10uF	20% 50V
C399	1-124-126-00	ELECT 47uF	20% 10V (B/VC)
C401	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C402	1-163-113-00	CERAMIC CHIP 68PF	5% 50V (B)
C403	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C404	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C405	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C406	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C408	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C409	1-124-126-00	ELECT 47uF	20% 10V (B)
C410	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C411	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C412	1-124-126-00	ELECT 47uF	20% 10V (B)
C413	1-163-117-00	CERAMIC CHIP 100PF	5% 50V (B)
C414	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C415	1-163-038-00	CERAMIC CHIP 0.1uF	25V (B)
C416	1-163-205-00	CERAMIC CHIP 0.001uF	5% 50V (B)
C417	1-163-243-11	CERAMIC CHIP 47PF	5% 50V (B)
C418	1-163-033-00	CERAMIC CHIP 0.022uF	50V (B)
C419	1-163-035-00	CERAMIC CHIP 0.047uF	50V (B)

Ref. No.	Part No.	Description	Remarks
C420	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C421	1-163-038-00	CERAMIC CHIP 0.1uF	25V (B)
C422	1-124-126-00	ELECT 47uF	20% 10V (B)
C426	1-163-113-00	CERAMIC CHIP 68PF	5% 50V (B)
C427	1-163-119-00	CERAMIC CHIP 120PF	5% 50V (B)
C428	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B)
C429	1-163-241-11	CERAMIC CHIP 39PF	5% 50V (B)
C450	1-163-145-00	CERAMIC CHIP 0.0015uF	5% 50V (B/VC)
C451	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B/VC)
C452	1-163-038-00	CERAMIC CHIP 0.1uF	25V (B/VC)
C454	1-124-927-11	ELECT 4.7uF	20% 100V (B/VC)
C455	1-124-126-00	ELECT 47uF	20% 10V (B/VC)
C457	1-163-031-11	CERAMIC CHIP 0.01uF	50V (B/VC)
C460	1-163-035-00	CERAMIC CHIP 0.047uF	50V (B/VC)
C461	1-163-035-00	CERAMIC CHIP 0.047uF	50V (B)
C462	1-163-035-00	CERAMIC CHIP 0.047uF	50V (B)
C463	1-124-907-11	ELECT 10uF	20% 50V (B)
C464	1-124-126-00	ELECT 47uF	20% 10V (B)
C465	1-124-907-11	ELECT 10uF	20% 50V
CS01	1-163-031-11	CERAMIC CHIP 0.01uF	50V
CS02	1-163-031-11	CERAMIC CHIP 0.01uF	50V
CS11	1-163-111-00	CERAMIC CHIP 56PF	5% 50V
CS12	1-163-031-11	CERAMIC CHIP 0.01uF	50V
CS13	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V
CS14	1-216-295-00	METAL CHIP 0	5% 1/10W
CS15	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V
CS16	1-124-927-11	ELECT 4.7uF	20% 100V
CS17	1-124-126-00	ELECT 47uF	20% 10V
CS18	1-163-038-00	CERAMIC CHIP 0.1uF	25V
CS19	1-163-031-11	CERAMIC CHIP 0.01	50V
< CONNECTOR >			
CN300	1-506-473-11	PIN, CONNECTOR 8P	
CN301	1-506-473-11	PIN, CONNECTOR 8P	
CN304	1-506-468-11	PIN, CONNECTOR 3P (B)	
* CN305	1-573-134-41	PIN, CONNECTOR 11P	
< DIODE >			
D101	8-719-400-18	DIODE MA152WK	
D105	8-719-400-18	DIODE MA152WK	
D301	8-719-400-18	DIODE MA152WK	
D302	8-719-400-18	DIODE MA152WK	
D401	8-719-400-18	DIODE MA152WK (B)	
< DELAY LINE >			
DL301	1-415-602-11	DELAY LINE, GLASS	
DL501	1-415-856-11	DELAY LINE, ULTRASONIC GLASS	

Ref. No.	Part No.	Description	Remarks
< FILTER >			
FL101	1-236-312-11	FILTER, BAND PASS	
FL301	1-239-915-11	FILTER, BAND PASS	
FL302	1-236-311-11	FILTER, BAND PASS 5.06MHz	
FL303	1-527-849-00	FILTER, CERAMIC13.3MHz	
FL401	1-236-584-11	BPF (B)	
FL402	1-236-582-11	BPF 4.3MHz (B)	
FL403	1-236-920-11	FILTER, LOW PASS 1.1MHz (B)	
FL404	1-236-920-11	FILTER, LOW PASS 1.1MHz (B)	
FL405	1-236-585-11	BPF 4.3MHz (B)	
FL406	1-236-585-11	BPF 4.3MHz (B)	
FL450	1-527-943-00	FILTER, CERAMIC (B/VC)	
< IC >			
IC101	8-759-420-07	IC AN3231K	
IC102	8-752-321-89	IC CXL5003P	
IC301	8-759-320-78	IC HALL8016NT	
IC302	8-759-822-05	IC LA7213	
IC360	8-759-420-53	IC AN3592K	
IC361	8-759-991-54	IC MSM6989RS	
IC362	8-759-927-56	IC BA7021	
IC363	8-759-822-05	IC LA7213 (EXCEPT B)	
IC401	8-759-991-55	IC BA7107 (B)	
IC450	8-759-904-95	IC BA7007 (B/VC)	
IC460	8-759-927-46	IC SN74HC00ANS (B)	
IC461	8-759-987-16	IC LM393P (B)	
IC501	8-759-925-90	IC SN74HC74ANS	
IC502	8-759-300-71	IC TC4053BF	
< JUMPER CHIP >			
JR001	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR002	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR003	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR004	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR005	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR006	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR007	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR008	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR009	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR010	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR011	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR012	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR013	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR014	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR017	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR018	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR019	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR020	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR036	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR038	1-216-296-00	METAL CHIP 0 5% 1/8W	

Ref. No.	Part No.	Description	Remarks
JR039	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR040	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR041	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR042	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR043	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR044	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR045	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR046	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR047	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR048	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR049	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR050	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR051	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR052	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR053	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR054	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR055	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR056	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR057	1-216-295-00	METAL CHIP 0 5% 1/10W (VC)	
JR058	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR064	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR065	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR066	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR068	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR500	1-216-295-00	METAL CHIP 0 5% 1/10W	
< COIL >			
L101	1-408-421-00	INDUCTOR 100uH	
L102	1-408-417-00	INDUCTOR 47uH (B)	
L103	1-408-419-00	INDUCTOR 68uH (B)	
L104	1-408-420-00	INDUCTOR 82uH	
L105	1-408-422-00	INDUCTOR 120uH	
L105	1-408-424-00	INDUCTOR 180uH (EXCEPT B)	
L106	1-408-421-00	INDUCTOR 100uH	
L107	1-408-421-00	INDUCTOR 100uH	
L108	1-408-421-00	INDUCTOR 100uH	
L109	1-408-421-00	INDUCTOR 100uH	
L112	1-408-410-00	INDUCTOR 12uH	
L113	1-408-413-00	INDUCTOR 22uH	
L119	1-408-417-00	INDUCTOR 47uH	
L126	1-408-424-00	INDUCTOR 180uH	
L301	1-408-421-00	INDUCTOR 100uH	
L302	1-408-427-00	INDUCTOR 330uH	
L303	1-408-429-00	INDUCTOR 470uH	
L305	1-408-409-00	INDUCTOR 10uH	
L306	1-408-408-00	INDUCTOR 8.2uH	
L307	1-408-408-00	INDUCTOR 8.2uH	

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
L309	1-407-499-00	INDUCTOR	3.9mH	Q402	8-729-920-74	TRANSISTOR	2SC2412K-QR (B)
L331	1-408-509-11	INDUCTOR	10uH	Q403	8-729-901-47	TRANSISTOR	DTA143EK
L360	1-408-409-00	INDUCTOR	10uH	Q405	8-729-920-74	TRANSISTOR	2SC2412K-QR (B)
L361	1-408-415-00	INDUCTOR	33uH	Q406	8-729-901-47	TRANSISTOR	DTA143EK (B)
L362	1-408-409-00	INDUCTOR	10uH	Q407	8-729-901-01	TRANSISTOR	DTC144EK (B)
L380	1-408-421-00	INDUCTOR	100uH	Q408	8-729-901-01	TRANSISTOR	DTC144EK (B)
L381	1-408-421-00	INDUCTOR	100uH	Q450	8-729-920-74	TRANSISTOR	2SC2412K-QR (B/VC)
L382	1-408-411-00	INDUCTOR	15uH	Q451	8-729-901-01	TRANSISTOR	DTC144EK (B)
L383	1-408-414-00	INDUCTOR	27uH	Q452	8-729-901-01	TRANSISTOR	DTC144EK (B)
L401	1-408-425-00	INDUCTOR	220uH (B)	Q453	8-729-901-01	TRANSISTOR	DTC144EK
L410	1-408-414-00	INDUCTOR	27uH (B)	Q460	8-729-901-01	TRANSISTOR	DTC144EK (B)
L414	1-408-416-00	INDUCTOR	39uH (B)	Q501	8-729-920-74	TRANSISTOR	2SC2412K-QR
L415	1-408-416-00	INDUCTOR	39uH (B)	Q502	8-729-901-01	TRANSISTOR	DTC144EK
L450	1-410-068-11	INDUCTOR	5.6mH (B/VC)	Q511	8-729-920-74	TRANSISTOR	2SC2412K-QR
L451	1-408-409-00	INDUCTOR	10uH (B)	Q512	8-729-920-74	TRANSISTOR	2SC2412K-QR
L490	1-410-509-11	INDUCTOR	10uH (B)	Q513	8-729-920-74	TRANSISTOR	2SC2412K-QR (B)
L491	1-410-509-11	INDUCTOR	10uH (B)	Q514	8-729-901-01	TRANSISTOR	DTC144EK
L501	1-408-406-00	INDUCTOR	5.6uH	Q515	8-729-901-01	TRANSISTOR	DTC144EK
L502	1-410-521-11	INDUCTOR	100uH (B)	Q516	8-729-901-04	TRANSISTOR	DTA114EK
		< TRANSISTOR >		Q517	8-729-901-47	TRANSISTOR	DTA143EK
Q102	8-729-216-22	TRANSISTOR	2SA1162	Q518	8-729-901-01	TRANSISTOR	DTC144EK
Q104	8-729-901-01	TRANSISTOR	DTC144EK	Q599	8-729-900-65	TRANSISTOR	DTA144EK
Q105	8-729-920-74	TRANSISTOR	2SC2412K-QR			< RESISTOR >	
Q106	8-729-216-22	TRANSISTOR	2SA1162	R101	1-216-105-00	METAL CHIP	220K 5% 1/10W
Q111	8-729-216-22	TRANSISTOR	2SA1162	R102	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
Q114	8-729-901-01	TRANSISTOR	DTC144EK (EXCEPT B)	R103	1-216-071-00	METAL CHIP	8.2K 5% 1/10W
Q121	8-729-920-74	TRANSISTOR	2SC2412K-QR	R104	1-216-069-00	METAL CHIP	6.8K 5% 1/10W
Q122	8-729-901-01	TRANSISTOR	DTC144EK	R105	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
Q123	8-729-901-01	TRANSISTOR	DTC144EK	R106	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
Q124	8-729-901-01	TRANSISTOR	DTC144EK (B)	R107	1-216-052-00	METAL CHIP	1.3K 5% 1/10W
Q125	8-729-901-01	TRANSISTOR	DTC144EK (B)	R108	1-216-036-00	METAL CHIP	300 5% 1/10W
Q301	8-729-920-74	TRANSISTOR	2SC2412K-QR	R109	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
Q302	8-729-920-74	TRANSISTOR	2SC2412K-QR	R110	1-216-091-00	METAL CHIP	56K 5% 1/10W
Q303	8-729-920-74	TRANSISTOR	2SC2412K-QR	R112	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
Q304	8-729-900-53	TRANSISTOR	DTC114EK	R113	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
Q305	8-729-216-22	TRANSISTOR	2SA1162	R114	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
Q306	8-729-901-01	TRANSISTOR	DTC144EK	R116	1-216-041-00	METAL CHIP	470 5% 1/10W
Q307	8-729-920-74	TRANSISTOR	2SC2412K-QR (B/VC)	R117	1-216-055-00	METAL CHIP	1.8K 5% 1/10W
Q308	8-729-920-74	TRANSISTOR	2SC2412K-QR	R118	1-216-059-00	METAL CHIP	2.7K 5% 1/10W
Q309	8-729-920-74	TRANSISTOR	2SC2412K-QR	R119	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
Q310	8-729-901-04	TRANSISTOR	DTA114EK	R120	1-216-063-00	METAL CHIP	3.9K 5% 1/10W
Q352	8-729-901-01	TRANSISTOR	DTC144EK (B)	R122	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
Q360	8-729-809-77	TRANSISTOR	2SC3142-J4	R123	1-216-067-00	METAL CHIP	5.6K 5% 1/10W
Q362	8-729-901-01	TRANSISTOR	DTC144EK	R124	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
Q380	8-729-920-74	TRANSISTOR	2SC2412K-QR	R125	1-216-039-00	METAL CHIP	390 5% 1/10W
Q381	8-729-920-74	TRANSISTOR	2SC2412K-QR	R126	1-216-047-00	METAL CHIP	820 5% 1/10W
Q382	8-729-216-22	TRANSISTOR	2SA1162	R127	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
Q390	8-729-901-01	TRANSISTOR	DTC144EK	R128	1-216-115-00	METAL CHIP	560K 5% 1/10W
Q399	8-729-901-01	TRANSISTOR	DTC144EK (B)				
Q401	8-729-920-74	TRANSISTOR	2SC2412K-QR (B)				

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
R129	1-216-089-00	METAL CHIP	47K 5% 1/10W	R334	1-216-059-00	METAL CHIP	2.7K 5% 1/10W
R130	1-216-089-00	METAL CHIP	47K 5% 1/10W	R335	1-216-037-00	METAL CHIP	330 5% 1/10W
R131	1-216-041-00	METAL CHIP	470 5% 1/10W	R336	1-216-037-00	METAL CHIP	330 5% 1/10W
R134	1-216-083-00	METAL CHIP	27K 5% 1/10W	R337	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R135	1-216-073-00	METAL CHIP	10K 5% 1/10W	R338	1-216-089-00	METAL CHIP	47K 5% 1/10W
R136	1-216-041-00	METAL CHIP	470 5% 1/10W	R339	1-216-049-00	METAL CHIP	1K 5% 1/10W
R137	1-216-049-00	METAL CHIP	1K 5% 1/10W (EXCEPT B/UB)	R355	1-216-037-00	METAL CHIP	330 5% 1/10W
R138	1-216-033-00	METAL CHIP	220 5% 1/10W	R356	1-216-105-00	METAL CHIP	220K 5% 1/10W
R141	1-216-049-00	METAL CHIP	1K 5% 1/10W	R357	1-216-049-00	METAL CHIP	1K 5% 1/10W
R144	1-216-121-00	METAL CHIP	1M 5% 1/10W	R358	1-216-085-00	METAL CHIP	33K 5% 1/10W
R154	1-216-039-00	METAL CHIP	390 5% 1/10W	R360	1-216-073-00	METAL CHIP	10K 5% 1/10W
R155	1-216-129-00	METAL CHIP	2.2M 5% 1/10W	R362	1-216-061-00	METAL CHIP	3.3K 5% 1/10W
R161	1-216-089-00	METAL CHIP	47K 5% 1/10W	R363	1-216-075-00	METAL CHIP	12K 5% 1/10W
R163	1-216-061-00	METAL CHIP	3.3K 5% 1/10W	R364	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R174	1-216-085-00	METAL CHIP	33K 5% 1/10W	R365	1-216-097-00	METAL CHIP	100K 5% 1/10W
R175	1-216-085-00	METAL CHIP	33K 5% 1/10W	R367	1-216-049-00	METAL CHIP	1K 5% 1/10W
R176	1-216-049-00	METAL CHIP	1K 5% 1/10W	R368	1-216-057-00	METAL CHIP	2.2K 5% 1/10W
R177	1-216-049-00	METAL CHIP	1K 5% 1/10W	R369	1-216-081-00	METAL CHIP	22K 5% 1/10W
R178	1-216-051-00	METAL CHIP	1.2K 5% 1/10W	R370	1-216-085-00	METAL CHIP	33K 5% 1/10W
R179	1-216-041-00	METAL CHIP	470 5% 1/10W	R372	1-216-033-00	METAL CHIP	220 5% 1/10W
R180	1-216-073-00	METAL CHIP	10K 5% 1/10W	R373	1-216-103-00	METAL CHIP	180K 5% 1/10W
R181	1-216-069-00	METAL CHIP	6.8K 5% 1/10W	R374	1-216-073-00	METAL CHIP	10K 5% 1/10W
R301	1-216-049-00	METAL CHIP	1K 5% 1/10W	R375	1-216-065-00	METAL CHIP	4.7K 5% 1/10W
R302	1-216-049-00	METAL CHIP	1K 5% 1/10W	R380	1-216-049-00	METAL CHIP	1K 5% 1/10W
R303	1-216-041-00	METAL CHIP	470 5% 1/10W	R381	1-216-037-00	METAL CHIP	330 5% 1/10W
R305	1-216-081-00	METAL CHIP	22K 5% 1/10W	R382	1-216-049-00	METAL CHIP	1K 5% 1/10W
R306	1-216-085-00	METAL CHIP	33K 5% 1/10W	R383	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
R307	1-216-049-00	METAL CHIP	1K 5% 1/10W	R384	1-216-689-11	METAL CHIP	39K 0.5% 1/10W
R308	1-216-051-00	METAL CHIP	1.2K 5% 1/10W	R385	1-216-073-00	METAL CHIP	10K 5% 1/10W
R309	1-216-049-00	METAL CHIP	1K 5% 1/10W	R386	1-216-049-00	METAL CHIP	1K 5% 1/10W
R310	1-216-045-00	METAL CHIP	680 5% 1/10W	R387	1-216-041-00	METAL CHIP	470 5% 1/10W
R311	1-216-049-00	METAL CHIP	1K 5% 1/10W	R388	1-216-053-00	METAL CHIP	1.5K 5% 1/10W
R312	1-216-061-00	METAL CHIP	3.3K 5% 1/10W	R390	1-216-073-00	METAL CHIP	10K 5% 1/10W
R313	1-216-041-00	METAL CHIP	470 5% 1/10W	R394	1-216-025-00	METAL CHIP	100 5% 1/10W
R314	1-216-045-00	METAL CHIP	680 5% 1/10W	R395	1-216-041-00	METAL CHIP	470 5% 1/10W
R315	1-216-049-00	METAL CHIP	1K 5% 1/10W	R399	1-216-073-00	METAL CHIP	10K 5% 1/10W
R316	1-216-097-00	METAL CHIP	100K 5% 1/10W	R401	1-216-049-00	METAL CHIP	1K 5% 1/10W (B)
R317	1-216-025-00	METAL CHIP	100 5% 1/10W	R402	1-216-049-00	METAL CHIP	1K 5% 1/10W (B)
R318	1-216-039-00	METAL CHIP	390 5% 1/10W	R403	1-216-049-00	METAL CHIP	1K 5% 1/10W (B)
R319	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R404	1-216-049-00	METAL CHIP	1K 5% 1/10W (B)
R320	1-216-069-00	METAL CHIP	6.8K 5% 1/10W	R405	1-216-049-00	METAL CHIP	1K 5% 1/10W (B)
R322	1-216-055-00	METAL CHIP	1.8K 5% 1/10W	R407	1-216-085-00	METAL CHIP	33K 5% 1/10W (B)
R323	1-216-061-00	METAL CHIP	3.3K 5% 1/10W	R408	1-216-081-00	METAL CHIP	22K 5% 1/10W (B)
R324	1-216-049-00	METAL CHIP	1K 5% 1/10W	R409	1-216-037-00	METAL CHIP	330 5% 1/10W (B)
R325	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (B/VC)	R410	1-216-017-00	METAL CHIP	47 5% 1/10W (B)
R326	1-216-059-00	METAL CHIP	2.7K 5% 1/10W (B/VC)	R411	1-216-053-00	METAL CHIP	1.5K 5% 1/10W (B)
R327	1-216-063-00	METAL CHIP	3.9K 5% 1/10W (B/VC)	R412	1-216-041-00	METAL CHIP	470 5% 1/10W (B)
R328	1-216-035-00	METAL CHIP	270 5% 1/10W	R413	1-216-049-00	METAL CHIP	1K 5% 1/10W (B)
R332	1-216-033-00	METAL CHIP	220 5% 1/10W	R414	1-216-075-00	METAL CHIP	12K 5% 1/10W (B)
R333	1-216-037-00	METAL CHIP	330 5% 1/10W	R415	1-216-053-00	METAL CHIP	1.5K 5% 1/10W (B)

Ref. No.	Part No.	Description	Remarks
R416	1-216-047-00	METAL CHIP 820 5%	1/10W (B)
R417	1-216-093-00	METAL CHIP 68K 5%	1/10W (B)
R418	1-216-097-00	METAL CHIP 100K 5%	1/10W (B)
R419	1-216-049-00	METAL CHIP 1K 5%	1/10W (B)
R420	1-216-049-00	METAL CHIP 1K 5%	1/10W (B)
R421	1-216-047-00	METAL CHIP 820 5%	1/10W (B)
R422	1-216-075-00	METAL CHIP 12K 5%	1/10W (B)
R423	1-216-041-00	METAL CHIP 470 5%	1/10W (B)
R425	1-216-061-00	METAL CHIP 3.3K 5%	1/10W (B)
R428	1-216-081-00	METAL CHIP 22K 5%	1/10W (B)
R429	1-216-079-00	METAL CHIP 18K 5%	1/10W (B)
R430	1-216-113-00	METAL CHIP 470K 5%	1/10W (B)
R431	1-216-049-00	METAL CHIP 1K 5%	1/10W (B)
R446	1-216-065-00	METAL CHIP 4.7K 5%	1/10W (B/VC)
R447	1-216-073-00	METAL CHIP 10K 5%	1/10W (B/VC)
R448	1-216-063-00	METAL CHIP 3.9K 5%	1/10W (B)
R449	1-216-081-00	METAL CHIP 22K 5%	1/10W (B/VC)
R450	1-216-057-00	METAL CHIP 2.2K 5%	1/10W (B/VC)
R451	1-216-065-00	METAL CHIP 4.7K 5%	1/10W (B)
R452	1-216-065-00	METAL CHIP 4.7K 5%	1/10W (B)
R454	1-216-109-00	METAL CHIP 330K 5%	1/10W (B/VC)
R460	1-216-049-00	METAL CHIP 1K 5%	1/10W (B/VC)
R461	1-216-059-00	METAL CHIP 2.7K 5%	1/10W (B/VC)
R462	1-216-089-00	METAL CHIP 47K 5%	1/10W (B)
R463	1-216-089-00	METAL CHIP 47K 5%	1/10W (B)
R464	1-216-049-00	METAL CHIP 1K 5%	1/10W (B)
R465	1-216-049-00	METAL CHIP 1K 5%	1/10W (B)
R466	1-216-089-00	METAL CHIP 47K 5%	1/10W (B)
R467	1-216-089-00	METAL CHIP 47K 5%	1/10W (B)
R468	1-216-083-00	METAL CHIP 27K 5%	1/10W (B)
R469	1-216-089-00	METAL CHIP 47K 5%	1/10W (B)
R470	1-216-073-00	METAL CHIP 10K 5%	1/10W (B)
R471	1-216-049-00	METAL CHIP 1K 5%	1/10W (B)
R478	1-216-073-00	METAL CHIP 10K 5%	1/10W (B)
R501	1-216-035-00	METAL CHIP 270 5%	1/10W
R502	1-216-051-00	METAL CHIP 1.2K 5%	1/10W
R503	1-216-059-00	METAL CHIP 2.7K 5%	1/10W
R504	1-216-069-00	METAL CHIP 6.8K 5%	1/10W
R505	1-216-051-00	METAL CHIP 1.2K 5%	1/10W
R511	1-216-045-00	METAL CHIP 680 5%	1/10W
R512	1-216-073-00	METAL CHIP 10K 5%	1/10W
R513	1-216-049-00	METAL CHIP 1K 5%	1/10W
R514	1-216-059-00	METAL CHIP 2.7K 5%	1/10W (B)
R515	1-216-057-00	METAL CHIP 2.2K 5%	1/10W (B)
R518	1-216-049-00	METAL CHIP 1K 5%	1/10W
R519	1-216-222-00	METAL GLAZE 10K 5%	1/8W
R520	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R521	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R522	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R523	1-216-059-00	METAL CHIP 2.7K 5%	1/10W

Ref. No.	Part No.	Description	Remarks
R524	1-216-059-00	METAL CHIP 2.7K 5%	1/10W
R527	1-216-073-00	METAL CHIP 10K 5%	1/10W
R528	1-216-049-00	METAL CHIP 1K 5%	1/10W
R529	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
R530	1-216-073-00	METAL CHIP 10K 5%	1/10W
R531	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R599	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
< VARIABLE RESISTOR >			
RV101	1-241-079-11	RES, ADJ, CARBON 4.7K	
RV102	1-241-079-11	RES, ADJ, CARBON 4.7K	
RV103	1-241-080-11	RES, ADJ, CARBON 10K (EXCEPT VC)	
RV103	1-241-079-11	RES, ADJ, CARBON 4.7K (VC)	
RV104	1-241-081-11	RES, ADJ, CARBON 22K	
RV105	1-241-081-11	RES, ADJ, CARBON 22K	
RV107	1-241-076-11	RES, ADJ, CARBON 1K	
RV108	1-241-080-11	RES, ADJ, CARBON 10K	
RV110	1-241-076-11	RES, ADJ, CARBON 1K	
RV301	1-241-076-11	RES, ADJ, CARBON 1K	
RV360	1-237-521-21	RES, ADJ, CARBON 100K	
RV361	1-241-076-11	RES, ADJ, CARBON 1K	
RV401	1-241-079-11	RES, ADJ, CARBON 4.7K (B)	
RV402	1-237-521-21	RES, ADJ, CARBON 100K (B)	
RV450	1-241-075-11	RES, ADJ, CARBON 470 (B/VC)	
< TRANSFORMER >			
T302	1-409-467-11	COIL (TRAP 7.8K)	
T450	1-409-467-11	COIL (TRAP 7.8K) (B/VC)	
< VIBRATOR >			
X301	1-577-651-11	VIBRATOR, CRYSTAL 4.43MHz	

*	A-6721-515-A TC-27 BOARD, COMPLETE (B MODEL)		

	(Ref. No. 18000 Series)		
< CAPACITOR >			
C102	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C103	1-126-301-11	ELECT 1uF	20% 50V
C104	1-126-301-11	ELECT 1uF	20% 50V
C105	1-163-117-00	CERAMIC CHIP 100PF	5% 50V
C106	1-163-133-00	CERAMIC CHIP 470PF	5% 50V
C107	1-124-638-11	ELECT 22uF	20% 10V
C108	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C109	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C110	1-126-177-11	ELECT 100uF	20% 10V
C111	1-163-031-11	CERAMIC CHIP 0.01uF	50V

TC-27

Ref. No.	Part No.	Description	Remarks
< DIODE >			
D101	8-719-400-18	DIODE MA152WK	
< DELAY LINE >			
DL101	1-415-313-00	DELAY LINE (1H)	
DL102	1-415-313-00	DELAY LINE (1H)	
< FILTER >			
FL101	1-236-312-11	FILTER, BAND PASS	
< IC >			
IC101	8-759-941-68	IC BA7131F	
IC102	8-752-035-00	IC CXA1227Q	
IC103	8-752-034-04	IC CXA1219M	
IC104	8-752-035-00	IC CXA1227Q	
IC105	8-752-034-04	IC CXA1219M	
IC106	8-759-710-29	IC NJM2235M	
IC107	8-759-008-67	IC MC14066BF	
< JUMPER RESISTOR >			
JR001	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR002	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR003	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR004	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR005	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR006	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR007	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR008	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR009	1-216-295-00	METAL CHIP 0 5% 1/10W	
JR011	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR012	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR013	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR014	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR015	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR016	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR017	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR018	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR019	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR020	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR021	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR022	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR023	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR024	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR025	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR026	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR027	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR028	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR029	1-216-296-00	METAL CHIP 0 5% 1/8W	
JR030	1-216-296-00	METAL CHIP 0 5% 1/8W	

Ref. No.	Part No.	Description	Remarks
< COIL >			
L102	1-408-421-00	INDUCTOR 100uH	
L103	1-408-408-00	INDUCTOR 8.2uH	
L104	1-408-408-00	INDUCTOR 8.2uH	
L105	1-408-410-00	INDUCTOR 12uH	
L106	1-408-409-00	INDUCTOR 10uH	
L107	1-408-409-00	INDUCTOR 10uH	
L108	1-408-410-00	INDUCTOR 12uH	
L109	1-408-408-00	INDUCTOR 8.2uH	
L110	1-408-408-00	INDUCTOR 8.2uH	
L111	1-408-410-00	INDUCTOR 12uH	
L112	1-408-409-00	INDUCTOR 10uH	
L113	1-408-409-00	INDUCTOR 10uH	
L114	1-408-410-00	INDUCTOR 12uH	
L115	1-408-421-00	INDUCTOR 100uH	
L116	1-408-421-00	INDUCTOR 100uH	
L117	1-408-421-00	INDUCTOR 100uH	
L119	1-410-509-11	INDUCTOR 10uH	
L120	1-410-509-11	INDUCTOR 10uH	
L121	1-408-422-00	INDUCTOR 120uH	
L122	1-408-426-00	INDUCTOR 270uH	
L123	1-410-520-11	INDUCTOR 82uH	
L124	1-410-507-11	INDUCTOR 6.8uH	
L125	1-410-520-11	INDUCTOR 82uH	
L126	1-410-507-11	INDUCTOR 6.8uH	
< VARIABLE COIL >			
LV101	1-408-532-00	COIL, VARIABLE	
LV102	1-408-530-00	COIL, VARIABLE	
LV103	1-408-532-00	COIL, VARIABLE	
LV104	1-408-532-00	COIL, VARIABLE	
LV105	1-408-530-00	COIL, VARIABLE	
LV106	1-408-532-00	COIL, VARIABLE	
< TRANSISTOR >			
Q101	8-729-216-22	TRANSISTOR 2SA1162	
Q102	8-729-920-74	TRANSISTOR 2SC2412K-QR	
Q103	8-729-920-74	TRANSISTOR 2SC2412K-QR	
Q104	8-729-920-74	TRANSISTOR 2SC2412K-QR	
Q105	8-729-920-74	TRANSISTOR 2SC2412K-QR	
Q107	8-729-920-74	TRANSISTOR 2SC2412K-QR	
Q109	8-729-920-74	TRANSISTOR 2SC2412K-QR	
Q110	8-729-920-74	TRANSISTOR 2SC2412K-QR	
Q111	8-729-920-74	TRANSISTOR 2SC2412K-QR	
Q112	8-729-920-74	TRANSISTOR 2SC2412K-QR	

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
Q113	8-729-920-74	TRANSISTOR 2SC2412K-QR		R141	1-216-077-00	METAL CHIP 15K 5% 1/10W	
Q114	8-729-920-74	TRANSISTOR 2SC2412K-QR		R142	1-216-041-00	METAL CHIP 470 5% 1/10W	
Q115	8-729-920-74	TRANSISTOR 2SC2412K-QR		R143	1-216-129-00	METAL CHIP 2. 2M 5% 1/10W	
Q116	8-729-216-22	TRANSISTOR 2SA1162		R144	1-216-081-00	METAL CHIP 22K 5% 1/10W	
Q117	8-729-920-74	TRANSISTOR 2SC2412K-QR		R145	1-216-121-00	METAL CHIP 1M 5% 1/10W	
Q118	8-729-216-22	TRANSISTOR 2SA1162		R146	1-216-039-00	METAL CHIP 390 5% 1/10W	
Q119	8-729-920-74	TRANSISTOR 2SC2412K-QR		R150	1-216-077-00	METAL CHIP 15K 5% 1/10W	
Q120	8-729-216-22	TRANSISTOR 2SA1162		R151	1-216-089-00	METAL CHIP 47K 5% 1/10W	
Q121	8-729-920-74	TRANSISTOR 2SC2412K-QR		R152	1-216-089-00	METAL CHIP 47K 5% 1/10W	
Q122	8-729-901-01	TRANSISTOR DTC144EK		R153	1-216-061-00	METAL CHIP 3. 3K 5% 1/10W	
Q123	8-729-920-74	TRANSISTOR 2SC2412K-QR		R154	1-216-685-11	METAL CHIP 27K 0. 5% 1/10W	
Q124	8-729-216-22	TRANSISTOR 2SA1162		R155	1-216-049-00	METAL CHIP 1K 5% 1/10W	
Q125	8-729-901-01	TRANSISTOR DTC144EK		R156	1-216-043-00	METAL CHIP 560 5% 1/10W	
< RESISTOR >				R162	1-216-685-11	METAL CHIP 27K 0. 5% 1/10W	
R101	1-216-043-00	METAL CHIP 560 5% 1/10W		R163	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R102	1-216-041-00	METAL CHIP 470 5% 1/10W		R164	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R103	1-216-041-00	METAL CHIP 470 5% 1/10W		R168	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R104	1-216-057-00	METAL CHIP 2. 2K 5% 1/10W		R169	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R105	1-216-039-00	METAL CHIP 390 5% 1/10W		R170	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R106	1-216-039-00	METAL CHIP 390 5% 1/10W		R171	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R107	1-216-039-00	METAL CHIP 390 5% 1/10W		R172	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R108	1-216-065-00	METAL CHIP 4. 7K 5% 1/10W		R173	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R109	1-216-097-00	METAL CHIP 100K 5% 1/10W		R174	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R110	1-216-075-00	METAL CHIP 12K 5% 1/10W		R175	1-216-089-00	METAL CHIP 47K 5% 1/10W	
R111	1-216-060-00	METAL GLAZE 3K 5% 1/10W		R176	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R112	1-216-067-00	METAL CHIP 5. 6K 5% 1/10W		R177	1-216-051-00	METAL CHIP 1. 2K 5% 1/10W	
R113	1-216-049-00	METAL CHIP 1K 5% 1/10W		R178	1-216-085-00	METAL CHIP 33K 5% 1/10W	
R114	1-216-049-00	METAL CHIP 1K 5% 1/10W		R179	1-216-077-00	METAL CHIP 15K 5% 1/10W	
R115	1-216-060-00	METAL GLAZE 3K 5% 1/10W		R180	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R116	1-216-067-00	METAL CHIP 5. 6K 5% 1/10W		R181	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R121	1-216-129-00	METAL CHIP 2. 2M 5% 1/10W		R182	1-216-041-00	METAL CHIP 470 5% 1/10W	
R122	1-216-081-00	METAL CHIP 22K 5% 1/10W		R184	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R123	1-216-121-00	METAL CHIP 1M 5% 1/10W		R185	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R124	1-216-039-00	METAL CHIP 390 5% 1/10W		R186	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R125	1-216-057-00	METAL CHIP 2. 2K 5% 1/10W		R187	1-216-059-00	METAL CHIP 2. 7K 5% 1/10W	
R126	1-216-039-00	METAL CHIP 390 5% 1/10W		R188	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R127	1-216-039-00	METAL CHIP 390 5% 1/10W		R189	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R128	1-216-039-00	METAL CHIP 390 5% 1/10W		R190	1-216-085-00	METAL CHIP 33K 5% 1/10W	
R129	1-216-065-00	METAL CHIP 4. 7K 5% 1/10W		R191	1-216-077-00	METAL CHIP 15K 5% 1/10W	
R130	1-216-097-00	METAL CHIP 100K 5% 1/10W		R192	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R131	1-216-075-00	METAL CHIP 12K 5% 1/10W		R193	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R132	1-216-060-00	METAL GLAZE 3K 5% 1/10W		R194	1-216-041-00	METAL CHIP 470 5% 1/10W	
R133	1-216-067-00	METAL CHIP 5. 6K 5% 1/10W		R195	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R134	1-216-067-00	METAL CHIP 5. 6K 5% 1/10W		R196	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R135	1-216-049-00	METAL CHIP 1K 5% 1/10W		R197	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R136	1-216-049-00	METAL CHIP 1K 5% 1/10W		R198	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R137	1-216-060-00	METAL GLAZE 3K 5% 1/10W		R199	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R138	1-216-067-00	METAL CHIP 5. 6K 5% 1/10W		R200	1-216-063-00	METAL CHIP 3. 9K 5% 1/10W	
R139	1-216-077-00	METAL CHIP 15K 5% 1/10W		R201	1-216-689-11	METAL CHIP 39K 0. 5% 1/10W	
R140	1-216-069-00	METAL CHIP 6. 8K 5% 1/10W		R202	1-216-073-00	METAL CHIP 10K 5% 1/10W	

Ref. No.	Part No.	Description	Remarks
R203	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R204	1-216-081-00	METAL CHIP 22K 5% 1/10W	
R205	1-216-295-00	METAL CHIP 0 5% 1/10W	
R251	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R252	1-216-049-00	METAL CHIP 1K 5% 1/10W	
< VARIABLE RESISTOR >			
RV101	1-241-083-11	RES, ADJ, CARBON 47K	
RV102	1-241-080-11	RES, ADJ, CARBON 10K	
RV103	1-241-080-11	RES, ADJ, CARBON 10K	
RV104	1-241-083-11	RES, ADJ, CARBON 47K	
RV105	1-241-080-11	RES, ADJ, CARBON 10K	
RV106	1-241-080-11	RES, ADJ, CARBON 10K	
< VIBRATOR >			
X101	1-577-117-21	OSCILLATOR, CRYSTAL 4.433619MHz	

MISCELLANEOUS			

1	1-466-749-11	SWITCH BLOCK, CONTROL (AEP/B/E/NC/NP)	
1	1-466-749-21	SWITCH BLOCK, CONTROL (VC)	
1	1-466-749-51	SWITCH BLOCK, CONTROL (UB)	
△66	1-413-756-11	POWER BLOCK (SR-425) (AEP/B/E/NC/NP)	
△66	1-413-757-11	POWER BLOCK (SR-426) (UB)	
△66	1-413-758-11	POWER BLOCK (SR-427) (VC)	
70	1-696-439-11	WIRE, FLAT TYPE (10 CORE)	
71	1-696-440-11	WIRE, FLAT TYPE (16 CORE)	
124	1-696-438-11	WIRE, FLAT TYPE (13 CORE) (NP/VC)	
260	1-543-647-11	HEAD, FE	
264	1-550-785-11	DRUM ASSY (DZH-52AR)	
306	1-692-062-11	SWITCH, ROTARY	
336	8-835-489-01	MOTOR, DC U-26K	
* 343	1-633-460-11	PC BOARD, CA-41	

Ref. No.	Part No.	Description	Remarks
ACCESSORIES & PACKING MATERIALS			

	1-693-178-11	REMOTE COMMANDER (RMT-V127)	
*	3-948-135-01	CUSHION (UPPER)	
*	3-948-136-01	CUSHION (LOWER)	
*	3-948-142-01	INDIVIDUAL CARTON (EXCEPT B)	
*	3-948-142-11	INDIVIDUAL CARTON (B)	
	1-551-513-00	CORD, CONNECTION (PAL)	
△	1-574-056-11	CORD, POWER (VC)	
△	1-575-131-11	CORD, POWER (AEP/B/E/NC/NP)	
	1-575-334-11	CORD, CONNECTION (A/V)	
△	1-590-866-21	CORD, POWER (UB)	
*	3-738-213-01	CASE, ACCESSORY	
	3-755-135-11	MANUAL, INSTRUCTION (ENGLISH) (UB/E)	
	3-755-135-41	MANUAL, INSTRUCTION (DUTCH, ITALIAN) (AEP)	
	3-755-135-51	MANUAL, INSTRUCTION (FRENCH, GERMANY, ITALIAN) (VC)	
	3-755-135-61	MANUAL, INSTRUCTION (SWEDISH, PORTUGUESE, DANISH) (NC)	
	3-755-135-71	MANUAL, INSTRUCTION (DUTCH, FRENCH, GERMAN) (NC)	
	3-755-135-81	MANUAL, INSTRUCTION (SPANISH) (NP)	
	3-755-135-91	MANUAL, INSTRUCTION (FRENCH) (B)	

HARDWARE LIST			

#1	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3	
#2	7-685-648-79	SCREW +BVTP 3X12 TYPE2 IT-3	
#3	7-682-547-04	SCREW +BVTT 3X6 (S)	
#4	7-621-255-25	SCREW +PTI 2X4 (S)	
#5	7-685-650-79	SCREW +BVTP 3X16 TYPE2 IT-3	
#6	7-621-732-08	SCREW	
#7	7-685-647-79	SCREW +BVTP 3X10 TYPE2 IT-3	
#8	7-682-548-04	SCREW +P 3X8	
#9	7-682-546-04	SCREW +P 3X5	
#10	7-628-254-00	SCREW +PS 2.6X5	
#11	7-624-102-04	STOP RING 1.5, TYPE-E	
#12	7-627-552-08	SCREW, PRECISION +P 1.7X2.5	

<p>Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.</p>	<p>Note: Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.</p>
--	---

MEMO

A series of horizontal dashed lines for writing.

SECTION 7 ELECTRICAL ADJUSTMENTS

During the adjustment, see the Parts Arrangement Diagram relevant to the adjustment on page 210.

7-1. PRE-ADJUSTMENT PREPARATIONS

Necessary items and indications for total adjustment of electric circuit of this machine will be described in this chapter.

7-1-1. Instruments to be Used

- 1) Color TV
- 2) Oscilloscope 1 or 2 phenomena, band more than 15 MHz, delay mode, as provided.
- 3) Frequency counter (min, 8 digits)
- 4) PAL pattern generator
- 5) SECAM pattern generator (SLV-815B only)
- 6) Digital voltmeter
- 7) Audio level meter
- 8) Audio generator
- 9) Attenuator
- 10) Distortion factor meter
- 11) Voice multiple signal generator
- 12) Alignment tape
Part code: H7099052H (MH-2)
- 13) HiFi alignment tape

7-1-2. Connection

Unless otherwise specified, connect and adjust the measuring instruments as shown in the following diagram.




Fig. 7-1.

7-1-3. Setup for Adjustment

In this adjustment, PAL pattern generator is connected with LINE 2 input signal terminal. When check to tuner, connected AERIAL terminal. Check that the amplitudes of video signal SYNC signal, of picture portions, and of burst signals are flat at approximately 0.3, 0.7 and 0.3V, respectively, and that the level ratio of the burst signal and "red" signal are 0.30:0.66. Fig. 7-2. shows video signals (color bars) used in adjusting the video section.




Fig. 7-2.

7-1-4. Alignment Tape (MH-2)

	Time	Video signal	Audio signal
1	10 min	Stair-step	6 kHz
2	5 min	—	3 kHz
3	10 min	Color bar	1 kHz
4	3 min	RF sweep	—

Table 7-1.

7-1-5. Specified I/O Level and Impedance

Input/output terminal

Video inputs	LINE IN: phono jacks EURO-AV: 21-pin (Pin ②) 1 V _{p-p} , 75Ω, unbalanced, sync negative
Audio inputs	LINE IN: phono jacks 47 kΩ, -7.5 dBs (0 dBs=0.775 V _{rms}) EURO-AV: 21-pin (Pin ② and ⑥) More than 10 kΩ, -4 dBs
Video outputs	LINE OUT: phono jack EURO-AV: 21-pin (Pin ⑩) 1 V _{p-p} , 75Ω, unbalanced sync negative
Audio outputs	LINE OUT: phono jack -7.5 dBs at load impedance 47 kΩ Output impedance: less than 10 kΩ EURO-AV: 21-pin (Pins ① and ③) Output impedance: less than 1 kΩ -4 dBs with 10 kΩ load

7-1-6. Operating Method When the Front Panel Removed

When adjust with the front panel (SW BLOCK, JOG/SHUTTLE, TK-17 board and TK-18 board) removed, connect the resistors as shown below and operate with the remote commander.





Fig. 7-3.

7-1-7. Adjusting Sequence

Make the electrical adjustment in the following sequence.



7-2. POWER SUPPLY CHECK (POWER BLOCK)

Mode	E-E
Measuring instrument	Digital voltmeter
UNSW 6V check	
Measurement point	Pin ⑤ of CN1
Specified value	$6 \pm 0.25\text{Vdc}$
UNSW -30V check	
Measurement point	Pin ⑩ of CN2
Specified value	$-30.0 \pm 2.5\text{Vdc}$
UNSW 6V check	
Measurement point	Pin ⑩ of CN2
Specified value	$6.0 \pm 0.6\text{Vdc}$
SW 5V check	
Measurement point	Pin ⑥ of CN1
Specified value	$5.00 \pm 0.15\text{Vdc}$
SW 9V check	
Measurement point	Pin ④ of CN1
Specified value	$9.0 \pm 0.3\text{Vdc}$
UNSW 12V check	
Measurement point	Pin ③ of CN1
Specified value	$12.0 \pm 0.1\text{Vdc}$
MTR 12V check	
Measurement point	Pin ① of CN2
Specified value	$12.0 \pm 0.3\text{Vdc}$
UNSW 35V check	
Measurement point	Pin ① of CN1
Specified value	$35\text{V} \pm 3.0\text{Vdc}$

Checking method:

- 1) Confirm that each voltage meets its specified value.

POWER BLOCK (Conductor side)




Fig. 7-4.

7-3. SYSTEM CONTROL ADJUSTMENT

7-3-1. Clock Adjustment (MF-167 BOARD)

Measurement point	Pin ③ of IC601
Measuring Instrument	Interval counter
Adjusting Element	CV601
Specified Value	0.1249995 ± 0.0000005 sec

Connection:

- 1) Make the circuit below and supply the generated voltage to IC601 pin ④.




Fig. 7-5-1.

Adjusting method:

- 1) Pass a 9-state binary counter through Pin ③ of IC601 to divide the 4096 Hz frequency nine times and transform to 8 Hz. Measure the cycle.
- 2) Adjust CV601 so that an 8 Hz cycle equals 0.1249995 ± 0.0000005 sec.

Note: Do not adjust CV601 except when replacing microcomputers.




Fig. 7-5-2.

7-4. SERVO SYSTEM ADJUSTMENT

7-4-1. Switching Position Adjustment (MA-140 Board)

Mode	PB
Signal	Alignment tape: SP stair-step section
Measurement point	CH1 : VIDEO OUT (LINE OUT) CH2: Pin ② of CN919(RF SWP)/MA-140
Measuring Instrument	Oscilloscope
Adjusting Element	RV401
Specified Value	$6.5 \pm 0.5H$ ($416 \pm 32 \mu\text{sec}$)

Adjusting method:

- 1) Once set to STOP mode, then to PB mode.
- 2) Check that the switching position is $6.5 \pm 0.5H$. ($416 \pm 32 \mu\text{sec}$)
If not meet the specified value, turn RV401 and repeat steps 1) to 2).




Fig. 7-6.

7-5. VIDEO SYSTEM ADJUSTMENT

Adjust the video system in the following sequence as a rule. The color video signal supplied from the pattern generator is used as a video input signal for video system adjustment in the recording mode.

Make sure that sync and color burst signals meet requirements specified at setup of adjustment shown in Fig. 7-2.

[Adjusting sequence]

- 7-5-1. Playback Y Signal Level Adjustment
- 7-5-2. Y Signal NR Level Adjustment
- 7-5-3. Sync AGC Adjustment
- 7-5-4. Sync Tip Carrier Set and Deviation Adjustment
- 7-5-5. White Clip, Dark Clip Adjustment
- 7-5-6. Recording Y Signal Level Adjustment
- 7-5-7. Recording Chroma Level Adjustment
- 7-5-8. PAL JOG AFC Adjustment
- 7-5-9. 0.5H CCD Level Adjustment
- 7-5-10. SECAM Discrimination Adjustment

7-5-1. Playback Y Signal Level Adjustment (YC-124 Board)

Mode	PB
Signal	Alignment tape: SP color bar section
Measurement Point	VIDEO LINE OUT terminal
Measuring Instrument	Oscilloscope
Adjusting Element	RV108
Specified Value	1.00 ± 0.05 Vp-p

- Note:** 1) Make this adjustment with the EDIT ON/OFF button set to off.
2) VIDEO LINE OUT terminal must be terminated at $75\Omega \pm 1\%$.

Adjusting method:

- 1) With RV108, adjust the VIDEO signal level to 1.00 ± 0.05 Vp-p.




Fig. 7-7.

7-5-2. Y Signal NR Level Adjustment (YC-124 Board)

Mode	PB
Signal	Alignment tape: SP color bar section
Measurement Point	Pin @ of IC101
Measuring Instrument	Oscilloscope
Adjusting Element	RV107
Specified Value	Less than 30mVp-p or minimum

Adjusting method:

- 1) Adjust to eliminate level differences for each H step with RV107.




Fig. 7-8.

7-5-3. Sync AGC Adjustment (YC-124 Board)

Mode	E-E
Signal	Color bar
Measurement Point	VIDEO LINE OUT terminal
Measuring Instrument	Oscilloscope
Adjusting Element	RV101
Specified Value	1.00 ± 0.05 Vp-p

Note: VIDEO LINE OUT terminal must be terminated at 75Ω .

Adjusting method:

- 1) With RV101, adjust the VIDEO signal level to 1.00 ± 0.05 Vp-p.




Fig. 7-9. SYNC AGC adjustment

7-5-4. Sync Tip Carrier Set and Deviation Adjustment (YC-124 Board)

Before starting the adjustment, be sure to check that recording Y signal level adjustment has been completed.

Sync tip carrier set	
Mode	E-E
Signal	No signal (Note 2)
Measurement Point	Pin ② of IC101
Measuring Instrument	Frequency counter
Adjusting Element	RV103
Specified Value	$3.80 \pm 0.05\text{MHz}$
Deviation adjustment	
Mode	REC and PB
Signal	Colour bars
Measurement Point	VIDEO LINE OUT terminal
Measuring Instrument	Oscilloscope
Adjusting Element	RV102
Specified Value	$1.00 \pm 0.05\text{Vp-p}$

Note 1) VIDEO LINE OUT terminal must be terminated at 75Ω .

2) To make no signal input, insert a shorting plug into VIDEO LINE IN 2 terminal.

Adjusting method:

- 1) Make a no signal state and select the E-E mode.
- 2) Connect the frequency counter to the Pin ② of IC101 and adjust to $3.80 \pm 0.05\text{MHz}$ with RV103.
- 3) Input the color bar signal to make recording.
- 4) Playback the recorded tape portion and check that the playback Y signal level is $1.00 \pm 0.05\text{Vp-p}$.




Fig. 7-10. Deviation adjustment

- 5) When the specified value is not met, input the color bar signal to select the E-E mode. Adjust RV102 to correct a playback Y signal level error, and then, repeat the steps 1) through 4) above.

7-5-5. White Clip, Dark Clip Adjustments (YC-124 Board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin ② of IC101
Measuring Instrument	Oscilloscope
Adjusting Element	White clip : RV105 Dark clip : RV104
Specified Value	White clip : $180 \pm 10\%$ Dark clip : $40 \pm 10\%$

Adjusting method:

- 1) With RV105, adjust the white clip level to $180 \pm 10\%$ of the white level (100%)
- 2) With RV104, adjust the dark clip level to $40 \pm 10\%$ of the white level (100%)




Fig. 7-11.

7-5-6. Recording Y Signal Level Adjustment (YC-124 Board)

Mode	REC
Signal	No signal
Measurement Point	Pin ③ of CN301 (YC-124)
Measuring Instrument	Oscilloscope
Adjusting Element	RV110 (YC-124 board)
Specified Value	$300 \pm 10\text{mV}$

Adjusting method:

- 1) With RV110, adjust the Y REC RF signal level to $300 \pm 10\text{mV}$




Fig. 7-12.

7-5-7. Recording Chroma Level Adjustment (YC-124 Board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin ⑧ of CN301
Measuring Instrument	Oscilloscope
Adjusting Element	RV301
Specified Value	120 ± 10 mVp-p




Fig. 7-13.

7-5-8. PAL JOG AFC Adjustment (YC-124 Board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin ⑩ of IC360
Measuring Instrument	Digital voltmeter
Adjusting Element	RV360
Specified Value	2.65 ± 0.05 Vdc

Adjusting method :

- 1) Adjust RV360 so that the voltage at Pin ⑩ of IC360 become 2.65 ± 0.05 Vdc.
At this time confirm that the cycle of delta wave at Pin ⑩ of IC360 is $32 \mu\text{sec}$.




Fig. 7-14.

7-5-9. 0.5H CCD Level Adjustment (YC-124 Board)

Mode	E-E
Signal	Color bar
Measurement Point	Pin ① of IC362
Measuring Instrument	Oscilloscope
Adjusting Element	RV361
Specified Value	Same signal level with Pin ⑥ of IC362.

Adjusting method :

- 1) Measure the signal level at Pin ⑥ of IC362.
(Approx. 2 Vp-p)
- 2) Adjust RV361 so that the signal levels at Pins ① and ⑥ of IC362 become same.




Fig. 7-15.

7-5-10. SECAM Discrimination Adjustment (YC-124 Board) (SLV-825B Only)

Mode	E-E
Signal	SECAM Color bar
Measurement Point	Pin ⑨ of IC450
Measuring Instrument	Oscilloscope
Adjusting Element	RV450
Specified Value	4.5 ± 0.1 Vp-p

Adjusting method :

- 1) Adjust RV450 so that the amplitude of $1/2$ fH waveform becomes 4.5 ± 0.1 Vp-p.




Fig. 7-16.

**7-5-11. SECAM Sync. Gate Timing Adjustment
(YC-124 Board)**

Mode	E-E
Signal	SECAM Colour bars
Measurement Point	CH1 : VIDEO OUTPUT CH2 : CN301 Pin⑧ (YC-124 board)
Measuring Instrument	Osilloscope
Adjusting Element	RV402
Speified Value	$T_2 = 0 \pm 0.3 \mu\text{sec}$

Adjusting method :

- 1) Adjust with RV402 so that the color bar signal on VIDEO OUTPUT terminal becomes to the specified value.




Fig. 7-17.

**7-5-12. SECAM Bell Filter Adjustment
(YC-124 Board)**

Mode	PB
Signal	SECAM Colour bars
Measurement Point	IC401⑤
Measuring Instrument	Osilloscope
Adjusting Element	FL402
Speified Value	Same level of colour bars

Adjusting method :

- 1) Adjust FL402 so that levels of colour bars become the same.




Fig. 7-18.

**7-5-13. SECAM Recording Chroma Level Adjustment
(YC-124 Board)**

Mode	E-E
Signal	SECAM Colour bars
Measurement Point	CN301 ⑧
Measuring Instrument	Osilloscope
Adjusting Element	RV401
Speified Value	$100 \pm 10\text{mVp-p}$




Fig. 7-19.

7-6. DIGITAL PICTURE AND CHARACTER GENERATOR SYSTEM ADJUSTMENTS

- Connect the monitor TV to EURO-AV connector (Pin ① of CNJ902 on MA-140 board), then perform the adjustment.




Fig. 7-20.

7-6-1. Read Clock Adjustment (DG-11 Board)

Mode	E-E (EDIT MONITOR)
Signal	Color bar
Measurement Point	EURO AV IN/OUT connector
Measuring Instrument	Monitor TV
Adjusting Element	T102
Specified Value	A=B

Adjusting method:

- 1) Adjust T102 so that the child pictures are positioned symmetrically.

Note: Adjust the character position following the steps in "Character Position Adjustment".




Fig. 7-21.

7-6-2. Write Clock Adjustment (DG-11 Board)

Mode	E-E
Signal	Color bar
Measurement Point	EURO AV IN/OUT connector
Measuring Instrument	Monitor TV
Adjusting Element	T101
Specified Value	A=B

Adjusting method:

- 1) Adjust T101 so that the image center of the child picture in INPUT side matches with the child picture frame center.




Fig. 7-22.

7-6-3. TINT Adjustment (DG-11 Board)

Mode	E-E (EDIT MONITOR)
Signal	Color bar
Measurement Point	Pin ⑩ of IC102
Measuring Instrument	Oscilloscope
Adjusting Element	RV104
Specified Value	A=B

Adjusting method:

- 1) Adjust RV104 so that the level A and level B become same.




Fig. 7-23.

7-6-4. Clamp Level Adjustment (DG-11 Board)

Mode	PB (P in P)
Signal	Color bar
Measurement Point	Pin ⑥ of CN101
Measuring Instrument	Oscilloscope
Adjusting Element	RV101
Specified Value	A=0V

Adjusting method:

- 1) Adjust RV101 so that the pedestal levels of parent picture match with the levels of child picture.




Fig. 7-24.

7-6-5. Hue and Color Level Adjustment (DG-11 Board)

Mode	E-E (P in P)
Signal	Color bar
Measurement Point	EURO AV IN/OUT connector
Measuring Instrument	Vectorscope
Adjusting Element	Hue : RV103 Color Level : RV102
Specified Value	The chroma luminance points in parent and child pictures should be overlapped.

Adjusting method:

- 1) Turn RV102 and RV103 alternately and match the chroma luminance point (higher luminance) of parent picture with the chroma luminance point (lower luminance) of child picture.

7-6-6. Character Generator Clock Check (CG-15 Board)

Mode	E-E
Signal	No signal
Measurement Point	Pin ② of IC602
Measuring Instrument	Frequency counter
Specified Value	17.734476MHz ± 100Hz

Note: Attach 10 kΩ resistor to tip of the probe.

Checking method:

- 1) Confirm that the clock oscillation frequency is 17.734476 MHz ± 100 Hz.

7-6-7. AFC Adjustment (CG-15 Board)

Mode	E-E
Signal	No signal
Measurement Point	Pin ⑧ of IC603
Measuring Instrument	Oscilloscope
Adjusting Element	RV601
Specified Value	15625 ± 50Hz

Connection :

- 1) Connect Pins ① and ⑨ of IC603 with 1kΩ resistance.

Adjusting method :

- 1) Adjust RV601 so that the oscillation frequency is 15625 ± 50Hz.

7-6-8. Character Position Adjustment (CG-15 Board)

Mode	E-E (EDIT MONITOR)
Signal	Color bar
Measurement Point	EURO AV IN/OUT connector
Measuring Instrument	Monitor TV
Adjusting Element	CV601
Specified Value	A=B

Note: Perform this adjustment after "Write Clock Adjustment".

Adjusting method :

- 1) Adjust CV601 so that the arrow mark is positioned at the center between the child pictures.




Fig. 7-25.

7-7. AUDIO SYSTEM ADJUSTMENTS

- Adjust the audio system in the LP mode, unless otherwise specified.
Use the alignment tape.
- Adjust both Lch and Rch.
- Audio system adjustments consist of section 7-7-1. Hi-Fi Audio adjustment and 7-7-2. Normal Audio Adjustment.

[Connection]




Fig. 7-26.

7-7-1. Hi-Fi Audio System Adjustment

- Set Switches and knobs to the following positions to make adjustment unless otherwise specified.
INPUT SELECT switch..... LINE 2
REC LEVEL knob..... Set to -21 dBs.
- When the tuner block is obstructive for adjustment, remove it.

[Adjusting sequence]

1. NTSC VCO fo adjustment
2. PAL VCO fo adjustment
3. NTSC BPF fo adjustment
4. PAL BPF fo adjustment
5. AF Switching Position adjustment
6. Hi-Fi/Normal Detect adjustment
7. Playback Level adjustment
8. Record VR (Left channel) Control adjustment
9. Record VR (Right channel) Control adjustment

1. NTSC VCO f_0 adjustment (HF-26 board)

Mode	Recording, NTSC mode
Signal	No signal (HF-26 CN202 Pin ②:L)
Measuring instrument	Frequency counter
LEFT channel (1.3 MHz) Adjustment	
Measurement point	IC201 Pin ⑨/HF-26
Adjusting element	RV202
Specified value	1.300 MHz \pm 1 KHZ
RIGHT channel (1.7 MHz) Adjustment	
Measurement point	IC201 Pin ⑩/HF-26
Adjusting element	RV205
Specified value	1.700 MHz \pm 1 kHz

Note: Connect the frequency counter through a probe of high input impedance (more than 10 M Ω) and low capacity (10 pF or less).

Checking method:

- 1) Connect the frequency counter to each measurement point.
- 2) Confirm that each frequency meet its specified value.

2. PAL VCO f_0 adjustment (HF-26 board)

Mode	Recording, PAL mode
Signal	No signal (HF-26 CN202 Pin ②:H)
Measuring instrument	Frequency counter
LEFT channel (1.4 MHz) Adjustment	
Measurement point	IC201, Pin ⑨/HF-26
Adjusting element	RV207
Specified value	1.400 MHz \pm 1 kHz
RIGHT channel (1.8 MHz) Adjustment	
Measurement point	IC201, Pin ⑩
Adjusting element	RV209
Specified value	1.800 MHz \pm 1 kHz

Note: Connect the frequency counter through a probe of high input impedance (more than 10 M Ω) and low capacity (10 pF or less).

Checking method:

- 1) Connect the frequency counter to each measurement point.
- 2) Confirm that each frequency meet its specified value.

3. NTSC BPF f_0 adjustment (HF-26 board)

Mode	NTSC, PB mode
Signal	1.720 MHz sine wave
Measuring instrument	Oscilloscope
Measurement point	HF-26, IC201, Pin ⑩
Adjusting element	RV204
Specified value	Minimum amplitude as shown

Adjusting method:

- 1) Set the NTSC PB switch to ON.
- 2) Input the sine wave signal of 1.720 MHz, 70 mV to CN202 Pin ⑨ from signal generator. (no modulated signal)
- 3) Adjust RV204 for the minimum amplitude.




Fig. 7-27.

4. PAL BPF f_0 adjustment (HF-26 board)

Mode	PAL, PB mode
Signal	1.840 MHz sine wave
Measuring instrument	Oscilloscope
Measurement point	HF-26, IC201, Pin ⑩
Adjusting element	RV208
Specified value	Minimum amplitude as shown

Adjusting method:

- 1) Input the sine wave signal of 1.840 MHz, 70 mV CN202 Pin ⑩ from signal generator. (no modulated signal)
- 2) Adjust RV208 for the minimum amplitude.




Fig. 7-28.

5. AF Switching Position adjustment (MA-140 board)

Mode	PB
Signal	Alignment tape (MH-2)
Measuring instrument	Oscilloscope
Measurement point	MA-140, CN901, Pin ⑥
Adjusting element	RV400
Specified value	Minimum amplitude

Adjusting method :

- 1) Playback the alignment tape (MH-2).
- 2) Press MANUAL of TRACKING button. Press both [+] and [-] keys of TRACKING simultaneously to obtain the center position of TRACKING.
- 3) Trigger oscilloscope by RP-147, CN803 Pin ⑤ (RF SW'G pulse).
- 4) Adjust RV400 to minimize A.




Fig. 7-29.

6. Hi-Fi/Normal Detect adjustment (MA-140 board)

Mode	PB
Signal	Alignment tape (HiFi 400 Hz)
Measuring instrument	Oscilloscope
Measurement point	MA-140, CN901, Pin ⑥
Adjusting element	RV201
Specified value	300 mV ± 10 mVp-p

Adjusting method :

- 1) Press MANUAL of TRACKING button. Obtain the maximum AFM RF level by adjusting TRACKING control.
- 2) Connect oscilloscope to MA-140, CN901 Pin ⑥, and is triggered by RP-147, CN803 Pin ⑤ (RF SW'G pulse).
- 3) Adjust RV201/MA-140 for 300 mV ± 10 mVp-p, in the side B.




Fig. 7-30.

7. Playback Level adjustment (HF-26 board)

Mode	PB
Signal	Alignment tape (HiFi 400 Hz)
Measurement point	Lch : AUDIO LINE OUT L Rch : AUDIO LINE OUT R
Measuring instrument	Audio level meter
Adjusting element	Lch : RV201 Rch : RV206
Specified value	-7.5 ± 0.1 dBs

Adjusting method :

- 1) Adjust a playback level to -7.5 ± 0.1 dBs for both L and R channels with RV201 and RV206 respectively.

8. Record VR (Left channel) Control adjustment (MF-167 board)

Mode	Recording
Signal	No signal
Measuring instrument	Digital voltmeter
Measurement point	MF-167, CN601, Pin ⑩
Adjusting element	RV603
Specified value	(voltage at CN601, Pin ⑩) × ½ ± 0.05 V

Adjusting method :

- 1) Set the RECORD VR (RV601) into the mechanical center [click] position.
- 2) Adjust RV603 to obtain that Pin ⑩ = [voltage at CN601 Pin ⑩ = LEVEL VR Vcc] × ½ ± 0.05 V

9. Record VR (Right channel) Control adjustment (MF-167 board)

Mode	Recording
Signal	No signal
Measuring instrument	Digital voltmeter
Measurement point	MF-167, CN601, Pin ⑩
Adjusting element	RV604
Specified value	(voltage at CN601, Pin ⑩) × ½ ± 0.05 V

Adjusting method :

- 1) Set the RECORD VR (RV602) into the mechanical center [click] position.
- 2) Adjust RV604 so that Pin ⑩ = [voltage at CN601 Pin ⑩ = LEVEL VR Vcc] × ½ ± 0.05 V

7-7-2. Normal Audio System Adjustment

- Make adjustment in the SP mode, unless otherwise specified. Use a normal VHS cassette for an adjustment tape.
- Make adjustment with the switches set to the following positions.
INPUT SELECT.....LINE 2
- Set the AUDIO MONITOR mode to NORMAL on the menu screen.

[Adjusting sequence]

1. ACE head adjustment...See Mechanism Block Adjustment
2. Recording bias adjustment

1. ACE head adjustment

See "Mechanism Block Adjustment".

2. Recording bias adjustment (MA-140 board)

Mode	REC and PB
Signal	333 Hz, -27.5 dBz } at AUDIO 7 kHz, -27.5 dBs } INPUT, LINE 2
Measuring point	AUDIO LINE OUT L or R
Measuring instrument	Audio level meter
Adjusting element	RV701
Specified value	0 ± 1 dB (1 ± 1dB for B model)

Adjusting method :

- 1) Supply a signal of 333 Hz, -27.5 dBs to Audio.
- 2) Connect the audio level meter to the Audio Line Output.
- 3) Adjust the attenuator so that the audio input level is -27.5 dBs.
- 4) Make recording in the SP mode.
- 5) Set an audio line input signal to 7 kHz and make recording.
- 6) Playback a recorded position, and measure output levels at 333 Hz and 7 kHz.
- 7) Confirm that the 7 kHz playback output levels within a range of the 333 Hz playback output level 0 ± 1 dB. When beyond this range, adjust RV701 and repeat the steps 1) through 7) above. (1 ± 1dB for B model)

7-8. TUNER SYSTEM ADJUSTMENTS

7-8-1. RF AGC Adjustment (IF501)

Signal	Broadcast TV signal
Adjusting element	VR of IF unit (Fig. 7-31.)

Adjusting method :

- 1) Adjust the monitor TV to a maximum contrast.
- 2) Turn the VR to make snow noise visible.
- 3) Turn the VR in an opposite direction and set it to the point where the snow noise disappears.
- 4) Receive each channel and confirm that there are no beat picture corruption snow noise due to cross modulation.




Fig. 7-31.

7-8-2. Receive Separation Adjustment (MA-140 board) (except UB model)

Signal	Lch : 400 Hz Stereo 100% modulation Rch : No modulation
Connect point	AUDIO LINE OUT R
Measuring instrument	Oscilloscope
Adjusting element	RV501

Adjusting method :

- 1) Set the sound multiplex signal generator in the Stereo mode, and set only Lch to 400 Hz, 100% modulation.
- 2) Connect the oscilloscope to the Rch of Audio Line Output.
- 3) Adjust RV501 to minimize Rch output.
When this is done, do not fully turn RV501. (The "STEREO" indication must be illuminated).

7-9. TRANSCODER (TC-27 Board) ADJUSTMENT

[SECAM Digital Picture Mode Chroma Adjustment]
(SL-825B model only)

- Connect the monitor TV to EURO-AV connector (pin ⑨ of CNJ902 on MA-140 board), then perform the adjustment.




Fig. 7-32.

【Adjusting sequence】

- 7-9-1. VCO-1 adjustment
- 7-9-2. VCO-2 adjustment
- 7-9-3. I-REF-1 adjustment
- 7-9-4. I-REF-2 adjustment
- 7-9-5. BELL-1 Filter adjustment
- 7-9-6. BELL-2 Filter adjustment
- 7-9-7. B-Y f_0 adjustment
- 7-9-8. R-Y f_0 adjustment
- 7-9-9. Colour Output Level adjustment

7-9-1. VCO-1 Adjustment (TC-27 Board)

Mode	E-E
Signal	no input signal
Measuring instrument	frequency counter
Measurement point	IC102, Pin ⑨
Adjusting element	RV101
Specified value	15,625 Hz \pm 10 Hz

Adjusting method :

- 1) Connect frequency counter to IC102, Pin ⑨.
- 2) Adjust RV101 for 15,625 Hz \pm 10Hz

7-9-2. VCO-2 Adjustment (TC-27 Board)

Mode	E-E
Signal	no input signal
Measuring instrument	frequency counter
Measurement point	IC104, Pin ⑨
Adjusting element	RV104
Specified value	15,625 Hz \pm 10 Hz

Adjusting method :

- 1) Connect frequency counter to IC104, Pin ⑨.
- 2) Adjust RV104 for 15,625 Hz \pm 10Hz

7-9-3. I-REF-1 Adjustment (TC-27 Board)

Mode	E-E
Signal	Colour bars (SECAM)
Measuring instrument	Oscilloscope
Measurement point	CH-1 : IC102, Pin ④ CH-2 : IC102, Pin ⑨
Adjusting element	RV103
Specified value	$T = 4.2 \pm 0.1 \mu\text{sec}$

Adjusting method :

- 1) Adjust RV103 so that T is $4.2 \pm 0.1 \mu\text{sec}$.




Fig. 7-33.

7-9-4. I-REF-2 Adjustment (TC-27 Board)

Mode	E-E
Signal	Colour bars (SECAM)
Measuring instrument	Oscilloscope
Measurement point	CH-1 : IC104, Pin ④ CH-2 : IC104, Pin ⑨
Adjusting element	RV106
Specified value	$T = 4.2 \pm 0.1 \mu\text{sec}$

Adjusting method :

- 1) Adjust RV106 so that T is $4.2 \pm 0.1 \mu\text{sec}$.




Fig. 7-34.

7-9-5. BELL-1 Filter Adjustment (TC-27 Board)

Mode	E-E
Signal	Colour bars (SECAM)
Measuring instrument	Oscilloscope
Measurement point	IC102, Pin ⑩
Adjusting element	LV102
Specified value	Same colour bars level

Adjusting method :

- 1) Adjust LV102 so that levels of colour bars have the same level.




Fig. 7-35.

7-9-6. BELL-2 Filter Adjustment (TC-27 Board)

Mode	E-E
Signal	Colour bars (SECAM)
Measuring instrument	Oscilloscope
Measurement point	IC104, Pin ⑩
Adjusting element	LV105
Specified value	Same colour bars level

Adjusting method :

- 1) Adjust LV105 so that levels of colour bars have the same level.




Fig. 7-36.

7-9-7. B-Y f_0 Adjustment (TC-27 Board)

Mode	E-E
Signal	Colour bars (SECAM)
Measuring instrument	Oscilloscope
Measurement point/ Adjusting element	B-Y 1 : IC103 Pin ③ LV103
	B-Y 2 : IC105 Pin ③ LV106
Specified value	within 0.05 Vp-p

Adjusting method :

- 1) Connect Pin ⑩ and Pin ⑪ of IC102 and IC104, each.
- 2) Adjust LV103 and LV106 for the level within 0.05Vp-p.




Fig. 7-37.

7-9-8. R-Y f_0 Adjustment (TC-27 Board)

Mode	E-E
Signal	Colour bars (SECAM)
Measuring instrument	Oscilloscope
Measurement point/ Adjusting element	R-Y 1 : IC103 Pin ② LV101
	R-Y 2 : IC105 Pin ② LV104
Specified value	within 0.05 Vp-p

Adjusting method :

- 1) Connect Pin ⑩ and Pin ⑪ of IC102 and IC104, each.
- 2) Adjust LV101 and LV104 for the level within 0.05Vp-p.




Fig. 7-38.

7-9-9. Colour Output Level Adjustment (TC-27 Board)

Mode	E-E
Signal	Colour bars (SECAM)
Measuring instrument	Oscilloscope
Measurement point/ Adjusting element	COLOR LEVEL 1 : IC103 Pin ③/RV102
	COLOR LEVEL 2 : IC105 Pin ③/RV105
Specified value	within 0.75 ± 0.05 Vp-p

Adjusting method :

- 1) Connect Pin ⑩ and Pin ⑫ of IC102 and IC104, each.
- 2) Adjust RV102 and RV105 for 0.75 ± 0.05 Vp-p.







Fig. 7-39.

7-10. ADJUSTMENT PARTS ARRANGEMENT DIAGRAM




7-10. ADJUSTMENT PARTS ARRANGEMENT DIAGRAM


MA-140 BOARD (COMPONENT SIDE)




YC-124 BOARD (COMPONENT SIDE)




MF-167 BOARD (COMPONENT SIDE)




HF-26 BOARD (COMPONENT SIDE)




CG-15 BOARD (COMPONENT SIDE)



TC-27 BOARD (COMPONENT SIDE)



DG-11 BOARD (COMPONENT SIDE)



SLV-725 ~~REP/INC~~ FEP/INC


SONY

SCALE FOR MICROFILM

SONY STANDARD
7-812-00-04 31.4
91-12

1
2
3
4
5
6

A3



symbol	min.	typ.	max.
*R111	2.2K	OPEN	OPEN
*R206	33K	OPEN	OPEN
*R207	18K	16K	OPEN
*R211	47K	82K	OPEN
*R212	47K	OPEN	OPEN
*R213	220	350	560

- | | | | | | |
|-------|-------------------|-----------|-----------------------------|--------|--------------------|
| D101 | S1W8A68 | O201 | 2SB733 or 2SA934 or 2SB1434 | SCR201 | 2P4M |
| D102 | ERA15-86 or MA01A | D201, 207 | AL02Z or ERA18-02 | IC201 | PO12RF13 |
| D103 | ERA22-88 or EG01C | D202 | RD16J5B or MA416B | IC202 | MS237L |
| D104 | ERA15-82 or 11ES2 | D203, 204 | S3L2BU or ERC91-02 or RL4Z | IC203 | PO99RF11 |
| D105 | MA165 | D205, 206 | D3S4M or RK44 or ERC81-004 | IC204 | SI-385BCA |
| D106 | RD3.8ES or MA483B | D208 | AK04 or ERA83-004 | IC205 | HA17431 or AN1431T |
| Q101 | 2SC4231 | D209 | RD39ES or MA439B | | |
| Q102 | 2SC3377 | | | | |
| PC101 | ON3171 | | | | |

DRN (TYPE D 30)
PLN (TYPE D 30)
CHK (TYPE D 30)
APP (TYPE D 30)

CN1

1	DC	+35V
2	SW	GND
3	UNSW	12V
4	SW	9V
5	UNSW	6V
6	SW	5V
7	SW	GND
8	AU	GND

CN2

1	MTR	12V
2	MTR	12V
3	MTR	GND
4	MTR	GND
5	POWER	ON
6	SW	GND
7	SW	5V
8	UNSW	GND
9	UNSW	6V
10	DC	-38V
11	DC	6V
12	DC	0V


△*				UNIT	TOLERANCE	USED ON	NAME	
△*				ANGLE			FAMILY	
△*				SCALE			ORIGINAL MODEL VSX-1761	
△*				MATERIAL (COLOR)		FRESH (COLOR)		
△*				DESCRIPTION				
HISTORY	SUPPL	ECN	NO.	REVISION				SIGN.
YCOUNT	REPL	NO.	DATE					
DRAWN BY	PLANNED BY	CHECKED BY	APPROVED BY	MODEL	SR-425回路図			
				VSX-1761				
				PART NO.	SB-D1594			
				0-479-456-01	1-413-756-11			
				ISSUED	REVISED	SHEET 10		

UPC POWER BLOCK

SLV-825 4Y/4K2

SLV-825 4B

SONY



CN1

1	DC	+35V
2	SW	GND
3	UNSW	12V
4	SW	9V
5	UNSW	6V
6	SW	5V
7	SW	GND
8	AU	GND

CN2

1	MTR	12V
2	MTR	12V
3	MTR	GND
4	MTR	GND
5	POWER	ON
6	SW	GND
7	SW	5V
8	UNSW	GND
9	UNSW	6V
10	DC	-38V
11	DC	6V
12	DC	CV

Symbol	min.	typ.	max.
*R111	2.2K	OPEN	OPEN
*R205	33K	OPEN	OPEN
*R207	18K	16K	OPEN
*R211	47K	82K	OPEN
*R212	47K	OPEN	OPEN
*R213	220	390	560

D181	S1W6A68
D182	ERA15-86 or A-01A
D183	ERA22-88 or EG81C
D184	ERA15-42 or 11E52
D185	MA165
D186	RO3-8ES or MA403B
Q181	2SC4731
Q182	2SC3377
PC181	PS2551

Q281	2SB733 or 2SA934 or 2SB1434
D281	AU82Z or ERA16-82
D282	RO16J5B or MA416B
D283	S3L28U or ERC91-82 or RL4Z
D285	D354M or RK44 or ERC81-804
D288	AK84 or ERA83-884
D289	RO39ES or MA439B

SCR281	204M
IC281	PO12RF13
IC282	MS237L
IC283	PO89RF11
IC284	SI-3358CA
IC285	HA17431 or AN1431T

□	□	□	□
□	□	□	□

UNIT	mm	TOLERANCE		USCD ON		RANK	
ANGLE	3°						
SCALE							
				ORIGINAL MODEL VSX-1760			
				MATERIAL (COLOR)			
				FINISH (COLOR)			
DESCRIPTION (C)							
REVISION							
DRAWN BY		CHECKED BY		APPROVED BY		SIGN.	
VSX-1760		SR-426 回路図		SB-D1914		SHEET 10	
PART NO.		0-479-512-01		1-413-757-11			

SONY STANDARD DRAWING (TYPE D.30)

SCALE FOR MICROFILM

A3



ISSUED _____ REVISED _____

REF NO.	P/N	REMARKS
F 181	1-532-203-00	2A 250V
C 101	1-130-711-00	0.22 μ F/250V
C 102	1-130-710-00	0.1 μ F/250V
C 103	1-161-742-00	CERAMIC 2200PF/400V
C 104	1-161-742-00	"
C 105	"	"
C 106	"	"
C 107	1-152-599-12	CERAMIC 4700PF/400V
C 108	"	"
C 109	"	"
C 110	1-125-497-11	100 μ F/400V (ORIGINAL 82 μ F/400V)
C 111	1-136-207-11	0.047 μ F/500V (" 400V)
C 112	1-162-558-11	100PF/2KV
C 113	1-126-772-11	1 μ F/100V
C 114	1-137-420-11	MAILAR 0.047 μ F/100V
C 115	"	"
C 201	1-124-122-11	100 μ F/50V (85 DEG TYPE)
C 202	1-128-320-11	2200 μ F/16V (105 DEG TYPE)
C 203	1-126-933-11	100 μ F/16V (85 DEG TYPE)
C 204	1-137-420-11	MAILAR 0.047 μ F/100V
C 205	1-126-934-11	220 μ F/16V
C 206	1-126-933-11	100 μ F/16V
C 207	1-128-320-11	2200 μ F/16V (105 DEG TYPE)
C 208	1-124-902-11	0.47 μ F/50V
C 209	1-126-947-11	470 μ F/16V (85 DEG TYPE)
C 210	1-126-934-11	220 μ F/16V (")
C 211	1-124-122-11	100 μ F/50V (")
C 212	1-124-557-11	1000 μ F/25V (")
C 213	1-137-370-11	MAILAR 0.01 μ F/50V
C 214	"	"
R 101	1-214-937-00	1M 1/2W
R 102	1-216-377-11	4.7 Ω /2W (ORIGINAL 4.7 Ω /2W CEMENT)
R 103	1-247-883-00	150K 1/4W
R 104	"	"
R 105	"	"
R 106	1-249-441-11	100K 1/4W
R 107	1-215-928-11	68K/3W
R 108	1-215-887-11	150 Ω /2W
R 109	1-249-397-11	22 Ω 1/4W
R 110	1-249-413-11	470 1/4W
R 111	FOR ADJUSTMENT	
R 112	1-249-441-11	100K 1/4W
R 201	1-249-413-11	470 1/4W
R 202	1-249-409-11	220 1/4W
R 203	1-249-413-11	470 1/4W
R 204	1-247-844-11	3.6K 1/4W
R 205	1-247-822-11	430 1/4W
R 206	FOR ADJUSTMENT	
R 207	"	
R 208	1-260-348-11	47 1/2W
R 209	1-247-838-00	2K

R	2 1 0	1-215-425-00	1.5K	
R	2 1 1	FOR ADJUSTMENT		
R	2 1 2	"		
R	2 1 3	"		
R	2 1 4	1-249-429-11	10K 1/4W	
R	2 1 5	1-219-149-11	FUSE RESISTOR	1 Ω 1/4W
R	2 1 6	1-219-112-11	"	10 Ω 1/4W
R	2 1 7	"	"	
D	1 0 1	8-719-510-06	S1W60	
D	1 0 2	8-719-304-63	RM11C	(ORIGINAL ERA15-06)
D	1 0 3	8-719-948-45	ERA22-08	
D	1 0 4	8-719-200-02	10E-2	
D	1 0 5	8-719-912-20	ISS120	(ORIGINAL MA165)
D	1 0 6	8-719-109-63	RD3, G5S-B2	
Q	1 0 1	8-729-204-94	2SC3559	(ORIGINAL 2SC4231)
Q	1 0 2	8-729-265-52	2SC2655	(" 2SC3377)
PC	1 0 1	9-903-923-01	CN3171	
Q	2 0 1	8-729-140-53	2SB733-34	
D	2 0 1	8-719-313-16	AU02A	(ORIGINAL ERA18-02)
D	2 0 2	8-719-114-82	RD16JSS1	
D	2 0 3	8-719-920-67	ERC91-02	
D	2 0 4	"	"	
D	2 0 5	8-719-981-00	ERC81-004	
D	2 0 6	"	"	
D	2 0 7	8-719-313-16	AU02A	
D	2 0 8	8-719-980-73	ERA83-006	(ORIGINAL ERA83-004)
D	2 0 9	8-719-110-88	RD39ES-B	(" MA4390)
SCR	2 0 1	8-719-104-17	2P5M	(ORIGINAL 2P4M 500V \rightarrow 600V)
IC	2 0 1	NOTHING	PQ12RF13	(PQ12RF11 9-902-066-01)
IC	2 0 2	8-759-632-07	M5227L	
IC	2 0 3	9-902-066-01	PQ12RF11	
IC	2 0 4	8-749-920-43	SI3050CA	(SI-3050CA)
IC	2 0 5	8-759-420-19	AN1431T	(ORIGINAL HA17431P)
L	1 8 1	1-421-915-11	CHALK COIL	
L	2 0 1	9-998-937-01	"	10 μ F
AC	INLET	1-540-054-11	AC INLET	
T	1 0 1	NO SUBSTITUTION (SWITCHING TRANS)		

VHS MECHANICAL ADJUSTMENT MANUAL II

- Please use in conjunction with the SERVICE MANUAL
- This VHS MECHANICAL ADJUSTMENT MANUAL II can be used for NTSC system and PAL system.



VHS VIDEO RECORDER
SONY®

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1. PREPARATIONS FOR CHECKS, ADJUSTMENTS AND REPLACEMENT OF THE DECK MECHANISM					
1-1.	Loading and unloading video cassettes with the power off	3	3-13.	S-guide and T-guide roller assy's	14
1-1-1.	Manual loading and unloading	3	3-14.	Reel lock release and REW gear	14
1-1-2.	Loading and unloading using a separate power source	3	3-15.	Tension regulator arm ass'y, tension regulator band ass'y	15
1-2.	Threading and unthreading with the power off	3	3-16.	S take-up ass'y	15
1-2-1.	Manual threading and unthreading	3	3-17.	S-reel ass'y	16
1-2-2.	Threading and unthreading using a separate power source	3	3-18.	T-reel ass'y	16
1-3.	To complete threading with the FL cassette controller removed	4	3-19.	Pendulum arm ass'y	16
2. PERIODICAL INSPECTION AND REPLACEMENT			3-20.	Relay gear	17
2-1.	Cleaning the rotary head disc ass'y	5	3-21.	Adjuster arm ass'y	17
2-2.	Cleaning the tape transport system	5	3-22.	CAP brake ass'y	17
2-3.	Cleaning the drive system	5	3-23.	Capstan motor	18
2-4.	Periodic Maintenance	6	3-24.	Rotary switch	18
2-5.	Service Tools and Jigs	7	3-25.	RKB cam gear	19
3. REPLACEMENT OF MAJOR COMPONENT PARTS OF THE DECK MECHANISM			3-26.	Sub-chassis ass'y	19
3-1.	FL mechanism	8	3-27.	Pendulum slide plate, pendulum arm	20
3-1-1.	FL door	8	3-28.	The limiter arm and limiter slide plate	20
3-1-2.	Erasure protection lever	8	3-29.	Cam motor	20
3-1-3.	Gear cover ass'y	8	3-30.	Cam gear	20
3-1-4.	Loading motor, worm gear (FL), worm wheel (FL), worm bearing	8	3-31.	Tension regulator arm, S take-up arm	21
3-1-5.	Door OPEN/CLOSE arm	9	3-32.	Mode slide plate, RVS relay gear	21
3-2.	TS ass'y and guide roller ass'y No.2	9	3-33.	Brake arm, brake slide plate	21
3-3.	ACE ass'y	10	3-34.	Right shuttle, right loading gear ass'y	22
3-4.	Drum ass'y	10	3-35.	Left shuttle ass'y, left loading gear ass'y	22
3-5.	Drum base ass'y	10	3-36.	C-roller arm ass'y, C-roller release lever	23
3-6.	Pinch roller ass'y and elevator cam	11	4. ADJUSTMENT		
3-7.	Cam gear, press and transmission gear	11	4-1.	Tape path adjustment	
3-8.	RVS arm ass'y and RVS cam gear	12	4-1-1.	Tension regulator position/tension adjustment	24
3-9.	Guide No.7	12	4-1-2.	Height adjustment of the guide roller No.2	25
3-10.	S-brake ass'y, T-brake ass'y	13	4-1-3.	Height adjustment of guide roller No. 7 and the RVS arm	25
3-11.	T-soft brake ass'y, REV brake arm	13	4-1-4.	Height adjustment of guide rollers No.3 and No.6	26
3-12.	S-soft brake arm ass'y	13	4-1-5.	ACE head ass'y adjustment (rough adjustment)	26
			4-1-6.	ACE head assembly adjustment (precision adjustment)	27
			4-1-7.	X-value adjustment	27
			4-1-8.	Adjustments after replacing the drum (video head)	29
			4-1-9.	Checking the tension and torque	31

1. PREPARATIONS FOR CHECKS, ADJUSTMENTS AND REPLACEMENT OF THE DECK MECHANISM

Note: Refer to "Replacement Method" in the Service Guide for instructions on replacing the cabinet and PC boards. DO not perform cassette loading or threading with the VCR positioned upside-down.

1-1. LOADING AND UNLOADING VIDEO CASSETTES WITH THE POWER OFF. (Fig. 1-1.)

1-1-1. Manual loading and unloading

- 1) Rotate the loading motor in the direction of arrow **A** until loading is completed.
(When unloading, rotate the loading motor in the direction of arrow **B**.)

1-1-2. Loading and unloading using a separate power source.

- 1) Cassette loading is performed by applying approx. 10V (300 mA) to the power terminal of the loading motor using a stabilized DC power source.
(When unloading, apply the same voltage to the opposite polarity of the power terminal.)




Fig. 1-1.

1-2. THREADING AND UNTHREADING WITH THE POWER OFF. (Fig. 1-2)

1-2-1. Manual threading and unthreading

- 1) Rotate the cam motor **1** in the direction of arrow **A** until threading is completed.
(When unthreading, rotate the cam motor **1** in the direction of arrow **B**.)

1-2-2. Threading and unthreading using a separate power source.

- 1) Threading is performed by applying approx. 10V (500 mA) to the power terminal for the cam motor **1** using a DC stabilized power source.
(When unthreading, apply the same voltage to the opposite polarity of the power terminal.)




Fig. 1-2.

1-3. TO COMPLETE THREADING WITH THE FL CASSETTE CONTROLLER REMOVED. (Fig. 1-3)

- 1) Unplug the AC power cord from the power outlet.
- 2) Shield the supply, take-up sensors and the LED with black-masking tape.
- 3) Hold the cassette down switch depressed by taping it, etc.
- 4) Plug the AC power cord into a power outlet.
(At this time, the power should turn on and the tape rewinds for approx. 10 seconds, and the power turns off.)
- 5) Turn the power switch ON so that the mechanism is ready for loading.

Note: In this condition, the VTR is ready to operate in the different operating modes, including the record mode.
At this time, rewind the tape for at least 15 seconds, then perform fast forward (FF).

Note: Following the above, be sure to reset the mechanism to the previous state as outlined below.

- 1) Remove the black-masking tape shielding the supply and take-up sensors, the LED and the tape holding cassette down switch.
- 2) Unplug the AC power cord from the power outlet to reset the system control microprocessor.




Fig. 1-3.

2. PERIODICAL INSPECTION AND REPLACEMENT

We recommend performing the following periodical inspections and maintenance in order to ensure that the unit operates in top condition and offers full performance, as well as realizes a long life of the mechanism and tapes.

* Be sure to perform the following maintenance procedures after the unit is repaired (regardless how long the unit has been used.)

2-1. CLEANING THE ROTARY HEAD DISC ASS'Y

- 1) Press Attach a deer skin cloth (Jig. Ref. No. J-7) soaked in cleaning solution (Jig. Ref. No. J-5) lightly to the rotary drum ass'y, then turn the rotary head disc slowly by hand to clean the surface of the rotary drum ass'y. (At this time, do not turn on the power motor to rotate the rotary head disc for cleaning.)
- 2) Also, do not wipe the drum ass'y by moving the deer skin cloth vertically across the head as this could damage of the tip of the head.

2-2. CLEANING THE TAPE TRANSPORT SYSTEM

- 1) Clean the tape transport surfaces (tape guide, a drum ass'y surfaces, capstan, pinch roller, etc.) with a deer skin cloth soaked in an approved in the recommended cleaning solution.

2-3. CLEANING THE DRIVE SYSTEM

- 1) Wipe the drive mechanism with an ordinary cloth soaked in an approved cleaning solution.




Fig. 2-1.

2-4. PERIODIC MAINTENANCE

Location of Maintenance and Check		User Hours	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	Remarks
		Replacement Part No.											
Performance Check	Clean tape running surfaces	—	○	○	○	○	○	○	○	○	○	○	Always perform after repair.
	Clean, degauss ACE ass'y	—	○	○	○	○	○	○	○	○	○	○	
	Clean, degauss video disc ass'y	—	○	○	○	○	○	○	○	○	○	○	Head life is greatly affected by environment and method of use.
Driving System	Reel belt	3-736-013-01	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Always perform after repair.
Tape Running System	Abnormal noise	—	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust or replace source of abnormal noise.
	Back tension measurement	—	-	☆	-	☆	-	☆	-	☆	-	☆	Check according to 4-1-1. Spec: 24 — 34g/cm (Measured with torque cassette)
	Brake system check	—	-	☆	-	☆	-	☆	-	☆	-	☆	
	REC/PB function check	—	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Always perform after repair.
	Forward torque measurement		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Spec: 80 — 140 g·cm

○ Cleaning ☆ Check

Note: Refer to the above items for part replacement when performing an overhaul.

2-5. SERVICE TOOLS AND JIGS

Ref. No.	Description	Part No.	Printing on jig	Remarks
J-1	Master plane	H-7099-279-H		
J-2	Reel disc height jig	H-7099-038-H		
J-3	Torque gauge adapter	H-7099-035-H		
J-4	Torque gauge	H-7099-039-H		
J-5	0.93mm Allen wrench	H-7099-202-H		
J-6	NTSC torque cassette VHT-063S PAL torque cassette	J-6082-011-A J-6082-066-A		For rewind torque and back tension
	NTSC torque cassette VHT-404S PAL torque cassette	J-6082-012-A J-6082-067-A		For cue/review
J-7	NTSC alignment tape JVC-MH-1 PAL alignment tape JVC-MH-2	H-7099-046-H H-7099-052-H		
	NTSC Hi-Fi alignment tape PAL Hi-Fi alignment tape	H-7099-153-H H-7099-175-H		
J-8	Cleaning fluid	Y-2031-001-0	—	
J-9	Chamois cloth	2-034-697-00	—	Cleaning
J-10	Head degausser	Widely available	—	Video, audio head degaussing
J-11	Small adjustment mirror (with handle)	J-6080-029-A	SL-5052	For tape path and tape running adjustment and check
	Small adjustment mirror (mirror only)	J-6080-030-1		




Fig. 2-2. Service tools and jigs

3. REPLACEMENT OF MAJOR COMPONENT PARTS OF THE DECK MECHANISM

- Note:**
- Refer to "Replacement Method" in the Service Guide for replacing the cabinet and PC boards.
 - When mounting parts, reverse the replacement procedure while referring to "Precautions on Mounting Parts".

- After grease coated parts such as gears are replaced, re-grease the replaced part.
- Do not touch the guides (taped surface) and brake shoe directly with your fingers or grease them, etc.
- Gears must be mounted so that they mesh with each other.

3-1. FL MECHANISM

3-1-1. FL door (Fig. 3-1.)

- 1) Press the claw ① in the direction of arrow A, then remove the FL door ② in the direction of arrow B.




Fig. 3-1.

3-1-2. Erasure protection lever (Fig. 3-2)

- 1) Remove the spring ①.
- 2) Disengage the claw ②, then slide the erasure protection lever ③ in the direction of arrow A.
- 3) Disengage the erasure protection lever ③ in the direction of arrow B.




Fig. 3-2.

3-1-3. Gear cover ass'y (Fig. 3-3)

- 1) Disengage the four claws ①, then remove the gear cover ass'y ②.




Fig. 3-3.

3-1-4. Loading motor, worm gear (FL), worm wheel (FL), worm bearing (Fig. 3-4)

- 1) Remove washer 3 ①, then pull out the worm wheel (FL) ②.
- 2) Remove the two screws ③, then remove the loading motor ④.
- 3) Remove the worm gear (FL) ⑤ and worm bearing ⑥.




Fig. 3-4.

3-1-5. Door OPEN/CLOSE arm (Fig. 3-5)

- 1) Remove the spring ❶.
- 2) Pull out the door OPEN/CLOSE arm ❷.




Fig. 3-5.

[Precautions on remounting] (Figs. 3-6 and 3-7.)

- When mounting the gear cover ass'y, match up the two holes on the gear cover ass'y with the two holes on the worm wheel (FL) and then with the hole on the right drive arm ass'y.
- Mesh the FL door and the door OPEN/CLOSE arm together as shown in A section in the figure below.
- The erasure protection lever shaft must fit into the groove on the left drive arm ass'y.




Fig. 3-6.




Fig. 3-7.

3-2. TS ASS'Y AND GUIDE ROLLER ASS'Y No. 2 (Fig. 3-8)

- 1) Remove the spring ❶.
- 2) Remove the TS ass'y ❷ in the direction of arrow A.
- 3) Turn guide roller ass'y No. 2 ❸ in the direction of arrow B and pull it out.

[Precautions on remounting]

- Clean the surface of guide roller No. 2 ❸ where the tape is attached.
- Apply lubricant over the section shown in Figure A below.

[Adjustment after replacement]

- Perform tape path adjustments as described in 4-1.




Fig. 3-8.

3-3. ACE ASS'Y (Fig. 3-9)

- 1) Slide the torsion coil spring ① in the direction of the arrow.
- 2) Remove the nylon nut N3 ②, then pull out the ACE ass'y ③.
- 3) Remove the ACE adjuster screw ④.

[Precautions on remounting]

- Clean the surface of the ACE ass'y ③ where the tape is attached.
- Hook both ends of the torsion coil spring ① to the ass'y as shown in Figure A below.
- Adjust the ACE adjuster screw ④ to the height shown in Figure A.

[Adjustment after replacement]

- Perform tape path adjustments as described in 4-1.




Fig. 3-9.

3-4. DRUM ASS'Y (Fig. 3-10)

- 1) Remove the three screws ①, then remove the drum ass'y ②.

[Precautions on remounting]

- Do not touch the head tips ③ and the ground plate ④ directly with your fingers or tools.
- Clean the surface of the drum ass'y ② where a tape is attached.
- The stopper ⑤ must be attached at the point shown in the figure below.
- Screws must be fastened with a $6\text{kg}\cdot\text{cm}$ ($\pm 1\text{kg}\cdot\text{cm}$) screw fastening torque. (The screws can be mounted in any order.)

[Adjustment after replacement]

- Perform tape path adjustments as described in 4-1.




Fig. 3-10.

3-5. DRUM BASE ASS'Y (Fig. 3-11)

- 1) Remove the drum. (Refer to 3-4.)
- 2) Remove the three screws ①, then remove the drum base ass'y ②.

[Precautions on remounting]

- The space ③ for the drum base must be mounted in its previous position as shown in the figure below. (Note that some units do not feature the spacer ③.)
- Fastening torque must be $10\text{kg}\cdot\text{cm}$ ($\pm 1\text{kg}\cdot\text{cm}$)
- The screws must be mounted in order of (a), (b) and (c).




Fig. 3-11.

3-6. PINCH ROLLER ASS'Y AND ELEVATOR CAM (Fig. 3-12)

- 1) Remove the two claws ①, then pull out the stopper ②.
- 2) Pull out the pinch roller ass'y ③.
- 3) Pull out the elevator cam ④.

[Precautions on remounting]

- Clean the surface of the pinch roller ass'y ③ where the tape is attached.
- Match up the □ marks on the elevator cam ④ and cam gear, press ⑤.




Fig. 3-12.

3-7. CAM GEAR, PRESS AND TRANSMISSION GEAR (Fig. 3-13)

- 1) Remove the pinch roller ass'y. (Refer to 3-6.)
- 2) Remove the screw ①, then remove the lid release plate ②.
- 3) Remove the two claws ③, then pull out the cam gear, press ④.
- 4) Remove the washer 2 ⑤, then pull out the transmission gear ⑥.

[Precautions on remounting]

- Check the top and bottom of the transmission gear ⑥.
- Match up the hole ⑦ on the chassis with the hole ⑦ on the cam gear, press ④.
- Match up the □ mark on the cam gear, press ④ with the □ mark on the alleviator cam ⑧.




Fig. 3-13.

3-8. RVS ARM ASS'Y AND RVS CAM GEAR (Fig. 3-14)

- 1) Remove the nylon nut M2 ① and plastic washer ②.
- 2) Disengage the claw ③, then pull out the RVS arm ass'y ④.
- 3) Remove washer 2 ⑤, then pull out the RVS cam gear ⑥.

[Precautions on remounting]

- The holes ⑦ in the chassis and in the RVS cam gear ⑥ must match up. Also, make sure to match up the holes ⑨ on the cam gear, press ⑧ and the chassis.
- The spring ⑩ must be hooked as shown in Fig. A below.
- Clean the surface of the RVS arm ass'y ④ where a tape is attached.
- Apply 1/2 drop of lubricant to the shaft ⑪.

[Adjustment after replacement]

- Perform tape path adjustments as described in 4-1.




Fig. 3-14.

3-9. GUIDE No. 7 (Fig. 3-15)

- 1) Remove the nylon nut M3 ①.
- 2) Pull out guide flange No. 7 ②, guide sleeve No. 7 ③, guide flange No. 7 ④ and compression coil spring ⑤ in the given order.

[Precautions on remounting]

- Clean the surface of the guide sleeve No. 7 ③ where the tape is attached.
- Adjust the height of guide No. 7 to the height shown in Fig. A below.

[Adjustment after replacement]

- Perform tape path adjustments as described in 4-1.




Fig. 3-15.

3-10. S-BRAKE ASS'Y, T-BRAKE ASS'Y (Fig. 3-16)

- 1) Remove the spring ①.
- 2) Disengage the claw ②, then pull out the S-brake ass'y ③.
- 3) Disengage the claw ④, then pull out the T-brake ass'y ⑤.

[Precautions on remounting]

- Do not touch the brake shoes for the respective S-brake ③ and T-brake ⑤ ass'y's directly with your fingers.
- Do not hold on to the S-brake ③ and T-brake ⑤ ass'y's by the arms when inserting them.
- The T-brake ass'y ⑤ must be positioned above the S-brake ass'y ③ as shown in Fig. A below.




Fig. 3-16.

3-11. T-SOFT BRAKE ASS'Y REV BRAKE ARM (Fig. 3-17)

- 1) Remove the end of the spring ① from the REV brake arm ②.
- 2) Remove the end of the spring ③ from the chassis.
- 3) Disengage the claw ④, then pull out the T-soft brake ass'y ⑤.
- 4) Disengage the claw ⑥, then pull out the REV brake arm ②.

[Precautions on remounting]

- Do not touch the brake shoe of the T-soft brake ass'y ⑤ directly with your fingers.




Fig. 3-17.

3-12. S-SOFT BRAKE ARM ASS'Y (Fig. 3-18)

- 1) Unhook the end of the spring ① from the chassis.
- 2) Disengage the claw ②, then pull out the S-soft brake arm ass'y ③.

[Precautions on remounting]

- The S-soft brake arm ass'y must not clamp down the tension regulator band ass'y ④ nor be positioned below the tension regulator band ④.




Fig. 3-18.

3-13. S-GUIDE AND T-GUIDE ROLLER ASSY'S (Fig. 3-19)

- 1) Loosen the setscrew ①, then remove the S-guide roller ass'y ② by turning it in the direction of the arrow A.
- 2) Loosen the setscrew ③, then remove the T-guide roller ass'y ④ by turning it in the direction of arrow B.

[Precautions on remounting]

- Clean the surfaces of the S-guide roller ② and T-guide roller ass'y's ④ where a tape is attached.

[Adjustment after replacement]

- Perform tape path adjustments as described in 4-1.




Fig. 3-19.

3-14. REEL LOCK RELEASE AND REW GEAR (Fig. 3-20)

- 1) Disengage the two claws ①, then remove the reel lock release ② along with the spring ③ (while the spring is still attached).
- 2) Next, pull out the REW gear ④ with the spring bearing ⑤ still attached).

[Precautions on remounting]

- Make sure that the small thrust bearing ⑥ remains attached.
- Make sure that the two claws ① lock the reel lock release ② in place.
- Apply 1/2 drop of lubricant to the shaft ⑦.
- Make sure that the spring ③ adheres to the reel lock release ② and that it fits inside the rib of the REW gear ④.
- Mount the REW gear ④ by meshing it with gear ⑧.




Fig. 3-20.

3-15. TENSION REGULATOR ARM ASS'Y, TENSION REGULATOR BAND ASS'Y (Fig. 3-21)

- 1) Remove the reel lock release ass'y. (Refer to Fig. 3-14.)
- 2) Disengage the three claws marked ① and the claw marked ②, then remove the tension regulator band ass'y ③.
- 3) Unhook the end of the spring ④ from the chassis.
- 4) Disengage the claw ⑤, then pull out the tension regulator arm ass'y ⑥.

[Precautions on remounting]

- Roll up the tension regulator band ③ on the S-reel by turning the S-soft brake arm ass'y ⑦ in the direction of the arrow.
- Hook the spring ④ at the center of the spring hook ⑧.
- Do not touch the brake shoe of the tension regulator band ass'y ③ directly with your fingers.
- Mount the tension regulator arm ass'y ⑥ at the position shown in Fig. A below.

[Adjustment after replacement]

- Check the back tension. (Refer to 4-1-1.)
- Perform tape path adjustments as described in 4-1.




Fig. 3-21.

3-16. S TAKE-UP ASS'Y (Fig. 3-22)

- 1) Remove the tension regulator arm ass'y and the tension regulator band ass'y. (Refer to 3-15.)
- 2) Unhook the end of the spring ① from the S take-up arm ②.
- 3) Disengage the two claws ③, then remove the S take-up ass'y ④.




Fig. 3-22.

3-17. S-REEL ASS'Y (Fig. 3-23)

- 1) Remove the S-soft brake arm ass'y. (Refer to 3-12.)
- 2) Remove the reel lock release. (Refer to 3-14.)
- 3) Remove the tension regulator band ass'y. (Refer to 3-15.)
- 4) Turn the S-brake ass'y ① in the direction of the arrow.
- 5) Pull out the S-reel ass'y ②.

[Precautions on remounting]

- At least one reel stand thrust bearing ③ must be attached (but not more than two).
- Do not touch the outer edge of the S-reel ass'y ② directly with your fingers.
- Apply 1/2 drop of lubricant over the shaft ④.
- Mount the S-reel ass'y ② while meshing it with the relay gear ⑤.




Fig. 3-23.

3-18. T-REEL ASS'Y (Fig. 3-24)

- 1) Remove the T-soft brake arm ass'y. (Refer to 3-11.)
- 2) Remove the reel lock release ass'y. (Refer to 3-14.)
- 3) Turn the T-brake ass'y ① in the direction of the arrow.
- 4) Pull out the T-reel ass'y ②.

[Precautions on remounting]

- At least one reel stand thrust bearing ③ must be attached (but not more than two).
- Do not touch the outer edge of the T-reel ass'y ② directly with your fingers.
- Apply 1/2 drop of lubricant on the shaft ④.
- Mount the T-reel ass'y ② while meshing it with the relay gear ⑤.




Fig. 3-24.

3-19. PENDULUM ARM ASS'Y (Fig. 3-25)

- 1) Remove the reel lock release ass'y. (Refer to 3-14.)
- 2) Remove the washer 2 ①, then pull out the pendulum arm ass'y ②.

[Precautions on remounting]

- Fit the boss on the pendulum cap ③ into the gap in the pendulum slide plate ④.
- The plastic slide ⑤ must be attached.
- Apply 1/2 drop of lubricant on the shaft ⑥.
- Mount the pendulum arm ass'y ② by meshing it with the upper limiter gear ⑦.




Fig. 3-25.

3-20. RELAY GEAR (Fig. 3-26)

- 1) Remove the reel lock release and REW gear. (Refer to 3-14.)
- 2) Remove the S-reel ass'y. (Refer to 3-17.)
- 3) Remove the T-reel ass'y. (Refer to 3-18).
- 4) Pull out the two relay gears ①.

[Precautions on remounting]

- The relay gears ① must rotate smoothly after remounting.
- Apply 1/2 drop of lubricant to the respective shafts ②.




Fig. 3-26.

3-21. ADJUSTER ARM ASS'Y (Fig. 3-27)

- 1) Remove screw ①.
- 2) Remove washer ⑥.
- 3) Remove the end of the spring ② hooked to the chassis.
- 4) Remove the end of the timing belt ③ from the capstan motor arm ass'y.
- 5) Disengage the claw ④, then remove the adjuster arm ass'y.

[Precautions on remounting]

- First mount the adjuster arm ass'y ⑤, timing belt ③ and spring ②, then attach the washer ⑥ and fasten the screw ①.
- The screw fastening torque must be within 5kg·cm ($\pm 1\text{kg}\cdot\text{cm}$).




Fig. 3-27.

3-22. CAP BRAKE ASS'Y (Fig. 3-28)

- 1) Loosen the screw ①, then push the timing belt ② in the direction of the arrow.
- 2) Unhook the end of the spring ③ from the chassis.
- 3) Disengage claw ④, then pull out CAP brake ass'y ⑤.

[Precautions on remounting]

- Do not touch the brake shoe of the CAP brake ass'y ⑤ directly with your fingers.




Fig. 3-28.

3-23. CAPSTAN MOTOR (Fig. 3-29)

- 1) Turn the ACE ass'y ① in the direction of arrow A as shown in Fig. A below, then remove three screws ②.
- 2) Remove screw ③, then remove the rotor clamp ④.
- 3) Turn the CAP brake ass'y ⑤ in the direction of arrow B, then pull out the capstan motor ⑥.

[Precautions on remounting]

- Clean the section of the capstan motor ⑥ where the tape is attached.
- Do not touch the brake shoe of the CAP brake ass'y ⑤ directly with your fingers.
- Of the three screws ②, first fasten screw A temporarily, then fasten screws B and C firmly, followed by screw A.
- The screw fastening torque must be within $3\text{kg}\cdot\text{cm} \pm 1\text{kg}\cdot\text{cm}$.

[Adjustments after mounting]

- Perform tape path adjustments as described in 4-1.




Fig. 3-29.

3-24. ROTARY SWITCH (Fig. 3-30)

- 1) Remove the adjuster arm ass'y. (Refer to 3-21.)
- 2) Remove the screws ① and ②, then pull out the rotary switch ③.

[Precautions on remounting]

- Match up the ● mark on the rotary switch ③ with the ▲ mark on the RKB cam gear ④ as shown in Fig. A.
- Match up holes ⑥ on the pendulum arm ⑤ and the chassis.




Fig. 3-30.

3-25. RKB CAM GEAR (Fig. 3-31)

- 1) Remove the adjuster arm ass'y. (Refer to 3-22.)
- 2) Remove washer 2 ①, then pull out the RKB cam gear ②.

[Precautions on remounting]

- When the limiter arm ③ is pushed in the direction of the arrow, the pin must fit into the notch on the RKB cam gear ②.
- The ■ mark on rotary switch ⑤ must match up with the ◀ mark on the RKB cam gear ② as shown in Fig. A.
- Apply 1/2 drop of lubricant to shaft ⑥.
- Match up the holes ④ on the RKB cam gear ② and the mode slide plate.




Fig. 3-31.

3-26. SUB-CHASSIS ASS'Y (Fig. 3-32)

- 1) Remove the reel lock release arm and REW gear. (Refer to 3-15.)
- 2) Remove the pendulum arm ass'y. (Refer to 3-19.)
- 3) Remove the adjuster arm ass'y. (Refer to 3-22.)
- 4) Remove the three screws ①, then remove sub-chassis ass'y ②.

[Precautions on remounting]

- The switching arm ③ must be switched in the direction of the arrow.
- The screws must be fastened in order of a, b and c.
- Mount the sub-chassis carefully so as not to damage the gear.
- The corner edge of the lug terminal ④ must fit into the gap between the chassis ass'y ② and mechanism chassis.




Fig. 3-32.

3-27. PENDULUM SLIDE PLATE, PENDULUM ARM (Fig. 3-33)

- 1) Remove the rotary switch. (Refer to 3-24.)
- 2) Remove the RKB cam gear. (Refer to 3-25.)
- 3) Remove the sub-chassis ass'y. (Refer to 3-26.)
- 4) Disengage the two claws ①, then pull out the pendulum slide plate ②.
- 5) Unhook the spring ③.
- 6) Disengage the claw ④, then pull out pendulum arm ⑤.

[Precautions on remounting]

- The shaft ⑥ must fit into hole ⑦.




Fig. 3-33.

3-28. THE LIMITER ARM AND LIMITER SLIDE PLATE (Fig. 3-24)

- 1) Remove the RKB cam gear. (Refer to 3-25.)
- 2) Remove the sub-chassis. (Refer to Fig. 3-26.)
- 3) Disengage the claw ①, then pull out the limiter arm ②.
- 4) Disengage the two claws ③, then pull out the limiter slide plate ④.

[Precautions on remounting]

- The shaft ⑤ must fit into the hole ⑥.




Fig. 3-34.

3-29. CAM MOTOR (Fig. 3-35)

- 1) Remove the sub-chassis ass'y. (Refer to 3-26.)
- 2) Disengage the six claws ①, then remove the cam motor ② and worm gear ③.

[Precautions on remounting]

- Check the meshing of cam motor ② and worm gear ③.




Fig. 3-35.

3-30. CAM GEAR (Fig. 3-36)

- 1) Remove the three washers 2 ①, then pull out the cam gear holder ②.
- 2) Pull out the cam gear ③.

[Precautions on remounting]

- Match up the right loading gear ass'y, the tension regulator arm, the S take-up arm, the work wheel, the brake arm and the mode slide plate with respective holes ④ to ⑨ on the chassis in that order.
- Match up the hole ⑩ on the mode slide plate with the hole ⑩ in cam gear ③.
- Apply 1/2 drop of lubricant to the shaft ⑪.




Fig. 3-36.

**3-31. TENSION REGULATOR ARM, S TAKE-UP ARM
(Fig. 3-37)**

- 1) Remove the cam gear. (Refer to 3-30)
- 2) Disengage the claw ①, then remove the tension regulator arm ②.
- 3) Remove the end of the spring ③ from the S take-up arm ④.
- 4) Disengage the claw ⑤, then pull out S take-up arm ④.




Fig. 3-37.

**3-32. MODE SLIDE PLATE, RVS RELAY GEAR
(Fig. 3-38)**

- 1) Remove the RKB cam gear. (Refer to 3-25.)
- 2) Remove the cam gear. (Refer to 3-30.)
- 3) Remove the two washers 2 ①.
- 4) Turn the CAP brake ② in the direction of the arrow, then pull out mode slide plate ③.
- 5) Pull out the RVS relay gear ④.

[Precautions on remounting]

- Match up the hole ⑤ on the RVS relay gear ④ with hole ⑤ in the chassis.
- Match up the holes ⑥ on the mode slide plate ③ with holes ⑥ in the chassis.
- Apply 1/2 drop of lubricant to the shaft ⑦.




Fig. 3-38.

3-33. BRAKE ARM, BRAKE SLIDE PLATE (Fig. 3-39)

- 1) Remove the sub-chassis. (Refer to 3-26.)
- 2) Remove the cam gear. (Refer to 3-30.)
- 3) Disengage the claw ①, then pull out the brake arm ②.
- 4) Disengage the two claws ③, then pull out the brake slide plate ④.

[Precautions on remounting]

- Insert the shaft ⑤ into hole ⑥.




Fig. 3-39.

3-34. RIGHT SHUTTLE, RIGHT LOADING GEAR ASSY'S (Fig. 3-40)

- 1) Remove the mode slide plate. (Refer to 3-32.)
- 2) Remove the plastic slider ❶, then pull out the right shuttle ass'y ❷.
- 3) Pull out the right loading gear ass'y ❸.

[Precautions on remounting]

- Match up the ▲ mark on the right loading gear ass'y ❸ with the ▲ mark on the left loading gear ass'y ❹ as shown in Fig. A below.
- Apply 1/2 drop of lubricant to the shaft ❺.
- Do not hold on to the arm when pressing on the right loading gear ❸.
- Clean the section of the right shuttle ass'y ❷ where the tape is attached.




Fig. 3-40.

3-35. LEFT SHUTTLE ASS'Y, LEFT LOADING GEAR ASS'Y (Fig. 3-41)

- 1) Remove the right shuttle ass'y and right loading gear ass'y. (Refer to 3-34.)
- 2) Remove the plastic slider ❶, then pull out the left shuttle ass'y ❷.
- 3) Remove washer 2 ❸, then pull out the left loading gear ass'y ❹.

[Precautions on remounting]

- Apply 1/2 drop of lubricant to shaft ❺.
- The tension regulator arm ass'y ❻ and left shuttle ass'y ❷ must be positioned as shown in Fig. A below.
- Do not hold on to the arm of the left loading gear ass'y ❹ when the left loading gear ass'y ❹ is pressed.
- Clean the section of the felt shuttle ass'y ❷ where the tape is attached.

[Adjustments after replacement]

- Form tape path adjustments as described in 4-1.




Fig. 3-41.

3-36. C-ROLLER ARM ASS'Y, C-ROLLER RELEASE LEVER (Fig. 3-42)

- 1) Disengage the claw ①, then pull out the C-roller arm ass'y ②.
- 2) Unhook the end of the spring ③ from the chassis.
- 3) Disengage the two claws ④, then pull out the C-roller release lever ⑤.

[Precautions on remounting]

- Mount C-roller arm ass'y ② so that the hole ⑥ on the C-roller arm ass'y ② fits into the boss ⑦ on the C-roller release lever ⑤.




Fig. 3-42.

4. ADJUSTMENT

4-1. TAPE PATH ADJUSTMENT

The "Tape path" refers to the route of the tape from the supply reel disk to the take-up reel disc via the video heads. Each component part of the tape transport system, particularly the surface of parts which make direct contact with the tape must always be kept clean, free of dust, oil, scratches and so forth.

The tape path system is factory preadjusted. When parts of the tape transport system are replaced, be sure to make the required adjustments as precisely as possible in order to ensure stable tape transport.

4-1-1. Tension regulator position/tension adjustment (Fig. 4-1.)

Purpose: Stabilizes contact of the video head and the tape to maintain the tension of the tape so that it feeds at a constant level.

● Position adjustment

Mode	Threading is completed without a cassette loaded. (Refer to section 1-2.)
Adjustment locations	Tension band holder

[Adjustment method]

- 1) Allow the unit to go through the threading procedure without a cassette loaded.
- 2) Set the VTR unit to playback, then turn the tension band adjuster lever so that the gap between guide No. 0 and tension arm is within $4.5 \pm 0.4\text{mm}$. *(Set the unit to playback without a cassette loaded.)
- 3) After adjustment, go through the loading procedure once more without a cassette loaded, then check the position of the tension arm.

● Tension adjustment

Mode	Playback
Measuring instrument/tool	Torque cassette
Adjustment locations	Position for hooking the tension spring
Specification	28 to 34 g·cm

[Adjustment method]

- 1) Playback the torque cassette.
- 2) Check that the center value deviation reading on the torque cassette meets with the standards.
- 3) When the reading is higher than the standards: Move the spring toward direction **A**.
When the reading is less than the standards: Move the spring toward direction **B**.

Note: Move the spring to the tension spring hook position and recheck the tension arm position. If the arm position is misaligned, adjust the position and tension of the tension arm.




Fig. 4-1.

4-1-2. Height adjustment of the guide roller No. 2 (Fig. 4-2)

Mode	Playback
Tool	Blank tape
Adjustment locations	Guide roller height adjuster screw

[Adjustment method]

- 1) Load a new tape in the unit, then play it back.
- 2) Make sure that the lower flange of guide roller No. 2 does not curl up.
- 3) When the tape curls up : Turn the guide roller adjuster screw clockwise.
When the tape does not fit into the lower flange : Turn the guide roller adjuster screw counter-clockwise.
- 4) After the above check, separate the tension arm from the tape, then re-attach it slowly. At this time, check if the tape curls up at the lower flange of the guide roller No. 2 and if the curl disappears within 2 seconds.
- 5) If curl does not disappear in two seconds : Turn the adjuster screw clockwise.
If the tape does not curl up : Turn the adjuster screw counter-clockwise.




Fig. 4-2.

4-1-3. Height adjustment of guide roller No. 7 and the RVS arm (Fig. 4-3.)

Mode	Playback
Tool	Blank tape
Adjustment locations	Height adjuster nut

[Adjustment method]

- 1) Load the tape into the VTR and play it back, then adjust the height of the guide roller No. 7 so that the tape runs along the lower flange of guide roller No. 7.
- 2) If the guide roller is too low : Turn the height adjuster nut counter-clockwise.
If the guide roller is too high : Turn the height adjuster nut clockwise.
- 3) Run the tape in REV, then adjust the height of the RVS arm so that the tape runs along guide roller No. 7.
- 4) If the tape gets caught in the upper flange of guide roller No. 7 : Turn the RVS arm height adjuster nut clockwise.
- 5) If the tape catches on the lower flange of guide roller No. 7 : Turn the RVS arm height adjuster nut counter-clockwise.




Fig. 4-3.

**4-1-4. Height adjustment of guide rollers
No. 3 and No. 6 (Fig. 4-4)**

Mode	Playback
Signal	Hi-Fi alignment tape (Hi-Fi 400Hz)
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check.
Adjustment locations	Guide roller height adjuster screw.

[Adjustment method]

- 1) Tracking (playback): Turn off the auto tracking, then press the tracking buttons ∇ and Δ simultaneously to set the tracking at the center position.
(If adjustment is made after the drum is replaced, the tracking must be set at the max. Rf output position.)
- 2) Height adjuster screw: Even out the RF output waveforms.
- 3) Press the tracking buttons (playback), ∇ and Δ alternately.
- 4) Check that RF output drops the same amount at the front and rear edges.




Fig. 4-4.

**4-1-5. ACE head ass'y adjustment
(rough adjustment) (Figs. 4-5 and 4-6)**

Purpose: Allows the tape to make even contact with the head for recording and playback of the specified track.

Mode	Playback
Tool	Blank tape
Adjustment locations	Height adjuster nut, tilt adjuster screw

[Adjustment method]

- 1) Mount the ACE head ass'y. At this time, adjust the height so that the height of guide flange No. 7 matches the level of the lower edge of the control head.
- 2) Remove the adjustment tool and load a new tape, then set the unit for playback.
- 3) Check that the tape does not curl or raise up noticeably near the ACE head.
- 4) If the tape curls up or raises noticeably, readjust the tilt adjuster screw, the azimuth adjuster screw and the height adjuster nut.
(The height of the ACE head should be adjusted so that the lower edge of the tape is approx. 0.1 to 0.15 mm from the control head.)
- 5) Perform precision adjustment.




Fig. 4-5.




Fig. 4-6.

4-1-6. ACE head assembly adjustment (precision adjustment)

Mode	Playback
Signal	Alignment tape (JVC-MH-1 1KHz)
Measuring instrument	Oscilloscope
Measuring point	Audio output terminal
Adjustment locations	Azimuth adjuster screw Height adjuster nut Tilt adjuster screw

[Adjustment method]

- 1) Adjust the tilt adjuster screw in the FWD or REV mode so that the lower flange of guide No. 7 does not curl up or raise.
- 2) Alternately adjust the azimuth adjuster screw, the height adjuster nut, and the tilt adjuster screw to maintain even audio output at maximum with minimum deviation.




Fig. 4-7.

4-1-7. X-value adjustment

Purpose : To obtain compatibility with other VTR.

Precaution : Be sure to perform the preset tracking adjustment before perform this adjustment. (Refer to the Service Guide.)

Turn off the auto tracking and set the VTR for manual tracking mode.

Mode	Playback
Signal	Hi-Fi alignment tape (Hi-Fi 400Hz), alignment tape (JVC-MH-1)
Measuring instrument	Oscilloscope
Measuring point	CH-1: Connector PB RF pin for RF PC board check. CH-2: Connector RF SW P pin for RF PC board check. (Check with the CHA head)
Adjustment locations	X-value adjuster screw

[Adjustment method]

● Adjustment by Hi-Fi alignment tape

When the tracking is set at the center position (by pressing the ∇ and Δ keys simultaneously), adjust the RF output to maximum.




Fig. 4-8.
-27-

● **Adjustment by Alignment tape (JVC-MH-1)**

Adjust the X-value adjuster screw so that maximum RF

output is obtained and also that the RF output drops to the same position on pressing the respective ▽ and ▴ buttons while the tracking is set at the center position.





Fig. 4-9.

4-1-8. Adjustments after replacing the drum (video head)

Purpose : Co-relative height, X-value and other factors of the drum will deviate from those of the guide roller. If the drum is replaced properly, these deviations are extremely small.

Precaution : Turn off the auto tracking and set the manual tracking mode.


Mode	Playback
Signal	Alignment tape (JVC-MH-1), blank tape
Measuring instrument	Oscilloscope
Measuring point	CH-1 : Connector PB RF pin for RF PC board check. CH-2 : Connector RF SW P pin for RF PC board check.
Adjustment locations	Guide roller (refer to 4-1-5.) Switching position, Tracking preset, SP delay mono-multi, X-value (refer to 4-1-8) } (Refer to the Service Guide)




[Adjustment method]

[Checking the evenness and fluctuation of the RF output]


- 1) Set the RF output to the maximum level using the tracking buttons.



- 2) Perform fine adjustment of the voltage level range of the oscilloscope, then adjust the RF output deviation to within 4 gradations.



- 3) Press the tracking buttons and adjust the maximum amplitude of the RF output to within 3 gradations.
- 4) At this time, check if the minimum amplitude is more than 2 gradations.



- 5) Check that the RF output fluctuation between minimum and maximum levels is within 13%.

4-1-9. Checking the tension and torque

Purpose : To check that the tension, torque and compression force of the tape take-up section and mobile sections to ensure smooth tape run and achieve standard VTR performance.

If the tape transport is not smooth or problems occur in relation to the tape transport speed, perform the following check.

Mode	Each operation mode without loading a cassette tape. (Refer to section 1-3.)
Measuring instrument	Torque gauge, Torque gauge adapter

Item	VTR operation mode	Reel to be measured	Measurement value
Main brake torque	Stop	Supply and take-up reels	170g·cm or more
Review torque	Review	Supply reel	180±30g·cm (using the torque cassette)
Take-up torque	Playback	Take-up reel	80 to 140g·cm (using torque cassette)
Back tension torque	Rewind	Take-up reel	4 to 25 g·cm

[Check method]

Measure the torque using the torque gauge and torque gauge adaptor with the torque gauge fixed.




Fig. 4-13.

